

L e n s e s



Lenses Selection Guide

B107

Plano Convex Lenses



Plano Convex Lens
SLB-P/SLSQ-P/SLSQK-P

B108

Plano Concave Lenses



Plano Concave Lenses
SLB-N/SLSQ-N/SLSQK-N

B118

Biconvex Lenses



Biconvex Lenses
SLB-B-P/SLSQ-B-P

B123

Biconcave Lenses



Biconcave Lenses
SLB-B-N/SLSQ-B-N

B129

Kit



ϕ 25.4 (BK7) Lens Kit
SLB-25.4-SET

B132

Contact sheet for Special Order for spherical lens **B133**

Reasonable Lens



Reasonable Plano Convex Lens
S-SLB-P/S-SLB-B-P

B134



Reasonable Plano Concave Lens
S-SLB-N/S-SLB-B-N

B138

Cylindrical Lenses



Cylindrical Plano Convex Lenses
CLB-P/CLSQ-P

B140



Cylindrical Plano Concave Lenses
CLB-N/CLSQ-N

B147

Contact sheet for Special Order for spherical lens **B150**



Rod Lenses
RODB

B151

Others



Fly-Eye Lens
FEL

B152



Fresnel Lens
FRL

B153



Micro Spheres
MS

B154



Micro Lens
SLM

B156



Aspheric Plano Convex Lens
AGL-15/AGL-20

B158



Aspheric Condenser Lenses
AGL

B159



High Precision Polished Aspheric Lenses
AGL-E/AGL-G

B160



Calcium Fluoride Plano Convex Lens
SLCFU

B162



Sapphire Plano Convex Lens
SLSH

B163




Single Lenses for CO₂ Lasers
Meniscus Lens for CO₂ Laser
SLZS

B164



Silicon Plano Convex Lens
SLSI

B166



Germanium Single Lens
SLGE


B167

Contact sheet for Special Order for Lenses **B168**

Lenses Selection Guide

These Lenses listed here are a single lens polished to a spherical shape different to multi-element lens for cameras or telescopes. The performance is reduced to minimum with a wide range of applications at low cost.

Application	Type of Lens	Features	Relevance information
Focus · Image formation			
Focused laser beam	Plano Convex Lenses Reference B108	Low cost. Small spot size.	High performance product → Achromatic Lenses
Collimated light		Spherical aberration is small.	High performance product → Achromatic Lenses
Illumination	Biconvex Lenses Reference B123 Plano Convex Lenses	Compact. High numerical aperture.	High numerical aperture → Aspheric Lenses
Image formation (Microscope)	Biconvex Lenses, Plano Convex Lenses	Low cost. Observation of a narrow field of view.	High performance product → Achromatic Lenses, Camera Lenses
Beam Shaping Diffusers			
Beam expansion	Plano Convex Lenses + Plano Concave Lenses Reference B118	Low cost. Low magnification.	High performance products → Beam Expanders
Light sheet	Cylindrical Lenses Reference B140	Low cost. Diverging beam uniaxial.	
Irregular beam	Plano Convex Lenses + Cylindrical Lenses	Varying the Beam Diameter and, Aspect ratio, Beam Divergence Aspect ratio.	



Application
Systems

Optics &
Optical
Coatings

Opto-
Mechanics

Bases

Manual
Stages

Actuators &
Adjusters

MotORIZED
Stages

Light Sources &
Laser Safety

Index

Guide

Mirrors

Beamsplitters

Polarizers

Lenses

Multi-Element Optics

Filters

Prisms

Substrates/Windows

Optical Data

Maintenance

Selection Guide

Plano Convex
Lenses
Plano Concave
Lenses

Biconvex Lenses

Biconcave Lenses

Kit

Reasonable Lens

Cylindrical

Others

Plano Convex Lenses | SLB-P/SLSQ-P/SLSQK-P

RoHS

Application Systems

Optics & Optical Coatings

Opto-Mechanics

Bases

Manual Stages

Actuators & Adjusters

Motorized Stages

Light Sources & Laser Safety

Index

Guide

Mirrors

Beamsplitters

Polarizers

Lenses

Multi-Element Optics

Filters

Prisms

Substrates/Windows

Optical Data

Maintenance

Selection Guide

Plano Convex Lenses

Plano Concave Lenses

Biconvex Lenses

Biconcave Lenses

Kit

Reasonable Lens

Cylindrical

Others


These are simple lenses having a flat surface on one side and a spherical surface on the other. They are also very close to the form which minimizes spherical aberration for infinite conjugate applications.

Our glass lenses are made from the highest grade of optical glass. We have a vast range of different diameters and focal lengths. The lenses listed here are standards. Please call if you do not see the lens you need. We have both larger and smaller lenses and many other diameters to choose from. However, we do try to keep these standards available for quick delivery.

- There are three types of plano convex lenses available; BK7 for use in visible range to infrared wavelength range, synthetic fused silica for wavelengths less than 350nm ultraviolet light, and synthetic fused silica lens for excimer laser wavelengths such as KrF (248nm) and ArF (193nm).
- BK7 lenses are also available with three types of anti-reflection coatings, visible wavelength range, in the near-infrared range and in the infrared range.
- Our lenses are listed by outside diameter and focal length to assist your selection according to required specifications.




Schematic



Outline Drawing

(in mm)



How to specify the anti-reflection coating

In case of specifying a anti-reflection coating 633nm – 1064nm to near infrared lens of SLB-100-500P.
 ⇒ SLB-100-500PIR1

Type of AR Coat	Part Number	Wavelength Range [nm]	Transmittance [%]
Visible range	SLB-100-500PM	400 – 700	> Average 99
Near-infrared	SLB-100-500PIR1	633 – 1064	> Average 98.5
Infrared	SLB-100-500PIR2	750 – 1550	> Average 98.5

⚠ Part of the above is an example of if you want to coat anti-reflective coating on the lens of the SLB-100-500P.

⚠ Anti-reflection coating can be available to the lens of all of SLB.

Specifications

Material	SLB: BK7 SLSQ: Synthetic fused silica SLSQK: Synthetic fused silica for Excimer Laser
Design wavelength	546.1nm
Refractive index	BK7: $n_d=1.519$ Synthetic fused silica: $n_d=1.460$
Coating	Uncoated: the end of the part number 'P' Anti-reflection coating: the end of the part number 'PM', 'PIR1', 'PIR2'
Laser Damage Threshold	Anti-reflection coating: $4\text{J}/\text{cm}^2$ Laser pulse with 10ns, repetition frequency 20Hz
Clear aperture	90% of actual aperture: Uncoated 85% of actual aperture: with coating, $\phi 10 \leq D$ 83% of actual aperture: with coating, $D < \phi 10$
Surface Quality (Scratch-Dig)	20-10 $\phi 10 \leq D$ 40-20 $D < \phi 10$


Guide

- ▶ Lenses are available in a large selection and in custom sizes and focal lengths.
- ▶ In addition to our standard coating we offer custom anti-reflective coating at specific wavelengths.
- ▶ Achromatic lenses (DLB) which are chromatic aberration correction are also available. [Reference](#) B172

Attention

- ▶ Plano convex lenses have a positive focal length and can be used in focusing and collimating applications.
- ▶ The plano convex lens has chromatic aberration, and the focal length will vary depending on the wavelength. Please check the "wavelength characteristic of the focal length data" on the Web.
- ▶ [WEB Reference](#) [Catalog Code](#) W3041
- ▶ Transmissions losses due to reflection off the front and rear surfaces of the lens can be minimized by coating the surfaces. Consult our Sales Division for anti-reflection coatings suitable for your application.

Typical Transmittance Data T: Transmission



BK7 $\phi 5 - \phi 12.7$

Uncoated	How to specify the anti-reflection coating			Diameter ϕD [mm]	Focal length f [mm]	Edge thickness t_e [mm]	Center thickness t_c [mm]	Back focal length f_b [mm]	Radius of curvature r [mm]	Centration [']
Part Number	Visibe 400 - 700nm	Near-infrared 633 - 1064nm	Infrared 750 - 1550nm							
SLB-05-08P	M	IR1	IR2	$\phi 5$	8	1.4	2.3	6.5	4.15	<3
SLB-05-10P	M	IR1	IR2	$\phi 5$	10	1.3	2.0	8.7	5.19	<3
SLB-05-12P	M	IR1	IR2	$\phi 5$	12	1.2	1.8	10.8	6.23	<3
SLB-05-15P	M	IR1	IR2	$\phi 5$	15	1.2	1.6	13.9	7.79	<3
SLB-05-20P	M	IR1	IR2	$\phi 5$	20	1.1	1.4	19.1	10.38	<3
SLB-05-25P	M	IR1	IR2	$\phi 5$	25	1.1	1.4	24.1	12.98	<3
SLB-05-30P	M	IR1	IR2	$\phi 5$	30	1.1	1.3	29.1	15.57	<3
SLB-06-08P	M	IR1	IR2	$\phi 6$	8	1.0	2.3	6.5	4.15	<3
SLB-06-09P	M	IR1	IR2	$\phi 6$	9	1.0	2.1	7.6	4.67	<3
SLB-06-10P	M	IR1	IR2	$\phi 6$	10	1.0	2.0	8.7	5.19	<3
SLB-06-12P	M	IR1	IR2	$\phi 6$	12	1.0	1.8	10.8	6.23	<3
SLB-06-15P	M	IR1	IR2	$\phi 6$	15	1.0	1.6	13.9	7.79	<3
SLB-06-20P	M	IR1	IR2	$\phi 6$	20	1.0	1.4	19.1	10.38	<3
SLB-06-25P	M	IR1	IR2	$\phi 6$	25	1.0	1.4	24.1	12.98	<3
SLB-06-30P	M	IR1	IR2	$\phi 6$	30	1.0	1.3	29.1	15.57	<3
SLB-07-10P	M	IR1	IR2	$\phi 7$	10	2.0	3.4	7.8	5.19	<3
SLB-07-12P	M	IR1	IR2	$\phi 7$	12	1.9	3.0	10.1	6.23	<3
SLB-07-15P	M	IR1	IR2	$\phi 7$	15	1.8	2.6	13.3	7.79	<3
SLB-07-20P	M	IR1	IR2	$\phi 7$	20	1.7	2.3	18.5	10.38	<3
SLB-07-25P	M	IR1	IR2	$\phi 7$	25	1.7	2.1	23.6	12.98	<3
SLB-07-30P	M	IR1	IR2	$\phi 7$	30	1.6	2.0	28.7	15.57	<3
SLB-07-40P	M	IR1	IR2	$\phi 7$	40	1.6	1.9	38.8	20.76	<3
SLB-07-50P	M	IR1	IR2	$\phi 7$	50	1.6	1.8	48.8	25.95	<3
SLB-08-10P	M	IR1	IR2	$\phi 8$	10	1.5	3.4	7.8	5.19	<3
SLB-08-12P	M	IR1	IR2	$\phi 8$	12	1.5	3.0	10.1	6.23	<3
SLB-08-15P	M	IR1	IR2	$\phi 8$	15	1.5	2.6	13.3	7.79	<3
SLB-08-20P	M	IR1	IR2	$\phi 8$	20	1.5	2.3	18.5	10.38	<3
SLB-08-25P	M	IR1	IR2	$\phi 8$	25	1.5	2.1	23.6	12.98	<3
SLB-08-30P	M	IR1	IR2	$\phi 8$	30	1.5	2.0	28.7	15.57	<3
SLB-08-40P	M	IR1	IR2	$\phi 8$	40	1.5	1.9	38.8	20.76	<3
SLB-08-50P	M	IR1	IR2	$\phi 8$	50	1.5	1.8	48.8	25.95	<3
SLB-10-15P	M	IR1	IR2	$\phi 10$	15	2.0	3.8	12.5	7.79	<1
SLB-10-20P	M	IR1	IR2	$\phi 10$	20	2.0	3.3	17.8	10.38	<1
SLB-10-25P	M	IR1	IR2	$\phi 10$	25	2.0	3.0	23.0	12.98	<1
SLB-10-30P	M	IR1	IR2	$\phi 10$	30	2.0	2.8	28.1	15.57	<1
SLB-10-40P	M	IR1	IR2	$\phi 10$	40	2.0	2.6	38.3	20.76	<1
SLB-10-50P	M	IR1	IR2	$\phi 10$	50	2.0	2.5	48.4	25.95	<1
SLB-10-60P	M	IR1	IR2	$\phi 10$	60	2.0	2.4	58.4	31.14	<1
SLB-10-70P	M	IR1	IR2	$\phi 10$	70	2.0	2.3	68.5	36.33	<1
SLB-10-80P	M	IR1	IR2	$\phi 10$	80	2.0	2.3	78.5	41.52	<1
SLB-10-100P	M	IR1	IR2	$\phi 10$	100	2.0	2.2	98.5	51.90	<1
SLB-12.7-20P	M	IR1	IR2	$\phi 12.7$	20	2.0	4.2	17.2	10.38	<1
SLB-12.7-25P	M	IR1	IR2	$\phi 12.7$	25	2.0	3.7	22.6	12.98	<1
SLB-12.7-30P	M	IR1	IR2	$\phi 12.7$	30	2.0	3.4	27.8	15.57	<1
SLB-12.7-40P	M	IR1	IR2	$\phi 12.7$	40	2.0	3.0	38.0	20.76	<1
SLB-12.7-50P	M	IR1	IR2	$\phi 12.7$	50	2.0	2.8	48.2	25.95	<1
SLB-12.7-60P	M	IR1	IR2	$\phi 12.7$	60	2.0	2.7	58.3	31.14	<1
SLB-12.7-70P	M	IR1	IR2	$\phi 12.7$	70	2.0	2.6	68.3	36.33	<1
SLB-12.7-80P	M	IR1	IR2	$\phi 12.7$	80	2.0	2.5	78.4	41.52	<1
SLB-12.7-100P	M	IR1	IR2	$\phi 12.7$	100	2.0	2.4	98.5	51.90	<1

Compatible Optic Mounts

LHF-10S / MLH-10, -15

Application
SystemsOptics &
Optical
CoatingsOpto-
Mechanics

Bases

Manual
StagesActuators &
AdjustersMotorized
StagesLight Sources &
Laser Safety

Index

Guide

Mirrors

Beamsplitters

Polarizers

Lenses

Multi-Element Optics

Filters

Prisms

Substrates/Windows

Optical Data

Maintenance

Selection Guide

Plano Convex
LensesPlano Concave
Lenses

Biconvex Lenses

Biconcave Lenses

Kit

Reasonable Lens

Cylindrical

Others

Plano Convex Lenses | SLB-P/SLSQ-P/SLSQK-P

Catalog Code W3042

BK7 φ15 – φ25.4										
Uncoated	How to specify the anti-reflection coating			Diameter φD [mm]	Focal length f [mm]	Edge thickness te [mm]	Center thickness tc [mm]	Back focal length fb [mm]	Radius of curvature r [mm]	Centration [']
Part Number	Visibe 400 – 700nm	Near-infrared 633 – 1064nm	Infrared 750 – 1550nm							
SLB-15-20P	M	IR1	IR2	φ15	20	2.0	5.2	16.6	10.38	<1
SLB-15-25P	M	IR1	IR2	φ15	25	2.0	4.4	22.1	12.98	<1
SLB-15-30P	M	IR1	IR2	φ15	30	2.0	3.9	27.4	15.57	<1
SLB-15-40P	M	IR1	IR2	φ15	40	2.0	3.4	37.8	20.76	<1
SLB-15-50P	M	IR1	IR2	φ15	50	2.0	3.1	48.0	25.95	<1
SLB-15-60P	M	IR1	IR2	φ15	60	2.0	2.9	58.1	31.14	<1
SLB-15-70P	M	IR1	IR2	φ15	70	2.0	2.8	68.2	36.33	<1
SLB-15-80P	M	IR1	IR2	φ15	80	2.0	2.7	78.2	41.52	<1
SLB-15-90P	M	IR1	IR2	φ15	90	2.0	2.6	88.3	46.71	<1
SLB-15-100P	M	IR1	IR2	φ15	100	2.0	2.5	98.3	51.90	<1
SLB-15-120P	M	IR1	IR2	φ15	120	2.0	2.5	118.4	62.28	<1
SLB-15-150P	M	IR1	IR2	φ15	150	2.0	2.4	148.4	77.85	<1
SLB-20-25P	M	IR1	IR2	φ20	25	2.0	6.7	20.6	12.98	<1
SLB-20-30P	M	IR1	IR2	φ20	30	2.0	5.6	26.3	15.57	<1
SLB-20-40P	M	IR1	IR2	φ20	40	2.0	4.6	37.0	20.76	<1
SLB-20-50P	M	IR1	IR2	φ20	50	2.0	4.0	47.4	25.95	<1
SLB-20-60P	M	IR1	IR2	φ20	60	2.0	3.6	57.6	31.14	<1
SLB-20-70P	M	IR1	IR2	φ20	70	2.0	3.4	67.8	36.33	<1
SLB-20-80P	M	IR1	IR2	φ20	80	2.0	3.2	77.9	41.52	<1
SLB-20-90P	M	IR1	IR2	φ20	90	2.0	3.1	88.0	46.71	<1
SLB-20-100P	M	IR1	IR2	φ20	100	2.0	3.0	98.0	51.90	<1
SLB-20-120P	M	IR1	IR2	φ20	120	2.0	2.8	118.2	62.28	<1
SLB-20-150P	M	IR1	IR2	φ20	150	2.0	2.6	148.3	77.85	<1
SLB-20-170P	M	IR1	IR2	φ20	170	2.0	2.6	168.2	88.23	<1
SLB-20-200P	M	IR1	IR2	φ20	200	2.0	2.5	198.4	103.8	<1
SLB-25-30P	M	IR1	IR2	φ25	30	2.0	8.3	24.5	15.57	<1
SLB-25-35P	M	IR1	IR2	φ25	35	2.0	7.0	30.4	18.17	<1
SLB-25-40P	M	IR1	IR2	φ25	40	2.0	6.2	36.0	20.76	<1
SLB-25-50P	M	IR1	IR2	φ25	50	2.0	5.2	46.6	25.95	<1
SLB-25-60P	M	IR1	IR2	φ25	60	2.0	4.6	57.0	31.14	<1
SLB-25-70P	M	IR1	IR2	φ25	70	2.0	4.2	67.2	36.33	<1
SLB-25-80P	M	IR1	IR2	φ25	80	2.0	3.9	77.4	41.52	<1
SLB-25-90P	M	IR1	IR2	φ25	90	2.0	3.7	87.6	46.71	<1
SLB-25-100P	M	IR1	IR2	φ25	100	2.0	3.5	97.7	51.9	<1
SLB-25-120P	M	IR1	IR2	φ25	120	2.0	3.3	117.8	62.28	<1
SLB-25-150P	M	IR1	IR2	φ25	150	2.0	3.0	148.0	77.85	<1
SLB-25-170P	M	IR1	IR2	φ25	170	2.0	2.9	168.1	88.23	<1
SLB-25-200P	M	IR1	IR2	φ25	200	2.0	2.8	198.2	103.8	<1
SLB-25-220P	M	IR1	IR2	φ25	220	2.0	2.7	218.2	114.18	<1
SLB-25-250P	M	IR1	IR2	φ25	250	2.0	2.6	248.3	129.75	<1
SLB-25.4-30P	M	IR1	IR2	φ25.4	30	1.7	8.3	24.5	15.57	<1
SLB-25.4-35P	M	IR1	IR2	φ25.4	35	1.8	7.0	30.4	18.17	<1
SLB-25.4-40P	M	IR1	IR2	φ25.4	40	1.9	6.2	36.0	20.76	<1
SLB-25.4-50P	M	IR1	IR2	φ25.4	50	1.9	5.2	46.6	25.95	<1
SLB-25.4-60P	M	IR1	IR2	φ25.4	60	1.9	4.6	57.0	31.14	<1
SLB-25.4-70P	M	IR1	IR2	φ25.4	70	1.9	4.2	67.2	36.33	<1
SLB-25.4-80P	M	IR1	IR2	φ25.4	80	1.9	3.9	77.4	41.52	<1
SLB-25.4-90P	M	IR1	IR2	φ25.4	90	1.9	3.7	87.6	46.71	<1
SLB-25.4-100P	M	IR1	IR2	φ25.4	100	1.9	3.5	97.7	51.90	<1
SLB-25.4-120P	M	IR1	IR2	φ25.4	120	2.0	3.3	117.8	62.28	<1
SLB-25.4-150P	M	IR1	IR2	φ25.4	150	2.0	3.0	148.0	77.85	<1
SLB-25.4-170P	M	IR1	IR2	φ25.4	170	2.0	2.9	168.1	88.23	<1
SLB-25.4-200P	M	IR1	IR2	φ25.4	200	2.0	2.8	198.2	103.80	<1
SLB-25.4-250P	M	IR1	IR2	φ25.4	250	2.0	2.6	248.3	129.75	<1
SLB-25.4-300P	M	IR1	IR2	φ25.4	300	2.0	2.5	298.4	155.70	<3
SLB-25.4-500P	M	IR1	IR2	φ25.4	500	2.0	2.3	498.4	259.50	<3
SLB-25.4-700P	M	IR1	IR2	φ25.4	700	2.0	2.2	698.5	363.30	<3
SLB-25.4-1000P	M	IR1	IR2	φ25.4	1000	2.0	2.2	998.5	519.00	<3

Compatible Optic Mounts

LHF-15S, -20S, -25.4S

BK7 $\phi 30 - \phi 40$										
Uncoated	How to specify the anti-reflection coating			Diameter ϕD [mm]	Focal length f [mm]	Edge thickness t_e [mm]	Center thickness t_c [mm]	Back focal length f_b [mm]	Radius of curvature r [mm]	Centration [']
Part Number	Visibe 400 - 700nm	Near-infrared 633 - 1064nm	Infrared 750 - 1550nm							
SLB-30-35P	M	IR1	IR2	$\phi 30$	35	2.0	9.9	28.5	18.17	<1
SLB-30-40P	M	IR1	IR2	$\phi 30$	40	2.0	8.4	34.5	20.76	<1
SLB-30-50P	M	IR1	IR2	$\phi 30$	50	2.0	6.8	45.5	25.95	<1
SLB-30-60P	M	IR1	IR2	$\phi 30$	60	2.0	5.9	56.1	31.14	<1
SLB-30-70P	M	IR1	IR2	$\phi 30$	70	2.0	5.2	66.5	36.33	<1
SLB-30-80P	M	IR1	IR2	$\phi 30$	80	2.0	4.8	76.8	41.52	<1
SLB-30-90P	M	IR1	IR2	$\phi 30$	90	2.0	4.5	87.1	46.71	<1
SLB-30-100P	M	IR1	IR2	$\phi 30$	100	2.0	4.2	97.2	51.90	<1
SLB-30-120P	M	IR1	IR2	$\phi 30$	120	2.0	3.8	117.5	62.28	<1
SLB-30-150P	M	IR1	IR2	$\phi 30$	150	2.0	3.5	147.7	77.85	<1
SLB-30-170P	M	IR1	IR2	$\phi 30$	170	2.0	3.3	167.8	88.23	<1
SLB-30-200P	M	IR1	IR2	$\phi 30$	200	2.0	3.1	198.0	103.80	<1
SLB-30-220P	M	IR1	IR2	$\phi 30$	220	2.0	3.0	218.0	114.18	<1
SLB-30-250P	M	IR1	IR2	$\phi 30$	250	2.0	2.9	248.1	129.75	<1
SLB-30-300P	M	IR1	IR2	$\phi 30$	300	2.0	2.7	298.2	155.70	<1
SLB-30-350P	M	IR1	IR2	$\phi 30$	350	2.0	2.6	348.3	181.65	<3
SLB-30-400P	M	IR1	IR2	$\phi 30$	400	2.0	2.5	398.2	207.60	<3
SLB-30-450P	M	IR1	IR2	$\phi 30$	450	2.0	2.5	448.4	233.55	<3
SLB-30-500P	M	IR1	IR2	$\phi 30$	500	2.0	2.4	498.4	259.50	<3
SLB-30-600P	M	IR1	IR2	$\phi 30$	600	2.0	2.4	598.4	311.40	<3
SLB-30-700P	M	IR1	IR2	$\phi 30$	700	2.0	2.3	698.5	363.30	<3
SLB-30-800P	M	IR1	IR2	$\phi 30$	800	2.0	2.3	798.5	415.20	<3
SLB-30-900P	M	IR1	IR2	$\phi 30$	900	2.0	2.2	898.5	467.10	<3
SLB-30-1000P	M	IR1	IR2	$\phi 30$	1000	2.0	2.2	998.5	519.00	<3
SLB-30-1200P	M	IR1	IR2	$\phi 30$	1200	2.0	2.2	1198.6	622.80	<3
SLB-30-1500P	M	IR1	IR2	$\phi 30$	1500	2.0	2.1	1498.6	778.50	<3
SLB-30-2000P	M	IR1	IR2	$\phi 30$	2000	2.0	2.1	1998.6	1038.00	<3
SLB-30-2500P	M	IR1	IR2	$\phi 30$	2500	2.0	2.1	2498.6	1297.50	<3
SLB-30-3000P	M	IR1	IR2	$\phi 30$	3000	2.0	2.1	2998.6	1557	<3
SLB-30-4000P	M	IR1	IR2	$\phi 30$	4000	2.0	2.1	3998.6	2076	<3
SLB-30-5000P	M	IR1	IR2	$\phi 30$	5000	2.0	2.1	4998.6	2595	<3
SLB-40-50P	M	IR1	IR2	$\phi 40$	50	2.0	11.4	42.5	25.95	<1
SLB-40-60P	M	IR1	IR2	$\phi 40$	60	2.0	9.3	53.9	31.14	<1
SLB-40-70P	M	IR1	IR2	$\phi 40$	70	2.0	8.0	64.7	36.33	<1
SLB-40-80P	M	IR1	IR2	$\phi 40$	80	2.0	7.1	75.3	41.52	<1
SLB-40-90P	M	IR1	IR2	$\phi 40$	90	2.0	6.5	85.7	46.71	<1
SLB-40-100P	M	IR1	IR2	$\phi 40$	100	2.0	6.0	96.0	51.90	<1
SLB-40-120P	M	IR1	IR2	$\phi 40$	120	2.0	5.3	116.5	62.28	<1
SLB-40-150P	M	IR1	IR2	$\phi 40$	150	2.0	4.6	147.0	77.85	<1
SLB-40-170P	M	IR1	IR2	$\phi 40$	170	2.0	4.3	167.2	88.23	<1
SLB-40-200P	M	IR1	IR2	$\phi 40$	200	2.0	3.9	197.4	103.80	<1
SLB-40-250P	M	IR1	IR2	$\phi 40$	250	2.0	3.6	247.7	129.75	<1
SLB-40-300P	M	IR1	IR2	$\phi 40$	300	2.0	3.3	297.7	155.70	<1
SLB-40-350P	M	IR1	IR2	$\phi 40$	350	2.0	3.1	348.0	181.65	<1
SLB-40-400P	M	IR1	IR2	$\phi 40$	400	2.0	3.0	398.0	207.60	<1
SLB-40-450P	M	IR1	IR2	$\phi 40$	450	2.0	2.9	448.1	233.55	<3
SLB-40-500P	M	IR1	IR2	$\phi 40$	500	2.0	2.8	498.2	259.50	<3
SLB-40-1000P	M	IR1	IR2	$\phi 40$	1000	2.0	2.4	998.4	519.00	<3

Compatible Optic Mounts

LHF-30S, -40S

Application
SystemsOptics &
Optical
CoatingsOpto-
Mechanics

Bases

Manual
StagesActuators &
AdjustersMotorized
StagesLight Sources &
Laser Safety

Index

Guide

Mirrors

Beamsplitters

Polarizers

Lenses

Multi-Element Optics

Filters

Prisms

Substrates/Windows

Optical Data

Maintenance

Selection Guide

Plano Convex
LensesPlano Concave
Lenses

Biconvex Lenses

Biconcave Lenses

Kit

Reasonable Lens

Cylindrical

Others

Plano Convex Lenses | SLB-P/SLSQ-P/SLSQK-P

Catalog Code W3044

Application Systems	BK7 $\phi 50 - \phi 60$										
	Uncoated	How to specify the anti-reflection coating			Diameter ϕD [mm]	Focal length f [mm]	Edge thickness t_e [mm]	Center thickness t_c [mm]	Back focal length f_b [mm]	Radius of curvature r [mm]	Centration [']
	Part Number	Visible 400 – 700nm	Near-infrared 633 – 1064nm	Infrared 750 – 1550nm							
Optics & Optical Coatings	SLB-50-70P	M	IR1	IR2	$\phi 50$	70	3.0	13.0	61.5	36.33	<1
	SLB-50-80P	M	IR1	IR2	$\phi 50$	80	3.0	11.4	72.5	41.52	<1
	SLB-50-90P	M	IR1	IR2	$\phi 50$	90	3.0	10.3	83.2	46.71	<1
Opto-Mechanics	SLB-50-100P	M	IR1	IR2	$\phi 50$	100	3.0	9.4	93.8	51.90	<1
	SLB-50-120P	M	IR1	IR2	$\phi 50$	120	3.0	8.2	114.6	62.28	<1
	SLB-50-150P	M	IR1	IR2	$\phi 50$	150	3.0	7.1	145.3	77.85	<1
Bases	SLB-50-170P	M	IR1	IR2	$\phi 50$	170	3.0	6.6	165.6	88.23	<1
	SLB-50-200P	M	IR1	IR2	$\phi 50$	200	3.0	6.1	196.0	103.80	<1
	SLB-50-220P	M	IR1	IR2	$\phi 50$	220	3.0	5.8	216.2	114.18	<1
Manual Stages	SLB-50-250P	M	IR1	IR2	$\phi 50$	250	3.0	5.4	246.4	129.75	<1
	SLB-50-300P	M	IR1	IR2	$\phi 50$	300	3.0	5.0	296.7	155.70	<1
	SLB-50-350P	M	IR1	IR2	$\phi 50$	350	3.0	4.7	346.9	181.65	<1
Actuators & Adjusters	SLB-50-400P	M	IR1	IR2	$\phi 50$	400	3.0	4.5	397.0	207.60	<1
	SLB-50-450P	M	IR1	IR2	$\phi 50$	450	3.0	4.3	447.1	233.55	<1
	SLB-50-500P	M	IR1	IR2	$\phi 50$	500	3.0	4.2	497.2	259.50	<1
Motorized Stages	SLB-50-600P	M	IR1	IR2	$\phi 50$	600	3.0	4.0	597.4	311.40	<3
	SLB-50-700P	M	IR1	IR2	$\phi 50$	700	3.0	3.9	697.5	363.30	<3
	SLB-50-800P	M	IR1	IR2	$\phi 50$	800	3.0	3.8	797.4	415.20	<3
Light Sources & Laser Safety	SLB-50-900P	M	IR1	IR2	$\phi 50$	900	3.0	3.7	897.6	467.10	<3
	SLB-50-1000P	M	IR1	IR2	$\phi 50$	1000	3.0	3.6	997.6	519.00	<3
	SLB-50-1200P	M	IR1	IR2	$\phi 50$	1200	3.0	3.5	1197.7	622.80	<3
Index	SLB-50-1500P	M	IR1	IR2	$\phi 50$	1500	3.0	3.4	1497.8	778.50	<3
	SLB-50-2000P	M	IR1	IR2	$\phi 50$	2000	3.0	3.3	1997.8	1038.00	<3
	SLB-50-2500P	M	IR1	IR2	$\phi 50$	2500	3.0	3.2	2497.9	1297.5	<3
Guide	SLB-50-3000P	M	IR1	IR2	$\phi 50$	3000	3.0	3.2	2997.9	1557.00	<3
	SLB-50-4000P	M	IR1	IR2	$\phi 50$	4000	3.0	3.2	3997.9	2076.00	<3
	SLB-50-5000P	M	IR1	IR2	$\phi 50$	5000	3.0	3.1	4997.9	2595.00	<3
Mirrors	SLB-50.8-70P	M	IR1	IR2	$\phi 50.8$	70	3.0	13.4	61.2	36.33	<1
	SLB-50.8-80P	M	IR1	IR2	$\phi 50.8$	80	3.0	11.7	72.3	41.52	<1
	SLB-50.8-90P	M	IR1	IR2	$\phi 50.8$	90	3.0	10.3	83.2	46.71	<1
Beamsplitters	SLB-50.8-100P	M	IR1	IR2	$\phi 50.8$	100	3.0	9.6	93.7	51.90	<1
	SLB-50.8-120P	M	IR1	IR2	$\phi 50.8$	120	2.8	8.2	114.6	62.28	<1
	SLB-50.8-150P	M	IR1	IR2	$\phi 50.8$	150	2.8	7.1	145.3	77.85	<1
Polarizers	SLB-50.8-170P	M	IR1	IR2	$\phi 50.8$	170	3.0	6.6	165.7	88.23	<1
	SLB-50.8-200P	M	IR1	IR2	$\phi 50.8$	200	2.9	6.1	196.0	103.8	<1
	SLB-50.8-250P	M	IR1	IR2	$\phi 50.8$	250	2.9	5.4	246.4	129.75	<1
Filters	SLB-50.8-300P	M	IR1	IR2	$\phi 50.8$	300	2.9	5.0	296.7	155.70	<1
	SLB-50.8-400P	M	IR1	IR2	$\phi 50.8$	400	3.0	4.5	397.0	207.60	<1
	SLB-50.8-500P	M	IR1	IR2	$\phi 50.8$	500	3.0	4.2	497.2	259.50	<1
Prisms	SLB-50.8-700P	M	IR1	IR2	$\phi 50.8$	700	3.0	3.9	697.4	363.30	<3
	SLB-50.8-1000P	M	IR1	IR2	$\phi 50.8$	1000	3.0	3.6	997.6	519.00	<3
	SLB-60-70P	M	IR1	IR2	$\phi 60$	70	3.0	18.8	57.6	36.33	<1
Substrates/Windows	SLB-60-80P	M	IR1	IR2	$\phi 60$	80	3.0	15.8	69.6	41.52	<1
	SLB-60-90P	M	IR1	IR2	$\phi 60$	90	3.0	13.9	80.8	46.71	<1
	SLB-60-100P	M	IR1	IR2	$\phi 60$	100	3.0	12.5	91.7	51.90	<1
Optical Data	SLB-60-120P	M	IR1	IR2	$\phi 60$	120	3.0	10.7	113.0	62.28	<1
	SLB-60-150P	M	IR1	IR2	$\phi 60$	150	3.0	9.0	144.1	77.85	<1
	SLB-60-170P	M	IR1	IR2	$\phi 60$	170	3.0	8.3	164.6	88.23	<1
Maintenance	SLB-60-200P	M	IR1	IR2	$\phi 60$	200	3.0	7.4	195.1	103.80	<1
	SLB-60-250P	M	IR1	IR2	$\phi 60$	250	3	6.5	245.7	129.75	<1
	SLB-60-300P	M	IR1	IR2	$\phi 60$	300	3.0	5.9	296.1	155.70	<1
Selection Guide	SLB-60-400P	M	IR1	IR2	$\phi 60$	400	3.0	5.2	396.6	207.60	<1
	SLB-60-500P	M	IR1	IR2	$\phi 60$	500	3.0	4.7	496.9	259.50	<1
	SLB-60-1000P	M	IR1	IR2	$\phi 60$	1000	3.0	3.9	997.5	519.00	<3

Compatible Optic Mounts

LHF-50S, -50.8S, -60AS

BK7 $\phi 80 - \phi 100$										
Uncoated	How to specify the anti-reflection coating			Diameter ϕD [mm]	Focal length f [mm]	Edge thickness t_e [mm]	Center thickness t_c [mm]	Back focal length f_b [mm]	Radius of curvature r [mm]	Centration [']
Part Number	Visibe 400 - 700nm	Near-infrared 633 - 1064nm	Infrared 750 - 1550nm							
SLB-80-100P	M	IR1	IR2	$\phi 80$	100	3.0	21.8	85.6	51.90	<1
SLB-80-150P	M	IR1	IR2	$\phi 80$	150	3.0	14.1	140.8	77.85	<1
SLB-80-200P	M	IR1	IR2	$\phi 80$	200	3.0	11.0	192.7	103.80	<1
SLB-80-250P	M	IR1	IR2	$\phi 80$	250	3.0	9.3	243.9	129.75	<1
SLB-80-300P	M	IR1	IR2	$\phi 80$	300	3.0	8.2	294.6	155.70	<1
SLB-80-350P	M	IR1	IR2	$\phi 80$	350	3.0	7.5	345.1	181.65	<1
SLB-80-400P	M	IR1	IR2	$\phi 80$	400	3.0	6.9	395.5	207.60	<1
SLB-80-500P	M	IR1	IR2	$\phi 80$	500	3.0	6.1	496.0	259.50	<1
SLB-80-700P	M	IR1	IR2	$\phi 80$	700	3.0	5.2	696.6	363.30	<1
SLB-80-800P	M	IR1	IR2	$\phi 80$	800	3.0	4.9	796.8	415.20	<1
SLB-80-1000P	M	IR1	IR2	$\phi 80$	1000	3.0	4.5	997.0	519.00	<3
SLB-100-150P	M	IR1	IR2	$\phi 100$	150	3.0	21.2	136.1	77.85	<1
SLB-100-200P	M	IR1	IR2	$\phi 100$	200	3.0	15.8	189.6	103.80	<1
SLB-100-250P	M	IR1	IR2	$\phi 100$	250	3.0	13.0	241.4	129.75	<1
SLB-100-300P	M	IR1	IR2	$\phi 100$	300	3.0	11.2	292.6	155.70	<1
SLB-100-350P	M	IR1	IR2	$\phi 100$	350	3.0	10.0	343.4	181.65	<1
SLB-100-400P	M	IR1	IR2	$\phi 100$	400	3.0	9.1	394.4	207.60	<1
SLB-100-500P	M	IR1	IR2	$\phi 100$	500	3.0	7.9	494.8	259.50	<1
SLB-100-600P	M	IR1	IR2	$\phi 100$	600	3.0	7.0	595.4	311.40	<1
SLB-100-700P	M	IR1	IR2	$\phi 100$	700	3.0	6.5	695.7	363.30	<1
SLB-100-800P	M	IR1	IR2	$\phi 100$	800	3.0	6.0	796.0	415.20	<1
SLB-100-1000P	M	IR1	IR2	$\phi 100$	1000	3.0	5.4	996.4	519.00	<1

Compatible Optic Mounts

LHF-80, -100

Application
SystemsOptics &
Optical
CoatingsOpto-
Mechanics

Bases

Manual
StagesActuators &
AdjustersMotorized
StagesLight Sources &
Laser Safety

Index

Guide

Mirrors

Beamsplitters

Polarizers

Lenses

Multi-Element Optics

Filters

Prisms

Substrates/Windows

Optical Data

Maintenance

Selection Guide

Plano Convex
LensesPlano Concave
Lenses

Biconvex Lenses

Biconcave Lenses

Kit

Reasonable Lens

Cylindrical

Others

Plano Convex Lenses | SLB-P/SLSQ-P/SLSQK-P

Catalog Code W3045

Synthetic fused silica $\phi 5 - \phi 20$							
Part Number	Diameter ϕD [mm]	Focal length f [mm]	Edge thickness t_e [mm]	Center thickness t_c [mm]	Back focal length f_b [mm]	Radius of curvature r [mm]	Centration [']
SLSQ-05-08P	$\phi 5$	8	1.6	2.5	6.3	3.68	<3
SLSQ-05-09P	$\phi 5$	9	1.4	2.3	7.6	4.14	<3
SLSQ-05-10P	$\phi 5$	10	1.4	2.1	8.6	4.60	<3
SLSQ-05-12P	$\phi 5$	12	1.3	1.9	10.7	5.52	<3
SLSQ-05-15P	$\phi 5$	15	1.2	1.7	13.8	6.90	<3
SLSQ-05-20P	$\phi 5$	20	1.2	1.5	19.0	9.20	<3
SLSQ-05-30P	$\phi 5$	30	1.1	1.3	29.1	13.80	<3
SLSQ-06-08P	$\phi 6$	8	1.0	2.5	6.3	3.68	<3
SLSQ-06-10P	$\phi 6$	10	1.0	2.1	8.6	4.60	<3
SLSQ-06-12P	$\phi 6$	12	1.0	1.9	10.7	5.52	<3
SLSQ-06-15P	$\phi 6$	15	1.0	1.7	13.8	6.90	<3
SLSQ-06-20P	$\phi 6$	20	1.0	1.5	19.0	9.20	<3
SLSQ-06-25P	$\phi 6$	25	1.0	1.4	24.0	11.50	<3
SLSQ-06-30P	$\phi 6$	30	1.0	1.3	29.1	13.80	<3
SLSQ-07-10P	$\phi 7$	10	2.2	3.8	7.4	4.60	<3
SLSQ-07-12P	$\phi 7$	12	2.0	3.2	9.8	5.52	<3
SLSQ-07-15P	$\phi 7$	15	1.8	2.8	13.1	6.90	<3
SLSQ-07-20P	$\phi 7$	20	1.7	2.4	18.3	9.20	<3
SLSQ-07-30P	$\phi 7$	30	1.6	2.1	28.6	13.80	<3
SLSQ-07-40P	$\phi 7$	40	1.6	1.9	38.7	18.40	<3
SLSQ-07-50P	$\phi 7$	50	1.6	1.9	48.7	23.00	<3
SLSQ-08-10P	$\phi 8$	10	1.5	3.8	7.4	4.60	<3
SLSQ-08-12P	$\phi 8$	12	1.5	3.2	9.8	5.52	<3
SLSQ-08-15P	$\phi 8$	15	1.5	2.8	13.1	6.90	<3
SLSQ-08-20P	$\phi 8$	20	1.5	2.4	18.3	9.20	<3
SLSQ-08-25P	$\phi 8$	25	1.5	2.2	23.5	11.50	<3
SLSQ-08-30P	$\phi 8$	30	1.5	2.1	28.6	13.80	<3
SLSQ-10-15P	$\phi 10$	15	2.0	4.1	12.2	6.90	<1
SLSQ-10-20P	$\phi 10$	20	2.0	3.5	17.6	9.20	<1
SLSQ-10-25P	$\phi 10$	25	2.0	3.1	22.8	11.50	<1
SLSQ-10-30P	$\phi 10$	30	2.0	2.9	28.0	13.80	<1
SLSQ-10-40P	$\phi 10$	40	2.0	2.7	38.2	18.40	<1
SLSQ-10-50P	$\phi 10$	50	2.0	2.6	48.3	23.00	<1
SLSQ-10-60P	$\phi 10$	60	2.0	2.5	58.3	27.60	<1
SLSQ-10-70P	$\phi 10$	70	2.0	2.4	68.4	32.20	<1
SLSQ-10-80P	$\phi 10$	80	2.0	2.3	78.4	36.80	<1
SLSQ-10-100P	$\phi 10$	100	2.0	2.3	98.4	46.00	<1
SLSQ-12.7-15P	$\phi 12.7$	15	2.0	6.2	10.8	6.90	<1
SLSQ-12.7-20P	$\phi 12.7$	20	2.0	4.5	16.9	9.20	<1
SLSQ-12.7-25P	$\phi 12.7$	25	2.0	3.9	22.3	11.50	<1
SLSQ-12.7-40P	$\phi 12.7$	40	2.0	3.1	37.9	18.40	<1
SLSQ-12.7-50P	$\phi 12.7$	50	2.0	2.9	48.0	23.00	<1
SLSQ-15-20P	$\phi 15$	20	2.0	5.9	16.0	9.20	<1
SLSQ-15-25P	$\phi 15$	25	2.0	4.8	21.7	11.50	<1
SLSQ-15-30P	$\phi 15$	30	2.0	4.2	27.1	13.80	<1
SLSQ-15-40P	$\phi 15$	40	2.0	3.6	37.5	18.40	<1
SLSQ-15-50P	$\phi 15$	50	2.0	3.3	47.8	23.00	<1
SLSQ-15-60P	$\phi 15$	60	2.0	3.0	57.9	27.60	<1
SLSQ-15-70P	$\phi 15$	70	2.0	2.9	68.0	32.20	<1
SLSQ-15-80P	$\phi 15$	80	2.0	2.8	78.1	36.80	<1
SLSQ-15-90P	$\phi 15$	90	2.0	2.7	88.2	41.40	<1
SLSQ-15-100P	$\phi 15$	100	2.0	2.6	98.3	46.00	<1
SLSQ-20-25P	$\phi 20$	25	2.0	7.8	19.6	11.50	<1
SLSQ-20-30P	$\phi 20$	30	2.0	6.3	25.7	13.80	<1
SLSQ-20-40P	$\phi 20$	40	2.0	5.0	36.6	18.40	<1
SLSQ-20-50P	$\phi 20$	50	2.0	4.3	47.1	23.00	<1
SLSQ-20-60P	$\phi 20$	60	2.0	3.9	57.3	27.60	<1
SLSQ-20-70P	$\phi 20$	70	2.0	3.6	67.5	32.20	<1
SLSQ-20-80P	$\phi 20$	80	2.0	3.4	77.7	36.80	<1
SLSQ-20-90P	$\phi 20$	90	2.0	3.2	87.8	41.40	<1
SLSQ-20-100P	$\phi 20$	100	2.0	3.1	97.9	46.00	<1
SLSQ-20-120P	$\phi 20$	120	2.0	2.9	118.0	55.20	<1
SLSQ-20-150P	$\phi 20$	150	2.0	2.7	148.1	69.00	<1
SLSQ-20-170P	$\phi 20$	170	2.0	2.6	168.2	78.20	<1
SLSQ-20-200P	$\phi 20$	200	2.0	2.5	198.3	92.00	<1

Compatible Optic Mounts

LHF-10S, -15S, -20S / MLH-10, -15 / LHF-12.7

Synthetic fused silica $\phi 25 - \phi 30$

Part Number	Diameter ϕD [mm]	Focal length f [mm]	Edge thickness t_e [mm]	Center thickness t_c [mm]	Back focal length f_b [mm]	Radius of curvature r [mm]	Centration [']
SLSQ-25-30P	$\phi 25$	30	2.0	10.0	23.2	13.80	<1
SLSQ-25-35P	$\phi 25$	35	2.0	8.0	29.6	16.10	<1
SLSQ-25-40P	$\phi 25$	40	2.0	6.9	35.3	18.40	<1
SLSQ-25-50P	$\phi 25$	50	2.0	5.7	46.1	23.00	<1
SLSQ-25-60P	$\phi 25$	60	2.0	5.0	56.6	27.60	<1
SLSQ-25-70P	$\phi 25$	70	2.0	4.5	66.9	32.20	<1
SLSQ-25-80P	$\phi 25$	80	2.0	4.2	77.1	36.80	<1
SLSQ-25-90P	$\phi 25$	90	2.0	3.9	87.3	41.40	<1
SLSQ-25-100P	$\phi 25$	100	2.0	3.7	97.4	46.00	<1
SLSQ-25-120P	$\phi 25$	120	2.0	3.4	117.6	55.20	<1
SLSQ-25-150P	$\phi 25$	150	2.0	3.1	147.8	69.00	<1
SLSQ-25-170P	$\phi 25$	170	2.0	3.0	167.9	78.20	<1
SLSQ-25-200P	$\phi 25$	200	2.0	2.9	198.0	92.00	<1
SLSQ-25-220P	$\phi 25$	220	2.0	2.8	218.1	101.20	<1
SLSQ-25-250P	$\phi 25$	250	2.0	2.7	248.2	115.00	<1
SLSQ-25.4-30P	$\phi 25.4$	30	1.6	10.0	23.2	13.80	<1
SLSQ-25.4-35P	$\phi 25.4$	35	1.8	8.0	29.5	16.10	<1
SLSQ-25.4-40P	$\phi 25.4$	40	1.8	6.9	35.3	18.40	<1
SLSQ-25.4-50P	$\phi 25.4$	50	1.9	5.7	46.1	23.00	<1
SLSQ-25.4-60P	$\phi 25.4$	60	1.9	5.0	56.6	27.60	<1
SLSQ-25.4-70P	$\phi 25.4$	70	1.9	4.5	66.9	32.20	<1
SLSQ-25.4-80P	$\phi 25.4$	80	1.9	4.2	77.1	36.80	<1
SLSQ-25.4-90P	$\phi 25.4$	90	1.9	3.9	87.3	41.40	<1
SLSQ-25.4-100P	$\phi 25.4$	100	1.9	3.7	97.5	46.00	<1
SLSQ-25.4-150P	$\phi 25.4$	150	1.9	3.1	147.9	69.00	<1
SLSQ-25.4-200P	$\phi 25.4$	200	1.9	2.9	198.0	92.00	<1
SLSQ-25.4-250P	$\phi 25.4$	250	1.9	2.7	248.2	115.00	<1
SLSQ-25.4-300P	$\phi 25.4$	300	1.9	2.5	298.3	138.00	<3
SLSQ-25.4-400P	$\phi 25.4$	400	1.9	2.3	398.4	184.00	<3
SLSQ-25.4-500P	$\phi 25.4$	500	1.9	2.3	498.0	230.00	<3
SLSQ-25.4-1000P	$\phi 25.4$	1000	1.9	2.1	998.6	460.00	<3
SLSQ-30-35P	$\phi 30$	35	2.0	12.3	26.6	16.10	<1
SLSQ-30-40P	$\phi 30$	40	2.0	9.7	33.3	18.40	<1
SLSQ-30-50P	$\phi 30$	50	2.0	7.6	44.8	23.00	<1
SLSQ-30-60P	$\phi 30$	60	2.0	6.4	55.6	27.60	<1
SLSQ-30-70P	$\phi 30$	70	2.0	5.7	66.1	32.20	<1
SLSQ-30-80P	$\phi 30$	80	2.0	5.2	76.4	36.80	<1
SLSQ-30-90P	$\phi 30$	90	2.0	4.8	86.7	41.40	<1
SLSQ-30-100P	$\phi 30$	100	2.0	4.5	96.9	46.00	<1
SLSQ-30-120P	$\phi 30$	120	2.0	4.1	117.2	55.20	<1
SLSQ-30-150P	$\phi 30$	150	2.0	3.7	147.5	69.00	<1
SLSQ-30-170P	$\phi 30$	170	2.0	3.5	167.6	78.20	<1
SLSQ-30-200P	$\phi 30$	200	2.0	3.2	197.8	92.00	<1
SLSQ-30-220P	$\phi 30$	220	2.0	3.1	217.9	101.20	<1
SLSQ-30-250P	$\phi 30$	250	2.0	3.0	248.0	115.00	<1
SLSQ-30-300P	$\phi 30$	300	2.0	2.8	298.1	138.00	<1
SLSQ-30-350P	$\phi 30$	350	2.0	2.7	348.2	161.00	<3
SLSQ-30-400P	$\phi 30$	400	2.0	2.6	398.2	184.00	<3
SLSQ-30-450P	$\phi 30$	450	2.0	2.5	448.3	207.00	<3
SLSQ-30-500P	$\phi 30$	500	2.0	2.5	498.3	230.00	<3
SLSQ-30-600P	$\phi 30$	600	2.0	2.4	598.4	276.00	<3
SLSQ-30-700P	$\phi 30$	700	2.0	2.4	698.4	322.00	<3
SLSQ-30-800P	$\phi 30$	800	2.0	2.3	798.4	368.00	<3
SLSQ-30-900P	$\phi 30$	900	2.0	2.3	898.4	414.00	<3
SLSQ-30-1000P	$\phi 30$	1000	2.0	2.2	998.5	460.00	<3
SLSQ-30-1200P	$\phi 30$	1200	2.0	2.2	1198.5	552.00	<3
SLSQ-30-1500P	$\phi 30$	1500	2.0	2.2	1498.5	690.00	<3
SLSQ-30-2000P	$\phi 30$	2000	2.0	2.1	1998.5	920.00	<3
SLSQ-30-2500P	$\phi 30$	2500	2.0	2.1	2498.6	1150.00	<3
SLSQ-30-3000P	$\phi 30$	3000	2.0	2.1	2998.6	1380.00	<3
SLSQ-30-4000P	$\phi 30$	4000	2.0	2.1	3998.6	1840.00	<3
SLSQ-30-5000P	$\phi 30$	5000	2.0	2.1	4998.6	2300.00	<3

Compatible Optic Mounts

LHF-25S, -25.4S, -30S

Application
SystemsOptics &
Optical
CoatingsOpto-
Mechanics

Bases

Manual
StagesActuators &
AdjustersMotorized
StagesLight Sources &
Laser Safety

Index

Guide

Mirrors

Beamsplitters

Polarizers

Lenses

Multi-Element Optics

Filters

Prisms

Substrates/Windows

Optical Data

Maintenance

Selection Guide

Plano Convex
LensesPlano Concave
Lenses

Biconvex Lenses

Biconcave Lenses

Kit

Reasonable Lens

Cylindrical

Others

Plano Convex Lenses | SLB-P/SLSQ-P/SLSQK-P

Catalog Code W3047

Synthetic fused silica $\phi 40 - \phi 50.8$							
Part Number	Diameter ϕD [mm]	Focal length f [mm]	Edge thickness t_e [mm]	Center thickness t_c [mm]	Back focal length f_b [mm]	Radius of curvature r [mm]	Centration [']
SLSQ-40-50P	$\phi 40$	50	2.0	13.6	40.7	23.00	<1
SLSQ-40-60P	$\phi 40$	60	2.0	10.6	52.8	27.60	<1
SLSQ-40-70P	$\phi 40$	70	2.0	9.0	63.9	32.20	<1
SLSQ-40-80P	$\phi 40$	80	2.0	7.9	74.6	36.80	<1
SLSQ-40-90P	$\phi 40$	90	2.0	7.2	85.1	41.40	<1
SLSQ-40-100P	$\phi 40$	100	2.0	6.6	95.5	46.00	<1
SLSQ-40-120P	$\phi 40$	120	2.0	5.8	116.1	55.20	<1
SLSQ-40-150P	$\phi 40$	150	2.0	5.0	146.6	69.00	<1
SLSQ-40-170P	$\phi 40$	170	2.0	4.6	166.8	78.20	<1
SLSQ-40-200P	$\phi 40$	200	2.0	4.2	197.1	92.00	<1
SLSQ-40-220P	$\phi 40$	220	2.0	4.0	217.3	101.20	<1
SLSQ-40-250P	$\phi 40$	250	2.0	3.8	247.4	115.00	<1
SLSQ-40-300P	$\phi 40$	300	2.0	3.5	297.6	138.00	<1
SLSQ-40-350P	$\phi 40$	350	2.0	3.2	347.8	161.00	<1
SLSQ-40-400P	$\phi 40$	400	2.0	3.1	397.9	184.00	<1
SLSQ-40-450P	$\phi 40$	450	2.0	3.0	448.0	207.00	<3
SLSQ-40-500P	$\phi 40$	500	2.0	2.9	498.0	230.00	<3
SLSQ-50-70P	$\phi 50$	70	3.0	14.9	59.8	32.20	<1
SLSQ-50-80P	$\phi 50$	80	3.0	12.8	71.2	36.80	<1
SLSQ-50-90P	$\phi 50$	90	3.0	11.4	82.2	41.40	<1
SLSQ-50-100P	$\phi 50$	100	3.0	10.4	92.9	46.00	<1
SLSQ-50-120P	$\phi 50$	120	3.0	9.0	113.8	55.20	<1
SLSQ-50-150P	$\phi 50$	150	3.0	7.7	144.7	69.00	<1
SLSQ-50-170P	$\phi 50$	170	3.0	7.1	165.1	78.20	<1
SLSQ-50-200P	$\phi 50$	200	3.0	6.5	195.6	92.00	<1
SLSQ-50-220P	$\phi 50$	220	3.0	6.1	215.8	101.20	<1
SLSQ-50-250P	$\phi 50$	250	3.0	5.8	246.1	115.00	<1
SLSQ-50-300P	$\phi 50$	300	3.0	5.3	296.4	138.00	<1
SLSQ-50-350P	$\phi 50$	350	3.0	5.0	346.6	161.00	<1
SLSQ-50-400P	$\phi 50$	400	3.0	4.7	396.8	184.00	<1
SLSQ-50-450P	$\phi 50$	450	3.0	4.5	446.9	207.00	<1
SLSQ-50-500P	$\phi 50$	500	3.0	4.4	497.0	230.00	<1
SLSQ-50-600P	$\phi 50$	600	3.0	4.1	597.2	276.00	<3
SLSQ-50-700P	$\phi 50$	700	3.0	4.0	697.3	322.00	<3
SLSQ-50-800P	$\phi 50$	800	3.0	3.9	797.4	368.00	<3
SLSQ-50-900P	$\phi 50$	900	3.0	3.8	897.4	414.00	<3
SLSQ-50-1000P	$\phi 50$	1000	3.0	3.7	997.5	460.00	<3
SLSQ-50-1200P	$\phi 50$	1200	3.0	3.6	1197.6	552.00	<3
SLSQ-50-1500P	$\phi 50$	1500	3.0	3.5	1497.6	690.00	<3
SLSQ-50-2000P	$\phi 50$	2000	3.0	3.3	1997.7	920.00	<3
SLSQ-50-2500P	$\phi 50$	2500	3.0	3.3	2497.8	1150.00	<3
SLSQ-50-3000P	$\phi 50$	3000	3.0	3.2	2997.8	1380.00	<3
SLSQ-50-4000P	$\phi 50$	4000	3.0	3.2	3997.8	1840.00	<3
SLSQ-50-5000P	$\phi 50$	5000	3.0	3.1	4997.9	2300.00	<3
SLSQ-50.8-70P	$\phi 50.8$	70	2.5	14.9	59.8	32.20	<1
SLSQ-50.8-80P	$\phi 50.8$	80	2.6	12.8	71.2	36.80	<1
SLSQ-50.8-90P	$\phi 50.8$	90	2.7	11.4	82.2	41.40	<1
SLSQ-50.8-100P	$\phi 50.8$	100	2.8	10.4	92.9	46.00	<1
SLSQ-50.8-120P	$\phi 50.8$	120	2.8	9.0	113.8	55.20	<1
SLSQ-50.8-150P	$\phi 50.8$	150	2.9	7.7	144.7	69.00	<1
SLSQ-50.8-170P	$\phi 50.8$	170	2.9	7.1	165.1	78.20	<1
SLSQ-50.8-200P	$\phi 50.8$	200	2.9	6.5	195.6	92.00	<1
SLSQ-50.8-250P	$\phi 50.8$	250	2.9	5.7	246.1	115.00	<1
SLSQ-50.8-300P	$\phi 50.8$	300	2.9	5.3	296.4	138.00	<1
SLSQ-50.8-400P	$\phi 50.8$	400	2.9	4.7	396.8	184.00	<1
SLSQ-50.8-500P	$\phi 50.8$	500	3.0	4.4	497.0	230.00	<1
SLSQ-50.8-1000P	$\phi 50.8$	1000	3.0	3.7	997.5	460.00	<3

Compatible Optic Mounts

LHF-40S, -50S, -50.8S

Synthetic fused silica $\phi 60 - \phi 100$

Part Number	Diameter ϕD [mm]	Focal length f [mm]	Edge thickness t_e [mm]	Center thickness t_c [mm]	Back focal length f_b [mm]	Radius of curvature r [mm]	Centration [']
SLSQ-60-80P	$\phi 60$	80	3.0	18.5	67.3	36.80	<1
SLSQ-60-90P	$\phi 60$	90	3.0	15.9	79.1	41.40	<1
SLSQ-60-100P	$\phi 60$	100	3.0	14.1	90.3	46.00	<1
SLSQ-60-120P	$\phi 60$	120	3.0	11.9	111.9	55.20	<1
SLSQ-60-150P	$\phi 60$	150	3.0	9.9	143.2	69.00	<1
SLSQ-60-170P	$\phi 60$	170	3.0	9.0	163.8	78.20	<1
SLSQ-60-200P	$\phi 60$	200	3.0	8.0	194.5	92.00	<1
SLSQ-60-220P	$\phi 60$	220	3.0	7.5	214.8	101.20	<1
SLSQ-60-250P	$\phi 60$	250	3.0	7.0	245.2	115.00	<1
SLSQ-60-300P	$\phi 60$	300	3.0	6.3	295.7	138.00	<1
SLSQ-60-350P	$\phi 60$	350	3.0	5.8	346.0	161.00	<1
SLSQ-60-400P	$\phi 60$	400	3.0	5.5	396.3	184.00	<1
SLSQ-60-450P	$\phi 60$	450	3.0	5.2	446.5	207.00	<1
SLSQ-60-500P	$\phi 60$	500	3.0	5.0	496.6	230.00	<1
SLSQ-100-200P	$\phi 100$	200	3.0	17.8	187.8	92.00	<1
SLSQ-100-250P	$\phi 100$	250	3.0	14.4	240.1	115.00	<1
SLSQ-100-300P	$\phi 100$	300	3.0	12.4	291.5	138.00	<1
SLSQ-100-350P	$\phi 100$	350	3.0	11.0	342.5	161.00	<1
SLSQ-100-400P	$\phi 100$	400	3.0	9.9	393.2	184.00	<1
SLSQ-100-500P	$\phi 100$	500	3.0	8.5	494.2	230.00	<1
SLSQ-100-600P	$\phi 100$	600	3.0	7.6	594.8	276.00	<1
SLSQ-100-700P	$\phi 100$	700	3.0	6.9	695.3	322.00	<1
SLSQ-100-800P	$\phi 100$	800	3.0	6.4	795.6	368.00	<1
SLSQ-100-1000P	$\phi 100$	1000	3.0	5.7	995.1	460.00	<1

Synthetic fused silica for Excimer Laser $\phi 30, \phi 50$

Part Number	Diameter ϕD [mm]	Focal length f [mm]	Edge thickness t_e [mm]	Center thickness t_c [mm]	Back focal length f_b [mm]	Radius of curvature r [mm]	Centration [']
SLSQK-30-40P	$\phi 30$	40	2.0	9.7	33.3	18.40	<1
SLSQK-30-50P	$\phi 30$	50	2.0	7.6	44.8	23.00	<1
SLSQK-30-60P	$\phi 30$	60	2.0	6.4	55.6	27.60	<1
SLSQK-30-80P	$\phi 30$	80	2.0	5.2	76.4	36.80	<1
SLSQK-30-100P	$\phi 30$	100	2.0	4.5	96.9	46.00	<1
SLSQK-30-150P	$\phi 30$	150	2.0	3.7	147.5	69.00	<1
SLSQK-30-200P	$\phi 30$	200	2.0	3.2	197.8	92.00	<1
SLSQK-30-300P	$\phi 30$	300	2.0	2.8	298.1	138.00	<1
SLSQK-50-70P	$\phi 50$	70	3.0	14.9	59.8	32.20	<1
SLSQK-50-100P	$\phi 50$	100	3.0	10.4	92.9	46.00	<1
SLSQK-50-150P	$\phi 50$	150	3.0	7.7	144.7	69.00	<1
SLSQK-50-200P	$\phi 50$	200	3.0	6.5	195.6	92.00	<1
SLSQK-50-300P	$\phi 50$	300	3.0	5.3	296.4	138.00	<1
SLSQK-50-400P	$\phi 50$	400	3.0	4.7	396.8	184.00	<1
SLSQK-50-500P	$\phi 50$	500	3.0	4.4	497.0	230.00	<1

Compatible Optic Mounts

LHF-60AS, -100 / LHF-30S, -50S

Application
SystemsOptics &
Optical
CoatingsOpto-
Mechanics

Bases

Manual
StagesActuators &
AdjustersMotorized
StagesLight Sources &
Laser Safety

Index

Guide

Mirrors

Beamsplitters

Polarizers

Lenses

Multi-Element Optics

Filters

Prisms

Substrates/Windows

Optical Data

Maintenance

Selection Guide

Plano Convex
LensesPlano Concave
Lenses

Biconvex Lenses

Biconcave Lenses

Kit

Reasonable Lens

Cylindrical

Others

Plano Concave Lenses | SLB-N/SLSQ-N/SLSQK-N

RoHS

Application Systems

Optics & Optical Coatings

Opto-Mechanics

Bases

Manual Stages

Actuators & Adjusters

Motorized Stages

Light Sources & Laser Safety

Index

Guide

Mirrors

Beamsplitters

Polarizers

Lenses

Multi-Element Optics

Filters

Prisms

Substrates/Windows

Optical Data

Maintenance

Selection Guide

Plano Convex Lenses

Plano Concave Lenses

Biconvex Lenses

Biconcave Lenses

Kit

Reasonable Lens

Cylindrical


Others

These simple negative lenses have many uses. Alone they form a virtual image of a distant object or collimated light source. Used in combination with other optics they reduce the power of the system. Sharp edges which are common in negative lenses are removed by beveling in order to reduce the likelihood of chipping.

- There are three types of plano concave lenses available; BK7 for use in visible range to infrared wavelength range, synthetic fused silica for wavelengths less than 350nm ultraviolet light, and synthetic fused silica lens for excimer laser wavelengths such as KrF (248nm) and ArF (193nm).
- BK7 lenses are also available with three types of anti-reflection coatings, visible wavelength range, in the near-infrared range and in the infrared range.
- Our lenses are listed by outside diameter and focal length to assist your selection according to required specifications.




Schematic



Outline Drawing

(in mm)



How to specify the anti-reflection coating

In case of specifying an anti-reflection coating 633nm – 1064nm to near infrared lens of SLB-50.8-200N.
⇒ SLB-50.8-200NIR1

Type of AR Coat	Part Number	Wavelength Range [nm]	Transmittance [%]
Visible range	SLB-50.8-200NM	400 – 700	> Average 99
Near-infrared	SLB-50.8-200NIR1	633 – 1064	> Average 98.5
Infrared	SLB-50.8-200NIR2	750 – 1550	> Average 98.5

! Part of the above is an example of if you want to coat anti-reflective coating on the lens of the SLB-50.8-200N.

! Anti-reflection coating can be available to the lens of all of SLB.

Specifications

Material	SLB: BK7 SLSQ: Synthetic fused silica SLSQK: Synthetic fused silica for Excimer Laser
Design wavelength	546.1nm
Refractive index	BK7: $n_d=1.519$ Synthetic fused silica: $n_d=1.460$
Coating	Uncoated: the end of the part number 'N' Anti-reflection coating: the end of the part number 'NM', 'NIR1', 'NIR2'
Laser Damage Threshold	Anti-reflection coating: $4\text{J}/\text{cm}^2$ Laser pulse with 10ns, repetition frequency 20Hz
Clear aperture	90% of actual aperture (Uncoated) 85% of actual aperture (BMAR)
Surface Quality (Scratch-Dig)	20-10


Guide

- ▶ Lenses are available in a large selection and in custom sizes and focal lengths.
- ▶ In addition to our standard coating we offer custom anti-reflective coating at specific wavelengths.

Attention

- ▶ Plano concave lenses are negative lenses that diverge collimated incident light and are primarily used in conjunction with plano convex lenses to shape beams.
- ▶ The plano-concave lens has chromatic aberration, the focal length will vary depending on the wavelength. Please check the "data wavelength characteristic of the focal length" on the WEB of the focal length of each wavelength. [▶ WEB Reference](#) [Catalog Code](#) W3050
- ▶ The plano concave lenses are designed for parallel light to be incident to the concave surface.
- ▶ Transmission losses due to reflection off the front and rear surfaces of the lens can be minimized by coating the surfaces. Consult our Sales Division for anti-reflection coatings suitable for your application.
- ▶ Sharp edges are common in negative lenses are removed by beveling in order to reduce chipping may result in smaller than edge thickness. Thicknesses listed in tables are to theoretical sharp edge.

Typical Transmittance Data T: Transmission



BK7 $\phi 10 - \phi 25$										
Uncoated	How to specify the anti-reflection coating			Diameter ϕD [mm]	Focal length f [mm]	Edge thickness t_e [mm]	Center thickness t_c [mm]	Back focal length f_b [mm]	Radius of curvature r [mm]	Centration [']
Part Number	Visibe 400 - 700nm	Near-infrared 633 - 1064nm	Infrared 750 - 1550nm							
SLB-10-15N	M	IR1	IR2	$\phi 10$	-15	3.8	2.0	-16.3	7.79	<1
SLB-10-20N	M	IR1	IR2	$\phi 10$	-20	3.3	2.0	-21.3	10.38	<1
SLB-10-25N	M	IR1	IR2	$\phi 10$	-25	3.0	2.0	-26.3	12.98	<1
SLB-10-30N	M	IR1	IR2	$\phi 10$	-30	2.8	2.0	-31.3	15.57	<1
SLB-10-40N	M	IR1	IR2	$\phi 10$	-40	2.6	2.0	-41.3	20.76	<1
SLB-10-50N	M	IR1	IR2	$\phi 10$	-50	2.5	2.0	-51.3	25.95	<1
SLB-10-60N	M	IR1	IR2	$\phi 10$	-60	2.4	2.0	-61.3	31.14	<1
SLB-10-70N	M	IR1	IR2	$\phi 10$	-70	2.3	2.0	-71.3	36.33	<1
SLB-10-80N	M	IR1	IR2	$\phi 10$	-80	2.3	2.0	-81.3	41.52	<1
SLB-10-90N	M	IR1	IR2	$\phi 10$	-90	2.3	2.0	-91.3	46.71	<1
SLB-10-100N	M	IR1	IR2	$\phi 10$	-100	2.2	2.0	-101.3	51.90	<1
SLB-12.7-15N	M	IR1	IR2	$\phi 12.7$	-15	5.3	2.0	-16.3	7.79	<1
SLB-12.7-20N	M	IR1	IR2	$\phi 12.7$	-20	4.2	2.0	-21.3	10.38	<1
SLB-12.7-25N	M	IR1	IR2	$\phi 12.7$	-25	3.7	2.0	-26.3	12.98	<1
SLB-12.7-30N	M	IR1	IR2	$\phi 12.7$	-30	3.4	2.0	-31.3	15.57	<1
SLB-15-20N	M	IR1	IR2	$\phi 15$	-20	5.2	2.0	-21.3	10.38	<1
SLB-15-25N	M	IR1	IR2	$\phi 15$	-25	4.4	2.0	-26.3	12.98	<1
SLB-15-30N	M	IR1	IR2	$\phi 15$	-30	3.9	2.0	-31.3	15.57	<1
SLB-15-40N	M	IR1	IR2	$\phi 15$	-40	3.4	2.0	-41.3	20.76	<1
SLB-15-50N	M	IR1	IR2	$\phi 15$	-50	3.1	2.0	-51.3	25.95	<1
SLB-15-60N	M	IR1	IR2	$\phi 15$	-60	2.9	2.0	-61.3	31.14	<1
SLB-15-70N	M	IR1	IR2	$\phi 15$	-70	2.8	2.0	-71.3	36.33	<1
SLB-15-80N	M	IR1	IR2	$\phi 15$	-80	2.7	2.0	-81.3	41.52	<1
SLB-15-100N	M	IR1	IR2	$\phi 15$	-100	2.5	2.0	-101.3	51.90	<1
SLB-20-25N	M	IR1	IR2	$\phi 20$	-25	6.7	2.0	-26.3	12.98	<1
SLB-20-30N	M	IR1	IR2	$\phi 20$	-30	5.6	2.0	-31.3	15.57	<1
SLB-20-40N	M	IR1	IR2	$\phi 20$	-40	4.6	2.0	-41.3	20.76	<1
SLB-20-50N	M	IR1	IR2	$\phi 20$	-50	4.0	2.0	-51.3	25.95	<1
SLB-20-60N	M	IR1	IR2	$\phi 20$	-60	3.6	2.0	-61.3	31.14	<1
SLB-20-70N	M	IR1	IR2	$\phi 20$	-70	3.4	2.0	-71.3	36.33	<1
SLB-20-80N	M	IR1	IR2	$\phi 20$	-80	3.2	2.0	-81.3	41.52	<1
SLB-20-90N	M	IR1	IR2	$\phi 20$	-90	3.1	2.0	-91.3	46.71	<1
SLB-20-100N	M	IR1	IR2	$\phi 20$	-100	3.0	2.0	-101.3	51.90	<1
SLB-20-120N	M	IR1	IR2	$\phi 20$	-120	2.8	2.0	-121.3	62.28	<1
SLB-20-150N	M	IR1	IR2	$\phi 20$	-150	2.6	2.0	-151.3	77.85	<1
SLB-25-30N	M	IR1	IR2	$\phi 25$	-30	8.3	2.0	-31.3	15.57	<1
SLB-25-35N	M	IR1	IR2	$\phi 25$	-35	7.0	2.0	-36.3	18.17	<1
SLB-25-40N	M	IR1	IR2	$\phi 25$	-40	6.2	2.0	-41.3	20.76	<1
SLB-25-50N	M	IR1	IR2	$\phi 25$	-50	5.2	2.0	-51.3	25.95	<1
SLB-25-60N	M	IR1	IR2	$\phi 25$	-60	4.6	2.0	-61.3	31.14	<1
SLB-25-70N	M	IR1	IR2	$\phi 25$	-70	4.2	2.0	-71.3	36.33	<1
SLB-25-80N	M	IR1	IR2	$\phi 25$	-80	3.9	2.0	-81.3	41.52	<1
SLB-25-90N	M	IR1	IR2	$\phi 25$	-90	3.7	2.0	-91.3	46.71	<1
SLB-25-100N	M	IR1	IR2	$\phi 25$	-100	3.5	2.0	-101.3	51.90	<1
SLB-25-120N	M	IR1	IR2	$\phi 25$	-120	3.3	2.0	-121.3	62.28	<1
SLB-25-150N	M	IR1	IR2	$\phi 25$	-150	3.0	2.0	-151.3	77.85	<1
SLB-25-170N	M	IR1	IR2	$\phi 25$	-170	3.0	2.0	-171.3	88.23	<1
SLB-25-200N	M	IR1	IR2	$\phi 25$	-200	2.8	2.0	-201.3	103.80	<1

Compatible Optic Mounts

LHF-10S, -15S, -20S, -25S, -25.4S / MLH-10, -15

Application
SystemsOptics &
Optical
CoatingsOpto-
Mechanics

Bases

Manual
StagesActuators &
AdjustersMotorized
StagesLight Sources &
Laser Safety

Index

Guide

Mirrors

Beamsplitters

Polarizers

Lenses

Multi-Element Optics

Filters

Prisms

Substrates/Windows

Optical Data

Maintenance

Selection Guide

Plano Convex
LensesPlano Concave
Lenses

Biconvex Lenses

Biconcave Lenses

Kit

Reasonable Lens

Cylindrical

Others

Plano Concave Lenses

SLB-N/SLSQ-N/SLSQK-N

Catalog Code W3051

BK7 $\phi 25.4 - \phi 50.8$

Uncoated	How to specify the anti-reflection coating			Diameter φD [mm]	Focal length f [mm]	Edge thickness te [mm]	Center thickness tc [mm]	Back focal length fb [mm]	Radius of curvature r [mm]	Centration [']
Part Number	Visibe 400 – 700nm	Near-infrared 633 – 1064nm	Infrared 750 – 1550nm							
SLB-25.4-30N	M	IR1	IR2	φ25.4	−30	8.6	2.0	−31.3	15.57	<1
SLB-25.4-40N	M	IR1	IR2	φ25.4	−40	6.3	2.0	−41.3	20.76	<1
SLB-25.4-50N	M	IR1	IR2	φ25.4	−50	5.3	2.0	−51.3	25.95	<1
SLB-25.4-60N	M	IR1	IR2	φ25.4	−60	4.7	2.0	−61.3	31.14	<1
SLB-25.4-70N	M	IR1	IR2	φ25.4	−70	4.3	2.0	−71.3	36.33	<1
SLB-25.4-80N	M	IR1	IR2	φ25.4	−80	4.0	2.0	−81.3	41.52	<1
SLB-25.4-90N	M	IR1	IR2	φ25.4	−90	3.8	2.0	−91.3	46.71	<1
SLB-25.4-100N	M	IR1	IR2	φ25.4	−100	3.6	2.0	−101.3	51.90	<1
SLB-25.4-150N	M	IR1	IR2	φ25.4	−150	3.0	2.0	−151.3	77.85	<1
SLB-25.4-200N	M	IR1	IR2	φ25.4	−200	2.8	2.0	−201.3	103.80	<1
SLB-30-35N	M	IR1	IR2	φ30	−35	9.9	2.0	−36.3	18.17	<1
SLB-30-40N	M	IR1	IR2	φ30	−40	8.4	2.0	−41.3	20.76	<1
SLB-30-50N	M	IR1	IR2	φ30	−50	6.8	2.0	−51.3	25.95	<1
SLB-30-60N	M	IR1	IR2	φ30	−60	5.9	2.0	−61.3	31.14	<1
SLB-30-70N	M	IR1	IR2	φ30	−70	5.2	2.0	−71.3	36.33	<1
SLB-30-80N	M	IR1	IR2	φ30	−80	4.8	2.0	−81.3	41.52	<1
SLB-30-90N	M	IR1	IR2	φ30	−90	4.5	2.0	−91.3	46.71	<1
SLB-30-100N	M	IR1	IR2	φ30	−100	4.2	2.0	−101.3	51.90	<1
SLB-30-120N	M	IR1	IR2	φ30	−120	3.8	2.0	−121.3	62.28	<1
SLB-30-150N	M	IR1	IR2	φ30	−150	3.5	2.0	−151.3	77.85	<1
SLB-30-170N	M	IR1	IR2	φ30	−170	3.3	2.0	−171.3	88.23	<1
SLB-30-200N	M	IR1	IR2	φ30	−200	3.1	2.0	−201.3	103.80	<1
SLB-30-220N	M	IR1	IR2	φ30	−220	3.0	2.0	−221.3	114.18	<1
SLB-30-250N	M	IR1	IR2	φ30	−250	2.9	2.0	−251.3	129.75	<1
SLB-40-50N	M	IR1	IR2	φ40	−50	11.4	2.0	−51.3	25.95	<1
SLB-40-60N	M	IR1	IR2	φ40	−60	9.3	2.0	−61.3	31.14	<1
SLB-40-70N	M	IR1	IR2	φ40	−70	8.0	2.0	−71.3	36.33	<1
SLB-40-80N	M	IR1	IR2	φ40	−80	7.1	2.0	−81.3	41.52	<1
SLB-40-100N	M	IR1	IR2	φ40	−100	6.0	2.0	−101.3	51.90	<1
SLB-50-70N	M	IR1	IR2	φ50	−70	13.0	3.0	−72.0	36.33	<1
SLB-50-80N	M	IR1	IR2	φ50	−80	11.4	3.0	−82.0	41.52	<1
SLB-50-90N	M	IR1	IR2	φ50	−90	10.3	3.0	−92.0	46.71	<1
SLB-50-100N	M	IR1	IR2	φ50	−100	9.4	3.0	−102.0	51.90	<1
SLB-50-120N	M	IR1	IR2	φ50	−120	8.2	3.0	−122.0	62.28	<1
SLB-50-150N	M	IR1	IR2	φ50	−150	7.1	3.0	−152.0	77.85	<1
SLB-50-170N	M	IR1	IR2	φ50	−170	6.6	3.0	−172.0	88.23	<1
SLB-50-200N	M	IR1	IR2	φ50	−200	6.1	3.0	−202.0	103.80	<1
SLB-50-220N	M	IR1	IR2	φ50	−220	5.8	3.0	−222.0	114.18	<1
SLB-50-250N	M	IR1	IR2	φ50	−250	5.4	3.0	−252.0	129.75	<1
SLB-50-300N	M	IR1	IR2	φ50	−300	5.0	3.0	−302.0	155.70	<1
SLB-50.8-70N	M	IR1	IR2	φ50.8	−70	13.4	3.0	−72.0	36.33	<1
SLB-50.8-80N	M	IR1	IR2	φ50.8	−80	11.7	3.0	−82.0	41.52	<1
SLB-50.8-90N	M	IR1	IR2	φ50.8	−90	10.5	3.0	−92.0	46.71	<1
SLB-50.8-100N	M	IR1	IR2	φ50.8	−100	9.6	3.0	−102.0	51.90	<1
SLB-50.8-150N	M	IR1	IR2	φ50.8	−150	7.3	3.0	−152.0	77.85	<1
SLB-50.8-200N	M	IR1	IR2	φ50.8	−200	6.2	3.0	−202.0	103.80	<1
SLB-50.8-250N	M	IR1	IR2	φ50.8	−250	5.5	3.0	−252.0	129.75	<1
SLB-50.8-300N	M	IR1	IR2	φ50.8	−300	5.1	3.0	−302.0	155.70	<1
Plano Convex Lenses										
Plano Concave Lenses										
Biconvex Lenses										
Biconcave Lenses										
Kit										
Reasonable Lens										
Cylindrical										
Others										

Compatible Optic Mounts

LHF-30S, -40S, -50S, -50.8S

Synthetic fused silica $\phi 10 - \phi 25.4$

Part Number	Diameter ϕD [mm]	Focal length f [mm]	Edge thickness t_e [mm]	Center thickness t_c [mm]	Back focal length f_b [mm]	Radius of curvature r [mm]	Centration [']
SLSQ-10-15N	$\phi 10$	-15	4.1	2.0	-16.4	6.90	<1
SLSQ-10-20N	$\phi 10$	-20	3.5	2.0	-21.4	9.20	<1
SLSQ-10-25N	$\phi 10$	-25	3.1	2.0	-26.4	11.50	<1
SLSQ-10-30N	$\phi 10$	-30	2.9	2.0	-31.4	13.80	<1
SLSQ-10-40N	$\phi 10$	-40	2.7	2.0	-41.4	18.40	<1
SLSQ-10-50N	$\phi 10$	-50	2.6	2.0	-51.4	23.00	<1
SLSQ-10-60N	$\phi 10$	-60	2.5	2.0	-61.4	27.60	<1
SLSQ-10-70N	$\phi 10$	-70	2.4	2.0	-71.4	32.20	<1
SLSQ-10-80N	$\phi 10$	-80	2.3	2.0	-81.4	36.80	<1
SLSQ-10-90N	$\phi 10$	-90	2.3	2.0	-91.4	41.40	<1
SLSQ-10-100N	$\phi 10$	-100	2.3	2.0	-101.4	46.00	<1
SLSQ-12.7-20N	$\phi 12.7$	-20	4.5	2.0	-21.4	9.20	<1
SLSQ-12.7-25N	$\phi 12.7$	-25	3.9	2.0	-26.4	11.50	<1
SLSQ-12.7-30N	$\phi 12.7$	-30	3.5	2.0	-31.4	13.80	<1
SLSQ-12.7-40N	$\phi 12.7$	-40	3.1	2.0	-41.4	18.40	<1
SLSQ-15-20N	$\phi 15$	-20	5.9	2.0	-21.4	9.20	<1
SLSQ-15-25N	$\phi 15$	-25	4.8	2.0	-26.4	11.50	<1
SLSQ-15-30N	$\phi 15$	-30	4.2	2.0	-31.4	13.80	<1
SLSQ-15-40N	$\phi 15$	-40	3.6	2.0	-41.4	18.40	<1
SLSQ-15-50N	$\phi 15$	-50	3.3	2.0	-51.4	23.00	<1
SLSQ-15-60N	$\phi 15$	-60	3.0	2.0	-61.4	27.60	<1
SLSQ-15-70N	$\phi 15$	-70	2.9	2.0	-71.4	32.20	<1
SLSQ-15-80N	$\phi 15$	-80	2.8	2.0	-81.4	36.80	<1
SLSQ-15-90N	$\phi 15$	-90	2.7	2.0	-91.4	41.40	<1
SLSQ-15-100N	$\phi 15$	-100	2.6	2.0	-101.4	46.00	<1
SLSQ-20-25N	$\phi 20$	-25	7.8	2.0	-26.4	11.50	<1
SLSQ-20-30N	$\phi 20$	-30	6.3	2.0	-31.4	13.80	<1
SLSQ-20-40N	$\phi 20$	-40	5.0	2.0	-41.4	18.40	<1
SLSQ-20-50N	$\phi 20$	-50	4.3	2.0	-51.4	23.00	<1
SLSQ-20-60N	$\phi 20$	-60	3.9	2.0	-61.4	27.60	<1
SLSQ-20-70N	$\phi 20$	-70	3.6	2.0	-71.4	32.20	<1
SLSQ-20-80N	$\phi 20$	-80	3.4	2.0	-81.4	36.80	<1
SLSQ-20-90N	$\phi 20$	-90	3.2	2.0	-91.4	41.40	<1
SLSQ-20-100N	$\phi 20$	-100	3.1	2.0	-101.4	46.00	<1
SLSQ-20-120N	$\phi 20$	-120	2.9	2.0	-121.4	55.20	<1
SLSQ-20-150N	$\phi 20$	-150	2.7	2.0	-151.4	69.00	<1
SLSQ-25-30N	$\phi 25$	-30	10.0	2.0	-31.4	13.80	<1
SLSQ-25-35N	$\phi 25$	-35	8.0	2.0	-36.4	16.10	<1
SLSQ-25-40N	$\phi 25$	-40	6.9	2.0	-41.4	18.40	<1
SLSQ-25-50N	$\phi 25$	-50	5.7	2.0	-51.4	23.00	<1
SLSQ-25-60N	$\phi 25$	-60	5.0	2.0	-61.4	27.60	<1
SLSQ-25-70N	$\phi 25$	-70	4.5	2.0	-71.4	32.20	<1
SLSQ-25-80N	$\phi 25$	-80	4.2	2.0	-81.4	36.80	<1
SLSQ-25-90N	$\phi 25$	-90	3.9	2.0	-91.4	41.40	<1
SLSQ-25-100N	$\phi 25$	-100	3.7	2.0	-101.4	46.00	<1
SLSQ-25-120N	$\phi 25$	-120	3.4	2.0	-121.4	55.20	<1
SLSQ-25-150N	$\phi 25$	-150	3.1	2.0	-151.4	69.00	<1
SLSQ-25-170N	$\phi 25$	-170	3.0	2.0	-171.4	78.20	<1
SLSQ-25-200N	$\phi 25$	-200	2.9	2.0	-201.4	92.00	<1
SLSQ-25.4-30N	$\phi 25.4$	-30	10.4	2.0	-31.4	13.80	<1
SLSQ-25.4-35N	$\phi 25.4$	-35	8.2	2.0	-36.4	16.1	<1
SLSQ-25.4-40N	$\phi 25.4$	-40	7.1	2.0	-41.4	18.40	<1
SLSQ-25.4-50N	$\phi 25.4$	-50	5.8	2.0	-51.4	23.00	<1
SLSQ-25.4-60N	$\phi 25.4$	-60	5.1	2.0	-61.4	27.60	<1
SLSQ-25.4-70N	$\phi 25.4$	-70	4.6	2.0	-71.4	32.20	<1
SLSQ-25.4-80N	$\phi 25.4$	-80	4.3	2.0	-81.4	36.80	<1
SLSQ-25.4-90N	$\phi 25.4$	-90	4.0	2.0	-91.4	41.40	<1
SLSQ-25.4-100N	$\phi 25.4$	-100	3.8	2.0	-101.4	46.00	<1
SLSQ-25.4-150N	$\phi 25.4$	-150	3.2	2.0	-151.4	69.00	<1
SLSQ-25.4-200N	$\phi 25.4$	-200	2.9	2.0	-201.4	92.00	<1

Compatible Optic Mounts

LHF-10S, -15S, -20S, -25S, -25.4S, -30S / MLH-10, -15

Application
SystemsOptics &
Optical
CoatingsOpto-
Mechanics

Bases

Manual
StagesActuators &
AdjustersMotorized
StagesLight Sources &
Laser Safety

Index

Guide

Mirrors

Beamsplitters

Polarizers

Lenses

Multi-Element Optics

Filters

Prisms

Substrates/Windows

Optical Data

Maintenance

Selection Guide

Plano Convex
LensesPlano Concave
Lenses

Biconvex Lenses

Biconcave Lenses

Kit

Reasonable Lens

Cylindrical

Others

Plano Concave Lenses

SLB-N/SLSQ-N/SLSQK-N

Catalog Code W3053

Synthetic fused silica $\phi 30 - \phi 50.8$

Part Number	Diameter ϕD [mm]	Focal length f [mm]	Edge thickness t_e [mm]	Center thickness t_c [mm]	Back focal length f_b [mm]	Radius of curvature r [mm]	Centration [']
SLSQ-30-35N	$\phi 30$	-35	12.3	2.0	-36.4	16.10	<1
SLSQ-30-40N	$\phi 30$	-40	9.7	2.0	-41.4	18.40	<1
SLSQ-30-50N	$\phi 30$	-50	7.6	2.0	-51.4	23.00	<1
SLSQ-30-60N	$\phi 30$	-60	6.4	2.0	-61.4	27.60	<1
SLSQ-30-70N	$\phi 30$	-70	5.7	2.0	-71.4	32.20	<1
SLSQ-30-80N	$\phi 30$	-80	5.2	2.0	-81.4	36.80	<1
SLSQ-30-90N	$\phi 30$	-90	4.8	2.0	-91.4	41.40	<1
SLSQ-30-100N	$\phi 30$	-100	4.5	2.0	-101.4	46.00	<1
SLSQ-30-120N	$\phi 30$	-120	4.1	2.0	-121.4	55.20	<1
SLSQ-30-150N	$\phi 30$	-150	3.7	2.0	-151.4	69.00	<1
SLSQ-30-170N	$\phi 30$	-170	3.5	2.0	-171.4	78.20	<1
SLSQ-30-200N	$\phi 30$	-200	3.2	2.0	-201.4	92.00	<1
SLSQ-30-220N	$\phi 30$	-220	3.1	2.0	-221.4	101.20	<1
SLSQ-30-250N	$\phi 30$	-250	3.0	2.0	-251.4	115.00	<1
SLSQ-40-50N	$\phi 40$	-50	13.6	2.0	-51.4	23.00	<1
SLSQ-40-60N	$\phi 40$	-60	10.6	2.0	-61.4	27.60	<1
SLSQ-40-70N	$\phi 40$	-70	9.0	2.0	-71.4	32.20	<1
SLSQ-40-100N	$\phi 40$	-100	6.6	2.0	-101.4	46.00	<1
SLSQ-40-120N	$\phi 40$	-120	5.8	2.0	-121.4	55.20	<1
SLSQ-40-150N	$\phi 40$	-150	5.0	2.0	-151.4	69.00	<1
SLSQ-40-200N	$\phi 40$	-200	4.2	2.0	-201.4	92.00	<1
SLSQ-40-250N	$\phi 40$	-250	3.8	2.0	-251.4	115.00	<1
SLSQ-50-70N	$\phi 50$	-70	14.9	3.0	-72.1	32.20	<1
SLSQ-50-80N	$\phi 50$	-80	12.8	3.0	-82.1	36.80	<1
SLSQ-50-90N	$\phi 50$	-90	11.4	3.0	-92.1	41.40	<1
SLSQ-50-100N	$\phi 50$	-100	10.4	3.0	-102.1	46.00	<1
SLSQ-50-120N	$\phi 50$	-120	9.0	3.0	-122.1	55.20	<1
SLSQ-50-150N	$\phi 50$	-150	7.7	3.0	-152.1	69.00	<1
SLSQ-50-170N	$\phi 50$	-170	7.1	3.0	-172.1	78.20	<1
SLSQ-50-200N	$\phi 50$	-200	6.5	3.0	-202.1	92.00	<1
SLSQ-50-220N	$\phi 50$	-220	6.1	3.0	-222.1	101.20	<1
SLSQ-50-250N	$\phi 50$	-250	5.8	3.0	-252.1	115.00	<1
SLSQ-50-300N	$\phi 50$	-300	5.3	3.0	-302.1	138.00	<1
SLSQ-50.8-70N	$\phi 50.8$	-70	15.4	3.0	-72.1	32.20	<1
SLSQ-50.8-80N	$\phi 50.8$	-80	13.2	3.0	-82.1	36.80	<1
SLSQ-50.8-90N	$\phi 50.8$	-90	11.7	3.0	-92.1	41.40	<1
SLSQ-50.8-100N	$\phi 50.8$	-100	10.6	3.0	-102.1	46.00	<1
SLSQ-50.8-150N	$\phi 50.8$	-150	7.8	3.0	-152.1	69.00	<1
SLSQ-50.8-200N	$\phi 50.8$	-200	6.6	3.0	-202.1	92.00	<1
SLSQ-50.8-250N	$\phi 50.8$	-250	5.8	3.0	-252.1	115.00	<1
SLSQ-50.8-300N	$\phi 50.8$	-300	5.4	3.0	-302.1	138.00	<1

Synthetic fused silica for Excimer Laser $\phi 30, \phi 50$

Part Number	Diameter D [mm]	Focal length f [mm]	Edge thickness t_e [mm]	Center thickness t_c [mm]	Back focal length f_b [mm]	Radius of curvature r [mm]	Centration [']
SLSQK-30-50N	$\phi 30$	-50	7.6	2.0	-51.4	23.00	<1
SLSQK-30-60N	$\phi 30$	-60	6.4	2.0	-61.4	27.60	<1
SLSQK-30-70N	$\phi 30$	-70	5.7	2.0	-71.4	32.20	<1
SLSQK-30-100N	$\phi 30$	-100	4.5	2.0	-101.4	46.00	<1
SLSQK-30-150N	$\phi 30$	-150	3.7	2.0	-151.4	69.00	<1
SLSQK-50-70N	$\phi 50$	-70	14.9	3.0	-72.1	32.20	<1
SLSQK-50-80N	$\phi 50$	-80	12.8	3.0	-82.1	36.80	<1
SLSQK-50-100N	$\phi 50$	-100	10.4	3.0	-102.1	46.00	<1
SLSQK-50-150N	$\phi 50$	-150	7.7	3.0	-152.1	69.00	<1
SLSQK-50-200N	$\phi 50$	-200	6.5	3.0	-202.1	92.00	<1

Compatible Optic Mounts

LHF-30S, -40S, -50S, -50.8S


Catalog Code W3054

Symmetrical biconvex lenses are most useful when dealing with finite conjugate points. This makes them ideal for 1:1 imaging applications or for use in multi-element systems.

- There are two types of biconvex lenses available; BK7 for use in visible range to infrared wavelength range and synthetic fused silica for wavelengths less than 350nm ultraviolet light.
- BK7 lenses are also available with three types of anti-reflection coatings, visible wavelength range, in the near-infrared range and in the infrared range.
- Our lenses are listed by outside diameter and focal length to assist your selection according to required specifications.




Schematic



Outline Drawing

(in mm)



Specifications

Material	SLB: BK7 SLSQ: Synthetic fused silica
Design wavelength	546.1nm
Refractive index	BK7: $n_d=1.519$ Synthetic fused silica: $n_d=1.460$
Coating	Uncoated: the end of the part number 'P' Anti-reflection coating: the end of the part number 'PM', 'PIR1', 'PIR2'
Laser Damage Threshold	Anti-reflection coating: $4J/cm^2$ Laser pulse with 10ns, repetition frequency 20Hz
Clear aperture	90% of actual aperture: Uncoated 85% of actual aperture: with coating, $\phi 10 \leq D$ 83% of actual aperture: with coating, $D < \phi 10$
Surface Quality (Scratch-Dig)	20-10 $\phi 10 \leq D$ 40-20 $D < \phi 10$

Guide

- ▶ Lenses are available in a large selection and in custom sizes and focal lengths.
- ▶ In addition to our standard coating we offer custom anti-reflective coating at specific wavelengths.
- ▶ Achromatic lenses (DLB) which are chromatic aberration correction are also available. [Reference](#) B172

Attention

- ▶ The biconvex spherical lens has a chromatic aberration, and the focal length will vary depending on the wavelength. Please check the "wavelength characteristic of the focal length data" on the Web for the focal lengths of each wavelength. [WEB Reference](#) [Catalog Code](#) W3055
- ▶ Biconvex spherical aberration is larger than that of the plano-convex lens, so focal spot may not gather at one point.
- ▶ Transmissions losses due to reflection off the front and rear surfaces of the lens can be minimized by coating the surfaces. Consult our Sales Division for anti-reflection coatings suitable for your application.

How to specify the anti-reflection coating

In case of specifying a anti-reflection coating 633nm – 1064nm to near infrared lens of SLB-100B-500P.

⇒ SLB-100B-500PIR1

Type of AR Coat	Part Number	Wavelength Range [nm]	Transmittance [%]
Visible range	SLB-100B-500PM	400 – 700	> Average 99
Near-infrared	SLB-100B-500PIR1	633 – 1064	> Average 98.5
Infrared	SLB-100B-500PIR2	750 – 1550	> Average 98.5

1 Part of the above is an example of if you want to coat anti-reflective coating on the lens of the SLB-100B-500P.

1 Anti-reflection coating can be available to the lens of all of SLB.

BK7 $\phi 5$

Part Number	How to specify the anti-reflection coating			Diameter ϕD [mm]	Focal length f [mm]	Edge thickness t_e [mm]	Center thickness t_c [mm]	Back focal length f_b [mm]	Radius of curvature r [mm]	Centration [']
	Uncoated	Visibe 400 – 700nm	Near-infrared 633 – 1064nm	Infrared 750 – 1550nm						
SLB-05B-06P		M	IR1	IR2	$\phi 5$	6.4	1.5	2.5	5.6	6.23 <3
SLB-05B-08P		M	IR1	IR2	$\phi 5$	8.4	1.4	2.1	7.6	8.30 <3
SLB-05B-10P		M	IR1	IR2	$\phi 5$	10.3	1.3	1.9	9.7	10.38 <3
SLB-05B-12P		M	IR1	IR2	$\phi 5$	12.3	1.2	1.7	11.7	12.46 <3
SLB-05B-15P		M	IR1	IR2	$\phi 5$	15.3	1.2	1.6	14.7	15.57 <3
SLB-05B-20P		M	IR1	IR2	$\phi 5$	20.2	1.1	1.4	19.8	20.76 <3
SLB-05B-25P		M	IR1	IR2	$\phi 5$	25.2	1.1	1.3	24.8	25.95 <3

Compatible Optic Mounts

MLH-10, -15

Biconvex Lenses | SLB-B-P/SLSQ-B-P

Catalog Code W3055

BK7 φ6 – φ20										
Uncoated	How to specify the anti-reflection coating			Diameter φD [mm]	Focal length f [mm]	Edge thickness te [mm]	Center thickness tc [mm]	Back focal length fb [mm]	Radius of curvature r [mm]	Centration [']
Part Number	Visibe 400 – 700nm	Near-infrared 633 – 1064nm	Infrared 750 – 1550nm							
SLB-06B-06P	M	IR1	IR2	φ6	6.4	1.0	2.5	5.6	6.23	<3
SLB-06B-08P	M	IR1	IR2	φ6	8.4	1.0	2.1	7.6	8.30	<3
SLB-06B-10P	M	IR1	IR2	φ6	10.3	1.0	1.9	9.7	10.38	<3
SLB-06B-12P	M	IR1	IR2	φ6	12.3	1.0	1.7	11.7	12.46	<3
SLB-06B-15P	M	IR1	IR2	φ6	15.3	1.0	1.6	14.7	15.57	<3
SLB-06B-20P	M	IR1	IR2	φ6	20.2	1.0	1.4	19.8	20.76	<3
SLB-07B-08P	M	IR1	IR2	φ7	8.6	2.0	3.6	7.4	8.30	<3
SLB-07B-10P	M	IR1	IR2	φ7	10.5	1.9	3.1	9.5	10.38	<3
SLB-07B-12P	M	IR1	IR2	φ7	12.5	1.8	2.8	11.5	12.46	<3
SLB-07B-15P	M	IR1	IR2	φ7	15.4	1.7	2.5	14.6	15.57	<3
SLB-07B-20P	M	IR1	IR2	φ7	20.4	1.7	2.3	19.6	20.76	<3
SLB-08B-08P	M	IR1	IR2	φ8	8.6	1.5	3.6	7.4	8.30	<3
SLB-08B-10P	M	IR1	IR2	φ8	10.5	1.5	3.1	9.5	10.38	<3
SLB-08B-12P	M	IR1	IR2	φ8	12.5	1.5	2.8	11.5	12.46	<3
SLB-08B-15P	M	IR1	IR2	φ8	15.4	1.5	2.5	14.6	15.57	<3
SLB-08B-20P	M	IR1	IR2	φ8	20.4	1.5	2.3	19.6	20.76	<3
SLB-08B-25P	M	IR1	IR2	φ8	25.4	1.5	2.1	24.6	25.95	<3
SLB-10B-10P	M	IR1	IR2	φ10	10.8	2.0	4.6	9.2	10.38	<1
SLB-10B-15P	M	IR1	IR2	φ10	15.6	2.0	3.6	14.4	15.57	<1
SLB-10B-20P	M	IR1	IR2	φ10	20.5	2.0	3.2	19.5	20.76	<1
SLB-10B-25P	M	IR1	IR2	φ10	25.5	2.0	3.0	24.5	25.95	<1
SLB-10B-30P	M	IR1	IR2	φ10	30.5	2.0	2.8	29.5	31.14	<1
SLB-10B-40P	M	IR1	IR2	φ10	40.4	2.0	2.6	39.6	41.52	<1
SLB-10B-50P	M	IR1	IR2	φ10	50.4	2.0	2.5	49.6	51.90	<1
SLB-10B-60P	M	IR1	IR2	φ10	60.4	2.0	2.4	59.6	62.28	<1
SLB-10B-70P	M	IR1	IR2	φ10	70.4	2.0	2.3	69.6	72.66	<1
SLB-10B-80P	M	IR1	IR2	φ10	80.4	2.0	2.3	79.6	83.04	<1
SLB-10B-90P	M	IR1	IR2	φ10	90.4	2.0	2.3	89.6	93.42	<1
SLB-10B-100P	M	IR1	IR2	φ10	100.4	2.0	2.2	99.6	103.80	<1
SLB-12.7B-12P	M	IR1	IR2	φ12.7	13.0	2.0	5.5	11.0	12.46	<1
SLB-12.7B-20P	M	IR1	IR2	φ12.7	20.7	2.0	4.0	19.3	20.76	<1
SLB-12.7B-25P	M	IR1	IR2	φ12.7	25.6	2.0	3.6	24.4	25.95	<1
SLB-12.7B-30P	M	IR1	IR2	φ12.7	30.6	2.0	3.3	29.5	31.14	<1
SLB-12.7B-40P	M	IR1	IR2	φ12.7	40.5	2.0	3.0	39.5	41.52	<1
SLB-12.7B-50P	M	IR1	IR2	φ12.7	50.5	2.0	2.8	49.5	51.90	<1
SLB-12.7B-60P	M	IR1	IR2	φ12.7	60.4	2.0	2.6	59.6	62.28	<1
SLB-12.7B-70P	M	IR1	IR2	φ12.7	70.4	2.0	2.6	69.6	72.66	<1
SLB-15B-15P	M	IR1	IR2	φ15	16.0	2.0	5.9	14.0	15.57	<1
SLB-15B-20P	M	IR1	IR2	φ15	20.8	2.0	4.8	19.2	20.76	<1
SLB-15B-25P	M	IR1	IR2	φ15	25.7	2.0	4.2	24.3	25.95	<1
SLB-15B-30P	M	IR1	IR2	φ15	30.6	2.0	3.8	29.4	31.14	<1
SLB-15B-40P	M	IR1	IR2	φ15	40.6	2.0	3.4	39.4	41.52	<1
SLB-15B-50P	M	IR1	IR2	φ15	50.5	2.0	3.1	49.5	51.90	<1
SLB-15B-60P	M	IR1	IR2	φ15	60.5	2.0	2.9	59.5	62.28	<1
SLB-15B-70P	M	IR1	IR2	φ15	70.5	2.0	2.8	69.5	72.66	<1
SLB-15B-80P	M	IR1	IR2	φ15	80.4	2.0	2.7	79.6	83.04	<1
SLB-15B-90P	M	IR1	IR2	φ15	90.4	2.0	2.6	89.6	93.42	<1
SLB-15B-100P	M	IR1	IR2	φ15	100.4	2.0	2.5	99.6	103.80	<1
SLB-20B-20P	M	IR1	IR2	φ20	21.2	2.0	7.1	18.8	20.76	<1
SLB-20B-25P	M	IR1	IR2	φ20	26.0	2.0	6.0	24.0	25.95	<1
SLB-20B-30P	M	IR1	IR2	φ20	31.0	2.0	5.3	29.1	31.14	<1
SLB-20B-40P	M	IR1	IR2	φ20	40.7	2.0	4.4	39.3	41.52	<1
SLB-20B-50P	M	IR1	IR2	φ20	50.7	2.0	3.9	49.3	51.90	<1
SLB-20B-60P	M	IR1	IR2	φ20	60.6	2.0	3.6	59.4	62.28	<1
SLB-20B-70P	M	IR1	IR2	φ20	70.6	2.0	3.4	69.4	72.66	<1
SLB-20B-80P	M	IR1	IR2	φ20	80.5	2.0	3.2	79.5	83.04	<1
SLB-20B-90P	M	IR1	IR2	φ20	90.5	2.0	3.1	89.5	93.42	<1
SLB-20B-100P	M	IR1	IR2	φ20	100.5	2.0	3.0	99.5	103.80	<1
SLB-20B-120P	M	IR1	IR2	φ20	120.5	2.0	2.8	119.5	124.56	<1
SLB-20B-150P	M	IR1	IR2	φ20	150.4	2.0	2.6	149.6	155.70	<1

Compatible Optic Mounts

LHF-10S, -15S, -20S / MLH-10, -15

BK7 $\phi 25 - \phi 50$										
Uncoated	How to specify the anti-reflection coating			Diameter ϕD [mm]	Focal length f [mm]	Edge thickness t_e [mm]	Center thickness t_c [mm]	Back focal length f_b [mm]	Radius of curvature r [mm]	Centration [']
Part Number	Visibe 400 - 700nm	Near-infrared 633 - 1064nm	Infrared 750 - 1550nm							
SLB-25B-25P	M	IR1	IR2	$\phi 25$	26.5	2.0	8.4	23.5	25.95	<1
SLB-25B-30P	M	IR1	IR2	$\phi 25$	31.2	2.0	7.2	28.8	31.14	<1
SLB-25B-35P	M	IR1	IR2	$\phi 25$	36.1	2.0	6.4	33.9	36.33	<1
SLB-25B-40P	M	IR1	IR2	$\phi 25$	41.0	2.0	5.9	39.0	41.52	<1
SLB-25B-50P	M	IR1	IR2	$\phi 25$	50.8	2.0	5.1	49.2	51.90	<1
SLB-25B-60P	M	IR1	IR2	$\phi 25$	60.8	2.0	4.5	59.2	62.28	<1
SLB-25B-70P	M	IR1	IR2	$\phi 25$	70.7	2.0	4.1	69.3	72.66	<1
SLB-25B-80P	M	IR1	IR2	$\phi 25$	80.6	2.0	3.9	79.4	83.04	<1
SLB-25B-90P	M	IR1	IR2	$\phi 25$	90.6	2.0	3.7	89.4	93.42	<1
SLB-25B-100P	M	IR1	IR2	$\phi 25$	100.6	2.0	3.5	99.4	103.80	<1
SLB-25B-150P	M	IR1	IR2	$\phi 25$	150.5	2.0	3.0	149.5	155.70	<1
SLB-25B-170P	M	IR1	IR2	$\phi 25$	170.5	2.0	2.9	169.5	176.46	<1
SLB-25B-200P	M	IR1	IR2	$\phi 25$	200.5	2.0	2.8	199.5	207.60	<1
SLB-25.4B-25P	M	IR1	IR2	$\phi 25.4$	26.5	1.8	8.4	23.6	25.95	<1
SLB-25.4B-30P	M	IR1	IR2	$\phi 25.4$	31.2	1.8	7.2	28.7	31.14	<1
SLB-25.4B-35P	M	IR1	IR2	$\phi 25.4$	36.1	1.8	6.4	33.9	36.33	<1
SLB-25.4B-40P	M	IR1	IR2	$\phi 25.4$	41.0	1.9	5.9	39.0	41.52	<1
SLB-25.4B-50P	M	IR1	IR2	$\phi 25.4$	50.8	1.9	5.1	49.2	51.90	<1
SLB-25.4B-60P	M	IR1	IR2	$\phi 25.4$	60.8	1.9	4.5	59.2	62.28	<1
SLB-25.4B-70P	M	IR1	IR2	$\phi 25.4$	70.7	1.9	4.1	69.3	72.66	<1
SLB-25.4B-80P	M	IR1	IR2	$\phi 25.4$	80.6	1.9	3.9	79.3	83.04	<1
SLB-25.4B-100P	M	IR1	IR2	$\phi 25.4$	100.6	1.9	3.5	99.4	103.80	<1
SLB-25.4B-150P	M	IR1	IR2	$\phi 25.4$	150.5	2.0	3.0	149.5	155.70	<1
SLB-25.4B-200P	M	IR1	IR2	$\phi 25.4$	200.5	2.0	2.8	199.6	207.60	<1
SLB-30B-30P	M	IR1	IR2	$\phi 30$	31.7	2.0	9.7	28.3	31.14	<1
SLB-30B-35P	M	IR1	IR2	$\phi 30$	36.5	2.0	8.5	33.5	36.33	<1
SLB-30B-40P	M	IR1	IR2	$\phi 30$	41.3	2.0	7.6	38.7	41.52	<1
SLB-30B-50P	M	IR1	IR2	$\phi 30$	51.1	2.0	6.4	48.9	51.90	<1
SLB-30B-60P	M	IR1	IR2	$\phi 30$	60.9	2.0	5.7	59.1	62.28	<1
SLB-30B-70P	M	IR1	IR2	$\phi 30$	70.9	2.0	5.1	69.1	72.66	<1
SLB-30B-80P	M	IR1	IR2	$\phi 30$	80.8	2.0	4.7	79.2	83.04	<1
SLB-30B-100P	M	IR1	IR2	$\phi 30$	100.7	2.0	4.2	99.3	103.80	<1
SLB-30B-120P	M	IR1	IR2	$\phi 30$	120.6	2.0	3.8	119.4	124.56	<1
SLB-30B-150P	M	IR1	IR2	$\phi 30$	150.6	2.0	3.4	149.4	155.70	<1
SLB-30B-170P	M	IR1	IR2	$\phi 30$	170.5	2.0	3.3	169.5	176.46	<1
SLB-30B-200P	M	IR1	IR2	$\phi 30$	200.5	2.0	3.1	199.5	207.60	<1
SLB-30B-250P	M	IR1	IR2	$\phi 30$	250.5	2.0	2.9	249.5	259.50	<1
SLB-40B-40P	M	IR1	IR2	$\phi 40$	42.1	2.0	12.3	37.9	41.52	<1
SLB-40B-50P	M	IR1	IR2	$\phi 40$	51.7	2.0	10.0	48.3	51.90	<1
SLB-40B-60P	M	IR1	IR2	$\phi 40$	61.4	2.0	8.6	58.6	62.28	<1
SLB-40B-70P	M	IR1	IR2	$\phi 40$	71.3	2.0	7.6	68.7	72.66	<1
SLB-40B-80P	M	IR1	IR2	$\phi 40$	81.2	2.0	6.9	78.8	83.04	<1
SLB-40B-90P	M	IR1	IR2	$\phi 40$	91.1	2.0	6.3	88.9	93.42	<1
SLB-40B-100P	M	IR1	IR2	$\phi 40$	101.0	2.0	5.9	99.0	103.80	<1
SLB-40B-120P	M	IR1	IR2	$\phi 40$	120.9	2.0	5.2	119.1	124.56	<1
SLB-40B-150P	M	IR1	IR2	$\phi 40$	150.8	2.0	4.6	149.2	155.70	<1
SLB-40B-170P	M	IR1	IR2	$\phi 40$	170.7	2.0	4.3	169.3	176.46	<1
SLB-40B-200P	M	IR1	IR2	$\phi 40$	200.6	2.0	3.9	199.4	207.60	<1
SLB-40B-250P	M	IR1	IR2	$\phi 40$	250.6	2.0	3.5	249.4	259.50	<1
SLB-50B-50P	M	IR1	IR2	$\phi 50$	52.7	3.0	15.8	47.3	51.90	<1
SLB-50B-60P	M	IR1	IR2	$\phi 50$	62.3	3.0	13.5	57.7	62.28	<1
SLB-50B-70P	M	IR1	IR2	$\phi 50$	72.0	3.0	11.9	68.0	72.66	<1
SLB-50B-80P	M	IR1	IR2	$\phi 50$	81.8	3.0	10.7	78.2	83.04	<1
SLB-50B-90P	M	IR1	IR2	$\phi 50$	91.6	3.0	9.8	88.4	93.42	<1
SLB-50B-100P	M	IR1	IR2	$\phi 50$	101.5	3.0	9.1	98.5	103.80	<1
SLB-50B-120P	M	IR1	IR2	$\phi 50$	121.3	3.0	8.0	118.7	124.56	<1
SLB-50B-150P	M	IR1	IR2	$\phi 50$	151.2	3.0	7.0	148.8	155.70	<1
SLB-50B-170P	M	IR1	IR2	$\phi 50$	171.1	3.0	6.6	168.9	176.46	<1
SLB-50B-200P	M	IR1	IR2	$\phi 50$	201.0	3.0	6.0	199.0	207.60	<1
SLB-50B-220P	M	IR1	IR2	$\phi 50$	220.9	3.0	5.7	219.1	228.36	<1
SLB-50B-250P	M	IR1	IR2	$\phi 50$	251.0	3.0	5.4	249.1	259.50	<1
SLB-50B-300P	M	IR1	IR2	$\phi 50$	300.8	3.0	5.0	299.2	311.40	<1

Compatible Optic Mounts

LHF-25S, -25.4S, -30S, -40S, -50S

Application Systems

Optics & Optical Coatings

Opto-Mechanics

Bases

Manual Stages

Actuators & Adjusters

Motorized Stages

Light Sources & Laser Safety

Index

Guide

Mirrors

Beamsplitters

Polarizers

Lenses

Multi-Element Optics

Filters

Prisms

Substrates/Windows

Optical Data

Maintenance

Selection Guide

Plano Convex Lenses
Plano Concave Lenses

Biconvex Lenses

Biconcave Lenses

Kit

Reasonable Lens

Cylindrical

Others

Biconvex Lenses | SLB-B-P/SLSQ-B-P

Catalog Code W3057

BK7 $\phi 50.8 - \phi 100$										
Uncoated	How to specify the anti-reflection coating			Diameter ϕD [mm]	Focal length f [mm]	Edge thickness t_e [mm]	Center thickness t_c [mm]	Back focal length f_b [mm]	Radius of curvature r [mm]	Centration [']
Part Number	Visibe 400 – 700nm	Near-infrared 633 – 1064nm	Infrared 750 – 1550nm							
SLB-50.8B-50P	M	IR1	IR2	$\phi 50.8$	52.7	3.0	16.3	47.1	51.90	<1
SLB-50.8B-60P	M	IR1	IR2	$\phi 50.8$	62.3	3.0	13.8	57.7	62.28	<1
SLB-50.8B-70P	M	IR1	IR2	$\phi 50.8$	72.0	3.0	12.2	68.0	72.66	<1
SLB-50.8B-80P	M	IR1	IR2	$\phi 50.8$	81.8	3.0	11.0	78.2	83.04	<1
SLB-50.8B-90P	M	IR1	IR2	$\phi 50.8$	91.6	2.8	9.8	88.3	93.42	<1
SLB-50.8B-100P	M	IR1	IR2	$\phi 50.8$	101.5	3.0	9.3	98.5	103.80	<1
SLB-50.8B-120P	M	IR1	IR2	$\phi 50.8$	121.3	2.8	8.0	118.6	124.56	<1
SLB-50.8B-150P	M	IR1	IR2	$\phi 50.8$	151.2	2.8	7.0	148.9	155.70	<1
SLB-50.8B-170P	M	IR1	IR2	$\phi 50.8$	171.1	2.4	6.1	169.0	176.46	<1
SLB-50.8B-200P	M	IR1	IR2	$\phi 50.8$	201.0	2.9	6.0	199.0	207.60	<1
SLB-50.8B-250P	M	IR1	IR2	$\phi 50.8$	251.0	2.9	5.4	249.1	259.50	<1
SLB-50.8B-300P	M	IR1	IR2	$\phi 50.8$	300.8	2.9	5.0	299.1	311.40	<1
SLB-60B-60P	M	IR1	IR2	$\phi 60$	63.2	3.0	18.4	56.8	62.28	<1
SLB-60B-70P	M	IR1	IR2	$\phi 60$	72.7	3.0	16.0	67.3	72.66	<1
SLB-60B-80P	M	IR1	IR2	$\phi 60$	82.4	3.0	14.2	77.6	83.04	<1
SLB-60B-90P	M	IR1	IR2	$\phi 60$	92.2	3.0	13.0	87.8	93.42	<1
SLB-60B-100P	M	IR1	IR2	$\phi 60$	102.0	3.0	11.9	98.0	103.80	<1
SLB-60B-120P	M	IR1	IR2	$\phi 60$	121.7	3.0	10.3	118.3	124.56	<1
SLB-60B-150P	M	IR1	IR2	$\phi 60$	151.5	3.0	8.8	148.5	155.70	<1
SLB-60B-170P	M	IR1	IR2	$\phi 60$	171.4	3.0	8.1	168.7	176.46	<1
SLB-60B-200P	M	IR1	IR2	$\phi 60$	201.2	3.0	7.4	198.8	207.60	<1
SLB-60B-250P	M	IR1	IR2	$\phi 60$	251.1	3.0	6.5	248.9	259.50	<1
SLB-60B-300P	M	IR1	IR2	$\phi 60$	301.0	3.0	5.9	299.0	311.40	<1
SLB-80B-100P	M	IR1	IR2	$\phi 80$	103.2	3.0	19.0	96.8	103.80	<1
SLB-80B-150P	M	IR1	IR2	$\phi 80$	152.2	3.0	13.5	147.8	155.70	<1
SLB-80B-200P	M	IR1	IR2	$\phi 80$	201.8	3.0	10.8	198.2	207.60	<1
SLB-80B-250P	M	IR1	IR2	$\phi 80$	251.5	3.0	9.2	248.5	259.50	<1
SLB-80B-300P	M	IR1	IR2	$\phi 80$	301.3	3.0	8.2	298.7	311.40	<1
SLB-80B-400P	M	IR1	IR2	$\phi 80$	401.1	3.0	6.9	398.9	415.20	<1
SLB-80B-500P	M	IR1	IR2	$\phi 80$	501.0	3.0	6.1	499.0	519.00	<1
SLB-80B-700P	M	IR1	IR2	$\phi 80$	700.9	3.0	5.2	699.1	726.60	<1
SLB-80B-1000P	M	IR1	IR2	$\phi 80$	1000.7	3.0	4.5	999.3	1038.00	<1
SLB-100B-150P	M	IR1	IR2	$\phi 100$	153.3	3.0	19.5	146.7	155.70	<1
SLB-100B-200P	M	IR1	IR2	$\phi 100$	202.5	3.0	15.2	197.5	207.60	<1
SLB-100B-250P	M	IR1	IR2	$\phi 100$	252.1	3.0	12.7	247.9	259.50	<1
SLB-100B-300P	M	IR1	IR2	$\phi 100$	301.8	3.0	11.1	298.2	311.40	<1
SLB-100B-400P	M	IR1	IR2	$\phi 100$	401.5	3.0	9.0	398.5	415.20	<1
SLB-100B-500P	M	IR1	IR2	$\phi 100$	501.3	3.0	7.8	498.7	519.00	<1
SLB-100B-700P	M	IR1	IR2	$\phi 100$	701.1	3.0	6.4	698.9	726.60	<1
SLB-100B-1000P	M	IR1	IR2	$\phi 100$	1001.0	3.0	5.4	999.1	1038.00	<1

Catalog Code W3058

Synthetic fused silica $\phi 5 - \phi 6$							
Part Number	Diameter ϕD [mm]	Focal length f [mm]	Edge thickness t_e [mm]	Center thickness t_c [mm]	Back focal length f_b [mm]	Radius of curvature r [mm]	Centration [']
SLSQ-05B-06P	$\phi 5$	6.5	1.6	2.8	5.5	5.52	<3
SLSQ-05B-08P	$\phi 5$	8.4	1.4	2.3	7.6	7.36	<3
SLSQ-05B-10P	$\phi 5$	10.4	1.3	2.0	9.6	9.20	<3
SLSQ-05B-12P	$\phi 5$	12.3	1.3	1.8	11.7	11.04	<3
SLSQ-05B-15P	$\phi 5$	15.3	1.2	1.7	14.7	13.80	<3
SLSQ-05B-20P	$\phi 5$	20.3	1.2	1.5	19.7	18.40	<3
SLSQ-05B-25P	$\phi 5$	25.2	1.1	1.4	24.8	23.00	<3
SLSQ-05B-30P	$\phi 5$	30.2	1.1	1.3	29.8	27.60	<3
SLSQ-06B-06P	$\phi 6$	6.5	1.0	2.8	5.5	5.52	<3
SLSQ-06B-08P	$\phi 6$	8.4	1.0	2.3	7.6	7.36	<3
SLSQ-06B-10P	$\phi 6$	10.4	1.0	2.0	9.6	9.20	<3
SLSQ-06B-12P	$\phi 6$	12.3	1.0	1.8	11.7	11.04	<3
SLSQ-06B-15P	$\phi 6$	15.3	1.0	1.7	14.7	13.80	<3
SLSQ-06B-20P	$\phi 6$	20.3	1.0	1.5	19.7	18.40	<3
SLSQ-06B-25P	$\phi 6$	25.2	1.0	1.4	24.8	23.00	<3
SLSQ-06B-30P	$\phi 6$	30.2	1.0	1.3	29.8	27.60	<3

Compatible Optic Mounts

LHF-50.8S, -60AS, -80, -100 / MLH-10, -15

Synthetic fused silica $\phi 7 - \phi 25$

Part Number	Diameter ϕD [mm]	Focal length f [mm]	Edge thickness t_e [mm]	Center thickness t_c [mm]	Back focal length f_b [mm]	Radius of curvature r [mm]	Centration [']
SLSQ-07B-08P	$\phi 7$	8.7	2.1	3.9	7.3	7.36	<3
SLSQ-07B-10P	$\phi 7$	10.6	1.9	3.3	9.4	9.20	<3
SLSQ-07B-12P	$\phi 7$	12.5	1.9	3.0	11.5	11.04	<3
SLSQ-07B-15P	$\phi 7$	15.5	1.8	2.7	14.5	13.80	<3
SLSQ-07B-20P	$\phi 7$	20.4	1.7	2.4	19.6	18.40	<3
SLSQ-07B-25P	$\phi 7$	25.4	1.7	2.2	24.6	23.00	<3
SLSQ-07B-30P	$\phi 7$	30.4	1.6	2.1	29.6	27.60	<3
SLSQ-07B-40P	$\phi 7$	40.3	1.6	1.9	39.7	36.80	<3
SLSQ-07B-50P	$\phi 7$	50.3	1.6	1.8	49.7	46.00	<3
SLSQ-08B-08P	$\phi 8$	8.7	1.5	3.9	7.3	7.36	<3
SLSQ-08B-10P	$\phi 8$	10.6	1.5	3.3	9.4	9.20	<3
SLSQ-08B-12P	$\phi 8$	12.5	1.5	3.0	11.5	11.04	<3
SLSQ-08B-15P	$\phi 8$	15.5	1.5	2.7	14.5	13.80	<3
SLSQ-08B-20P	$\phi 8$	20.4	1.5	2.4	19.6	18.40	<3
SLSQ-08B-25P	$\phi 8$	25.4	1.5	2.2	24.6	23.00	<3
SLSQ-08B-30P	$\phi 8$	30.4	1.5	2.1	29.6	27.60	<3
SLSQ-08B-40P	$\phi 8$	40.3	1.5	1.9	39.7	36.80	<3
SLSQ-08B-50P	$\phi 8$	50.3	1.5	1.8	49.7	46.00	<3
SLSQ-10B-10P	$\phi 10$	10.9	2.0	5.0	9.1	9.20	<1
SLSQ-10B-15P	$\phi 10$	15.7	2.0	3.9	14.3	13.80	<1
SLSQ-10B-20P	$\phi 10$	20.6	2.0	3.4	19.4	18.40	<1
SLSQ-10B-25P	$\phi 10$	25.5	2.0	3.1	24.5	23.00	<1
SLSQ-10B-30P	$\phi 10$	30.5	2.0	2.9	29.5	27.60	<1
SLSQ-10B-40P	$\phi 10$	40.5	2.0	2.7	39.5	36.80	<1
SLSQ-10B-50P	$\phi 10$	50.4	2.0	2.5	49.6	46.00	<1
SLSQ-10B-60P	$\phi 10$	60.4	2.0	2.5	59.6	55.20	<1
SLSQ-10B-70P	$\phi 10$	70.4	2.0	2.4	69.6	64.40	<1
SLSQ-10B-80P	$\phi 10$	80.4	2.0	2.3	79.6	73.60	<1
SLSQ-10B-90P	$\phi 10$	90.4	2.0	2.3	89.6	82.80	<1
SLSQ-10B-100P	$\phi 10$	100.4	2.0	2.3	99.6	92.00	<1
SLSQ-15B-15P	$\phi 15$	16.2	2.0	6.4	13.8	13.80	<1
SLSQ-15B-20P	$\phi 15$	20.9	2.0	5.2	19.1	18.40	<1
SLSQ-15B-25P	$\phi 15$	25.8	2.0	4.5	24.2	23.00	<1
SLSQ-15B-30P	$\phi 15$	30.7	2.0	4.1	29.3	27.60	<1
SLSQ-15B-40P	$\phi 15$	40.6	2.0	3.5	39.4	36.80	<1
SLSQ-15B-50P	$\phi 15$	50.6	2.0	3.2	49.4	46.00	<1
SLSQ-15B-60P	$\phi 15$	60.5	2.0	3.0	59.5	55.20	<1
SLSQ-15B-70P	$\phi 15$	70.5	2.0	2.9	69.5	64.40	<1
SLSQ-15B-80P	$\phi 15$	80.5	2.0	2.8	79.5	73.60	<1
SLSQ-15B-90P	$\phi 15$	90.5	2.0	2.7	89.5	82.80	<1
SLSQ-15B-100P	$\phi 15$	100.5	2.0	2.6	99.6	92.00	<1
SLSQ-20B-20P	$\phi 20$	21.5	2.0	7.9	18.5	18.40	<1
SLSQ-20B-25P	$\phi 20$	26.2	2.0	6.6	23.8	23.00	<1
SLSQ-20B-30P	$\phi 20$	31.0	2.0	5.8	29.0	27.60	<1
SLSQ-20B-40P	$\phi 20$	40.8	2.0	4.8	39.2	36.80	<1
SLSQ-20B-50P	$\phi 20$	50.7	2.0	4.2	49.3	46.00	<1
SLSQ-20B-60P	$\phi 20$	60.7	2.0	3.8	59.3	55.20	<1
SLSQ-20B-70P	$\phi 20$	70.6	2.0	3.6	69.4	64.40	<1
SLSQ-20B-80P	$\phi 20$	80.6	2.0	3.4	79.4	73.60	<1
SLSQ-20B-90P	$\phi 20$	90.6	2.0	3.2	89.4	82.80	<1
SLSQ-20B-100P	$\phi 20$	100.5	2.0	3.1	99.5	92.00	<1
SLSQ-20B-120P	$\phi 20$	120.5	2.0	2.9	119.5	110.40	<1
SLSQ-20B-150P	$\phi 20$	150.5	2.0	2.7	149.5	138.00	<1
SLSQ-25B-25P	$\phi 25$	26.7	2.0	9.4	23.3	23.00	<1
SLSQ-25B-30P	$\phi 25$	31.4	2.0	8.0	28.6	27.60	<1
SLSQ-25B-35P	$\phi 25$	36.3	2.0	7.1	33.7	32.20	<1
SLSQ-25B-40P	$\phi 25$	41.1	2.0	6.4	38.9	36.80	<1
SLSQ-25B-50P	$\phi 25$	51.0	2.0	5.5	49.0	46.00	<1
SLSQ-25B-60P	$\phi 25$	60.8	2.0	4.9	59.2	55.20	<1
SLSQ-25B-70P	$\phi 25$	70.8	2.0	4.5	69.2	64.40	<1
SLSQ-25B-80P	$\phi 25$	80.7	2.0	4.1	79.3	73.60	<1
SLSQ-25B-90P	$\phi 25$	90.7	2.0	3.9	89.3	82.80	<1
SLSQ-25B-100P	$\phi 25$	100.6	2.0	3.7	99.4	92.00	<1
SLSQ-25B-120P	$\phi 25$	120.6	2.0	3.4	119.4	110.40	<1
SLSQ-25B-150P	$\phi 25$	150.5	2.0	3.1	149.5	138.00	<1
SLSQ-25B-170P	$\phi 25$	170.5	2.0	3.0	169.5	156.40	<1
SLSQ-25B-200P	$\phi 25$	200.5	2.0	2.9	199.5	184.00	<1

Compatible Optic Mounts

LHF-10S, -15S, -20S, -25S / MLH-10, -15

Application
SystemsOptics &
Optical
CoatingsOpto-
Mechanics

Bases

Manual
StagesActuators &
AdjustersMotorized
StagesLight Sources &
Laser Safety

Index

Guide

Mirrors

Beamsplitters

Polarizers

Lenses

Multi-Element Optics

Filters

Prisms

Substrates/Windows

Optical Data

Maintenance

Selection Guide

Plano Convex
Lenses
Plano Concave
Lenses

Biconvex Lenses

Biconcave Lenses

Kit

Reasonable Lens

Cylindrical

Others

Biconvex Lenses | SLB-B-P/SLSQ-B-P

Catalog Code W3059

Synthetic fused silica $\phi 25.4 - \phi 50.8$							
Part Number	Diameter ϕD [mm]	Focal length f [mm]	Edge thickness t_e [mm]	Center thickness t_c [mm]	Back focal length f_b [mm]	Radius of curvature r [mm]	Centration [']
SLSQ-25.4B-25P	$\phi 25.4$	26.7	1.8	9.4	23.3	23.00	<1
SLSQ-25.4B-30P	$\phi 25.4$	31.4	1.8	8.0	28.5	27.60	<1
SLSQ-25.4B-35P	$\phi 25.4$	36.3	1.9	7.1	33.8	32.20	<1
SLSQ-25.4B-40P	$\phi 25.4$	41.1	1.9	6.4	38.8	36.80	<1
SLSQ-25.4B-50P	$\phi 25.4$	51.0	1.9	5.5	49.1	46.00	<1
SLSQ-25.4B-60P	$\phi 25.4$	60.9	1.9	4.9	59.0	55.20	<1
SLSQ-25.4B-70P	$\phi 25.4$	70.8	1.9	4.4	69.1	64.40	<1
SLSQ-25.4B-80P	$\phi 25.4$	80.7	1.9	4.1	79.1	73.60	<1
SLSQ-25.4B-90P	$\phi 25.4$	90.7	1.9	3.9	89.2	82.80	<1
SLSQ-25.4B-100P	$\phi 25.4$	100.6	1.9	3.7	99.2	92.00	<1
SLSQ-25.4B-150P	$\phi 25.4$	150.5	1.9	3.1	149.3	138.00	<1
SLSQ-25.4B-200P	$\phi 25.4$	200.5	2.0	2.9	199.4	184.00	<1
SLSQ-30B-30P	$\phi 30$	32.0	2.0	10.9	28.0	27.60	<1
SLSQ-30B-35P	$\phi 30$	36.7	2.0	9.4	33.3	32.20	<1
SLSQ-30B-40P	$\phi 30$	41.5	2.0	8.4	38.5	36.80	<1
SLSQ-30B-50P	$\phi 30$	51.2	2.0	7.0	48.8	46.00	<1
SLSQ-30B-60P	$\phi 30$	61.1	2.0	6.2	58.9	55.20	<1
SLSQ-30B-70P	$\phi 30$	71.0	2.0	5.5	69.0	64.40	<1
SLSQ-30B-80P	$\phi 30$	80.9	2.0	5.1	79.1	73.60	<1
SLSQ-30B-90P	$\phi 30$	90.8	2.0	4.7	89.2	82.80	<1
SLSQ-30B-100P	$\phi 30$	100.8	2.0	4.5	99.2	92.00	<1
SLSQ-30B-120P	$\phi 30$	120.7	2.0	4.0	119.3	110.40	<1
SLSQ-30B-150P	$\phi 30$	150.6	2.0	3.6	149.4	138.00	<1
SLSQ-30B-170P	$\phi 30$	170.6	2.0	3.4	169.4	156.40	<1
SLSQ-30B-200P	$\phi 30$	200.6	2.0	3.2	199.4	184.00	<1
SLSQ-30B-220P	$\phi 30$	220.5	2.0	3.1	219.5	202.40	<1
SLSQ-30B-250P	$\phi 30$	250.5	2.0	3.0	249.5	230.00	<1
SLSQ-40B-40P	$\phi 40$	42.5	2.0	13.8	37.5	36.80	<1
SLSQ-40B-50P	$\phi 40$	52.0	2.0	11.2	48.0	46.00	<1
SLSQ-40B-60P	$\phi 40$	61.7	2.0	9.5	58.3	55.20	<1
SLSQ-40B-70P	$\phi 40$	71.5	2.0	8.4	68.5	64.40	<1
SLSQ-40B-80P	$\phi 40$	81.3	2.0	7.5	78.7	73.60	<1
SLSQ-40B-90P	$\phi 40$	91.2	2.0	6.9	88.8	82.80	<1
SLSQ-40B-100P	$\phi 40$	101.1	2.0	6.4	98.9	92.00	<1
SLSQ-40B-120P	$\phi 40$	121.0	2.0	5.7	119.0	110.40	<1
SLSQ-40B-150P	$\phi 40$	150.8	2.0	4.9	149.2	138.00	<1
SLSQ-40B-170P	$\phi 40$	170.8	2.0	4.6	169.2	156.40	<1
SLSQ-40B-200P	$\phi 40$	200.7	2.0	4.2	199.3	184.00	<1
SLSQ-40B-220P	$\phi 40$	220.7	2.0	4.0	219.3	202.40	<1
SLSQ-40B-250P	$\phi 40$	250.6	2.0	3.7	249.4	230.00	<1
SLSQ-50B-50P	$\phi 50$	53.2	3.0	17.8	46.8	46.00	<1
SLSQ-50B-60P	$\phi 50$	62.7	3.0	15.0	57.3	55.20	<1
SLSQ-50B-70P	$\phi 50$	72.3	3.0	13.1	67.7	64.40	<1
SLSQ-50B-80P	$\phi 50$	82.1	3.0	11.8	77.9	73.60	<1
SLSQ-50B-90P	$\phi 50$	91.9	3.0	10.7	88.1	82.80	<1
SLSQ-50B-100P	$\phi 50$	101.7	3.0	9.9	98.3	92.00	<1
SLSQ-50B-120P	$\phi 50$	121.5	3.0	8.7	118.5	110.40	<1
SLSQ-50B-150P	$\phi 50$	151.3	3.0	7.6	148.7	138.00	<1
SLSQ-50B-170P	$\phi 50$	171.2	3.0	7.0	168.8	156.40	<1
SLSQ-50B-200P	$\phi 50$	201.1	3.0	6.4	198.9	184.00	<1
SLSQ-50B-220P	$\phi 50$	221.0	3.0	6.1	219.0	202.40	<1
SLSQ-50B-250P	$\phi 50$	251.0	3.0	5.7	249.0	230.00	<1
SLSQ-50B-300P	$\phi 50$	300.9	3.0	5.3	299.1	276.00	<1
SLSQ-50.8B-50P	$\phi 50.8$	53.2	2.5	17.8	46.7	46.00	<1
SLSQ-50.8B-60P	$\phi 50.8$	62.7	2.6	15.0	57.3	55.20	<1
SLSQ-50.8B-70P	$\phi 50.8$	72.3	2.7	13.1	67.7	64.40	<1
SLSQ-50.8B-80P	$\phi 50.8$	82.1	2.8	11.8	78.0	73.60	<1
SLSQ-50.8B-90P	$\phi 50.8$	91.9	2.7	10.7	87.7	82.80	<1
SLSQ-50.8B-100P	$\phi 50.8$	101.7	2.7	9.9	98.3	92.00	<1
SLSQ-50.8B-120P	$\phi 50.8$	121.5	2.8	8.7	118.5	110.40	<1
SLSQ-50.8B-150P	$\phi 50.8$	151.3	2.9	7.6	148.7	138.00	<1
SLSQ-50.8B-200P	$\phi 50.8$	201.1	2.9	6.4	198.9	184.00	<1
SLSQ-50.8B-250P	$\phi 50.8$	251.0	3.0	5.8	249.0	230.00	<1
SLSQ-50.8B-300P	$\phi 50.8$	300.9	3.0	5.3	298.8	276.00	<1

Compatible Optic Mounts


LHF-25.4S, -30S, -40S, -50S, -50.8S

These biconcave lenses are used when a very high negative power is required. They can be used in a multi-element system or alone to produce a diverging cone or virtual image. Sharpe edges, which are common in negative lenses, are removed by beveling to reduce the likelihood of chipping.

- There are two types of biconvex lenses available; BK7 for use in visible range to infrared wavelength range and synthetic fused silica for wavelengths less than 350nm ultraviolet light.
- Consult our Sales Division for anti-reflection coatings suitable for your application.
- Our lenses are listed by outside diameter and focal length to assist your selection according to required specifications.




Schematic



Outline Drawing

(in mm)



How to specify the anti-reflection coating

In case of specifying a anti-reflection coating 633nm – 1064nm to near infrared lens of SLB-50.8B-200N.

⇒ SLB-50.8B-200NIR1

Type of AR Coat	Part Number	Wavelength Range [nm]	Transmittance [%]
Visible range	SLB-50.8B-200NM	400 – 700	> Average 99
Near-infrared	SLB-50.8B-200NIR1	633 – 1064	> Average 98.5
Infrared	SLB-50.8B-200NIR2	750 – 1550	> Average 98.5

! Part of the above is an example of if you want to coat anti-reflective coating on the lens of the SLB-50.8B-200N.

! Anti-reflection coating can be available to the lens of all of SLB.

Specifications

Material	SLB: BK7 SLSQ: Synthetic fused silica
Design wavelength	546.1nm
Refractive index	BK7: $n_d=1.519$ Synthetic fused silica: $n_d=1.460$
Coating	Uncoated: the end of the part number 'N' Anti-reflection coating: the end of the part number 'NM', 'NIR1', 'NIR2'
Laser Damage Threshold	Anti-reflection coating: $4J/cm^2$ Laser pulse with 10ns, repetition frequency 20Hz
Clear aperture	90% of actual aperture: Uncoated 85% of actual aperture: with coating
Surface Quality (Scratch-Dig)	20-10

Guide


- ▶ Lenses are available in a large selection and in custom sizes and focal lengths.
- ▶ In addition to our standard coating we offer custom anti-reflective coating at specific wavelengths.

Attention

- ▶ When a concave lens is used in combination with a convex lens it will be able to converge the light and can projected a suitable image.
- ▶ The biconvex spherical lens has chromatic aberration, and the focal length will vary depending on the wavelength. Please check the "wavelength characteristic of the focal length data" on the Web for the focal lengths of each wavelength. [WEB Reference](#) [Catalog Code](#) W3060
- ▶ Transmissions losses due to reflection off the front and rear surfaces of the lens can be minimized by coating the surfaces. Consult our Sales Team for anti-reflection coatings suitable for your application.
- ▶ The outer edge of the concave side is chamfered and the result is possibility that the lens may have a smaller edge thickness for this design.

Typical Transmittance Data

T: Transmission



Synthetic fused silica $\phi 10 - \phi 50.8$

Part Number	Diameter ϕD [mm]	Focal length f [mm]	Edge thickness t_e [mm]	Center thickness t_c [mm]	Back focal length f_b [mm]	Radius of curvature r [mm]	Centration [']
SLSQ-10B-10N	$\phi 10$	-9.7	5.0	2.0	-10.3	9.20	<1
SLSQ-10B-15N	$\phi 10$	-14.7	3.9	2.0	-15.3	13.80	<1
SLSQ-10B-20N	$\phi 10$	-19.7	3.4	2.0	-20.3	18.40	<1
SLSQ-10B-25N	$\phi 10$	-24.7	3.1	2.0	-25.3	23.00	<1
SLSQ-10B-30N	$\phi 10$	-29.7	2.9	2.0	-30.3	27.60	<1
SLSQ-10B-40N	$\phi 10$	-39.7	2.7	2.0	-40.3	36.80	<1
SLSQ-10B-50N	$\phi 10$	-49.7	2.5	2.0	-50.3	46.00	<1
SLSQ-15B-15N	$\phi 15$	-14.7	6.4	2.0	-15.3	13.80	<1
SLSQ-15B-20N	$\phi 15$	-19.7	5.2	2.0	-20.3	18.40	<1
SLSQ-15B-25N	$\phi 15$	-24.7	4.5	2.0	-25.3	23.00	<1
SLSQ-15B-30N	$\phi 15$	-29.7	4.1	2.0	-30.3	27.60	<1
SLSQ-15B-40N	$\phi 15$	-39.7	3.5	2.0	-40.3	36.80	<1
SLSQ-15B-50N	$\phi 15$	-49.7	3.2	2.0	-50.3	46.00	<1
SLSQ-20B-20N	$\phi 20$	-19.7	7.9	2.0	-20.3	18.40	<1
SLSQ-20B-25N	$\phi 20$	-24.7	6.6	2.0	-25.3	23.00	<1
SLSQ-20B-30N	$\phi 20$	-29.7	5.8	2.0	-30.3	27.60	<1
SLSQ-20B-40N	$\phi 20$	-39.7	4.8	2.0	-40.3	36.80	<1
SLSQ-20B-50N	$\phi 20$	-49.7	4.2	2.0	-50.3	46.00	<1
SLSQ-25B-25N	$\phi 25$	-24.7	9.4	2.0	-25.3	23.00	<1
SLSQ-25B-30N	$\phi 25$	-29.7	8.0	2.0	-30.3	27.60	<1
SLSQ-25B-35N	$\phi 25$	-34.7	7.1	2.0	-35.3	32.20	<1
SLSQ-25B-40N	$\phi 25$	-39.7	6.4	2.0	-40.3	36.80	<1
SLSQ-25B-50N	$\phi 25$	-49.7	5.5	2.0	-50.3	46.00	<1
SLSQ-25B-60N	$\phi 25$	-59.7	4.9	2.0	-60.3	55.20	<1
SLSQ-25B-70N	$\phi 25$	-69.7	4.5	2.0	-70.3	64.40	<1
SLSQ-25B-80N	$\phi 25$	-79.7	4.1	2.0	-80.3	73.60	<1
SLSQ-25B-90N	$\phi 25$	-89.7	3.9	2.0	-90.3	82.80	<1
SLSQ-25B-100N	$\phi 25$	-99.7	3.7	2.0	-100.3	92.00	<1
SLSQ-25.4B-25N	$\phi 25.4$	-24.7	9.6	2.0	-25.4	23.00	<1
SLSQ-25.4B-30N	$\phi 25.4$	-29.7	8.2	2.0	-30.4	27.60	<1
SLSQ-25.4B-40N	$\phi 25.4$	-39.7	6.5	2.0	-40.4	36.80	<1
SLSQ-25.4B-50N	$\phi 25.4$	-49.7	5.6	2.0	-50.4	46.00	<1
SLSQ-25.4B-60N	$\phi 25.4$	-59.7	5.0	2.0	-60.4	55.20	<1
SLSQ-25.4B-70N	$\phi 25.4$	-69.7	4.5	2.0	-70.4	64.40	<1
SLSQ-25.4B-80N	$\phi 25.4$	-79.7	4.2	2.0	-80.4	73.60	<1
SLSQ-25.4B-90N	$\phi 25.4$	-89.7	4.0	2.0	-90.4	82.80	<1
SLSQ-25.4B-100N	$\phi 25.4$	-99.7	3.8	2.0	-100.4	92.00	<1
SLSQ-25.4B-150N	$\phi 25.4$	-149.7	3.2	2.0	-150.4	138.00	<1
SLSQ-25.4B-200N	$\phi 25.4$	-199.7	2.9	2.0	-200.4	184.00	<1
SLSQ-30B-30N	$\phi 30$	-29.7	10.9	2.0	-30.3	27.60	<1
SLSQ-30B-35N	$\phi 30$	-34.7	9.4	2.0	-35.3	32.20	<1
SLSQ-30B-40N	$\phi 30$	-39.7	8.4	2.0	-40.3	36.80	<1
SLSQ-30B-50N	$\phi 30$	-49.7	7.0	2.0	-50.3	46.00	<1
SLSQ-30B-60N	$\phi 30$	-59.7	6.2	2.0	-60.3	55.20	<1
SLSQ-30B-70N	$\phi 30$	-69.7	5.5	2.0	-70.3	64.40	<1
SLSQ-30B-80N	$\phi 30$	-79.7	5.1	2.0	-80.3	73.60	<1
SLSQ-30B-90N	$\phi 30$	-89.7	4.7	2.0	-90.3	82.80	<1
SLSQ-30B-100N	$\phi 30$	-99.7	4.5	2.0	-100.3	92.00	<1
SLSQ-40B-40N	$\phi 40$	-39.7	13.8	2.0	-40.3	36.80	<1
SLSQ-40B-50N	$\phi 40$	-49.7	11.2	2.0	-50.3	46.00	<1
SLSQ-40B-60N	$\phi 40$	-59.7	9.5	2.0	-60.3	55.20	<1
SLSQ-40B-70N	$\phi 40$	-69.7	8.4	2.0	-70.3	64.40	<1
SLSQ-40B-80N	$\phi 40$	-79.7	7.5	2.0	-80.3	73.60	<1
SLSQ-40B-90N	$\phi 40$	-89.7	6.9	2.0	-90.3	82.80	<1
SLSQ-40B-100N	$\phi 40$	-99.7	6.4	2.0	-100.3	92.00	<1
SLSQ-50B-50N	$\phi 50$	-49.5	17.8	3.0	-50.5	46.00	<1
SLSQ-50B-60N	$\phi 50$	-59.5	15.0	3.0	-60.5	55.20	<1
SLSQ-50B-70N	$\phi 50$	-69.5	13.1	3.0	-70.5	64.40	<1
SLSQ-50B-80N	$\phi 50$	-79.5	11.8	3.0	-80.5	73.60	<1
SLSQ-50B-90N	$\phi 50$	-89.5	10.7	3.0	-90.5	82.80	<1
SLSQ-50B-100N	$\phi 50$	-99.5	9.9	3.0	-100.5	92.00	<1
SLSQ-50.8B-50N	$\phi 50.8$	-49.5	18.3	3.0	-50.5	46.00	<1
SLSQ-50.8B-60N	$\phi 50.8$	-59.5	15.4	3.0	-60.5	55.20	<1
SLSQ-50.8B-70N	$\phi 50.8$	-69.5	13.4	3.0	-70.5	64.40	<1
SLSQ-50.8B-80N	$\phi 50.8$	-79.5	12.0	3.0	-80.5	73.60	<1
SLSQ-50.8B-90N	$\phi 50.8$	-89.5	11.0	3.0	-90.5	82.80	<1
SLSQ-50.8B-100N	$\phi 50.8$	-99.5	10.2	3.0	-100.5	92.00	<1
SLSQ-50.8B-150N	$\phi 50.8$	-149.5	7.7	3.0	-150.5	138.00	<1
SLSQ-50.8B-200N	$\phi 50.8$	-199.5	6.5	3.0	-200.5	184.00	<1
SLSQ-50.8B-250N	$\phi 50.8$	-249.5	5.8	3.0	-250.5	230.00	<1
SLSQ-50.8B-300N	$\phi 50.8$	-299.5	5.3	3.0	-300.5	276.00	<1

Compatible Optic Mounts

LHF-10S, -15S, -20S, -25S, -25.4S, -30S, -40S, -50S, -50.8S / MLH-10, -15

Application
SystemsOptics &
Optical
CoatingsOpto-
Mechanics

Bases

Manual
StagesActuators &
AdjustersMotorized
StagesLight Sources &
Laser Safety

Index

Guide

Mirrors

Beamsplitters

Polarizers

Lenses

Multi-Element Optics

Filters

Prisms

Substrates/Windows

Optical Data

Maintenance

Selection Guide

Plano Convex

Lenses

Plano Concave

Lenses

Biconvex Lenses

Biconcave Lenses

Kit

Reasonable Lens

Cylindrical

Others

$\phi 25.4$ (BK7) Lens Kit | SLB-25.4-SET

RoHS

Catalog Code

W3194

Application Systems

Optics & Optical Coatings

Opto-Mechanics

Bases

Manual Stages

Actuators & Adjusters

Motorized Stages

Light Sources & Laser Safety

Index

Guide

Mirrors

Beamsplitters

Polarizers

Lenses

Multi-Element Optics

Filters

Prisms

Substrates/Windows

Optical Data

Maintenance

Selection Guide

Plano Convex Lenses

Plano Concave Lenses

Biconvex Lenses

Biconcave Lenses

Kit

Reasonable Lens

Cylindrical

Others

This is a perfect lens kit suitable for use in many areas from teaching materials to research and development. The special Lens Kit comes with 27 lenses that are commonly used including plano convex (9 Focal lengths), biconvex (6 Focal lengths), plano concave (6 Focal lengths) and biconcave (6 Focal lengths).

- Outer diameter of the lenses are all 25.4mm diameter.
- Focal length are provided in a wide range of -200 - 1,000 mm.
- A special case made of wood is provided for convenient storage.



Specifications

Part Number	SLB-25.4-SET
Material	BK7
Design Wavelength	546.1nm
Refractive Index	$n_d = 1.519$
Coating	Uncoated
Clear Aperture	90% of the diameter
Surface Quality (Scratch-Dig)	20-10

Components							
Shape of Lenses	Part Number	Diameter ϕD [mm]	Focal length f [mm]	Edge thickness t_e [mm]	Center thickness t_c [mm]	Back focal length f_b [mm]	Centration [']
Plano Convex Lenses	SLB-25.4-30P	$\phi 25.4$	30	1.7	8.3	24.5	<1
	SLB-25.4-50P	$\phi 25.4$	50	1.9	5.2	46.6	<1
	SLB-25.4-70P	$\phi 25.4$	70	1.9	4.2	67.2	<1
	SLB-25.4-100P	$\phi 25.4$	100	1.9	3.5	97.7	<1
	SLB-25.4-150P	$\phi 25.4$	150	2.0	3.0	148.0	<1
	SLB-25.4-200P	$\phi 25.4$	200	2.0	2.8	198.2	<1
	SLB-25.4-300P	$\phi 25.4$	300	2.0	2.5	298.4	<3
	SLB-25.4-500P	$\phi 25.4$	500	2.0	2.3	498.4	<3
Biconvex Lenses	SLB-25.4-1000P	$\phi 25.4$	1000	2.0	2.2	998.5	<3
	SLB-25.4B-25P	$\phi 25.4$	26.5	1.8	8.4	23.6	<1
	SLB-25.4B-50P	$\phi 25.4$	50.8	1.9	5.1	49.2	<1
	SLB-25.4B-70P	$\phi 25.4$	70.7	1.9	4.1	69.3	<1
	SLB-25.4B-100P	$\phi 25.4$	100.6	1.9	3.5	99.4	<1
	SLB-25.4B-150P	$\phi 25.4$	150.5	2.0	3.0	149.5	<1
	SLB-25.4B-200P	$\phi 25.4$	200.5	2.0	2.8	199.6	<1
Plano Concave Lenses	SLB-25.4-30N	$\phi 25.4$	-30	8.6	2.0	-31.3	<1
	SLB-25.4-50N	$\phi 25.4$	-50	5.3	2.0	-51.3	<1
	SLB-25.4-70N	$\phi 25.4$	-70	4.3	2.0	-71.3	<1
	SLB-25.4-100N	$\phi 25.4$	-100	3.6	2.0	-101.3	<1
	SLB-25.4-150N	$\phi 25.4$	-150	3.0	2.0	-151.3	<1
	SLB-25.4-200N	$\phi 25.4$	-200	2.8	2.0	-201.3	<1
Biconcave Lenses	SLB-25.4B-25N	$\phi 25.4$	-24.7	8.6	2.0	-25.4	<1
	SLB-25.4B-50N	$\phi 25.4$	-49.7	5.2	2.0	-50.4	<1
	SLB-25.4B-70N	$\phi 25.4$	-69.7	4.2	2.0	-70.4	<1
	SLB-25.4B-100N	$\phi 25.4$	-99.7	3.6	2.0	-100.4	<1
	SLB-25.4B-150N	$\phi 25.4$	-149.7	3.0	2.0	-150.4	<1
	SLB-25.4B-200N	$\phi 25.4$	-199.7	2.8	2.0	-200.4	<1

Contact sheet for Special Order for spherical lens

☐ Estimation ☐ Order

Date

☐ To: Sigma Koki Co., Ltd. **FAX +81-3-5638-6550**

Affiliation (Organization Name)					
Department					
TEL		FAX		E-mail	
Country/Address					
Name & Designation		(Tentative name is okay)			
Drawing Number		Estimate		☐ Yes: by Date ☐ No	
Desired Delivery Date		Budget		JP Yen	
Specification of lens	Quantity				
	Selected from standard product	Part Number			If you are using a spherical lens of standard product, please fill in the product number.
	Custom-made	Shape	☐ Plano Convex ☐ Biconvex ☐ Plano Concave ☐ Biconcave ☐ Meniscus ☐ Other ()		
		Material	☐ BK7 ☐ Synthetic fused silica ☐ Synthetic fused silica for Excimer Laser ($\lambda =$)		
		Focal length	f =		mm
		Diameter	Diameter		
			Center Thickness	tc =	
	Design wavelength	$\lambda =$		nm	
Specifications of Coating	Presence or absence of the coating	☐ Non ☐ Single-layer anti-reflection coating ☐ Broadband multi-layer anti-reflection coating ☐ Other ()			
	Type of AR (If required)				
Specifications of Light Source Used	Wavelength Range	$\lambda =$		Type	
	Output or Energy	W		Beam Size	mm
		J	Pulse width	s	Repetition frequency
Incident angle	$\theta =$ °				
Other	* Write more detailed specifications here. (Rough illustration is acceptable.)				

Sigma Koki Co., Ltd.

General Catalog 02

Application Systems

Optics & Optical Coatings

Opto-Mechanics

Bases

Manual Stages

Actuators & Adjusters

Motorized Stages

Light Sources & Laser Safety

Index

Guide

Mirrors

Beamsplitters

Polarizers

Lenses

Multi-Element Optics

Filters

Prisms

Substrates/Windows

Optical Data

Maintenance

Selection Guide

Plano Convex Lenses

Plano Concave Lenses

Biconvex Lenses

Biconcave Lenses

Kit

Reasonable Lens

Cylindrical

Others

Reasonable Plano Convex Lens

S-SLB-P/S-SLB-B-P

RoHS


This lower cost product offering of Plano Convex Lenses has only minimal reduction in quality and is perfect for most applications.

It can be used in an optical systems such as observation or lighting applications when the higher surface quality Plano Convex Lens (SLB-P) is not required.




Schematic

Plano Convex



Biconvex



- It has the same specification of Plano Convex Lens (SLB-P) except the surface quality and is ideal for experiments and applications where high-precision is not required.
- There are two types of lens offer, a Plano convex lens with low spherical aberration and a biconvex lens that is used to shorten the focal length.
- In addition to uncoated products, there are three types of anti-reflection coating for visible, near-infrared, and infrared.

Specifications

Material	BK7
Design Wavelength	546.1nm
Refractive Index	$n_e=1.519$
Centration	<3'
Coating	Uncoated: the end of the part number 'P' Anti-reflection coating: the end of the part number 'PM', 'PIR1', 'PIR2'
Laser Damage Threshold	Anti-reflection coating: $4\text{J}/\text{cm}^2$ Laser pulse with 10ns, repetition frequency 20Hz
Clear Aperture	90% of actual aperture: Uncoated 85% of actual aperture: with coating, $\phi 10 \leq D$ 83% of actual aperture: with coating, $D < \phi 10$
Surface Quality (Scratch-Dig)	60-40


Attention

- ▶ Plano convex lens and biconvex spherical lens have a chromatic aberration, and the focal length will vary depending on the wavelength.
- ▶ Please check the "wavelength characteristic of the focal length data" on the Web for the focal lengths of each wavelength.
- ▶ WEB Reference **Catalog Code** W3041
- ▶ Transmissions losses due to reflection off the front and rear surfaces of the lens can be minimized by coating the surfaces. Consult our Sales Division for anti-reflection coatings suitable for your application.

Outline Drawing


(in mm)

Plano Convex



- Tolerance
- Diameter
 - $\phi 60$ or less $\phi D_{-0.05}^{+0.05}$
 - $\phi 80$ $\phi D_{-0.15}^{+0.15}$
 - $\phi 100$ $\phi D_{-0.2}^{+0.2}$
- Focal length
 - $(\phi 10 \leq \phi D)$ $\pm 1\%$
 - $(\phi D < \phi 10)$ $\pm 2\%$
- Thickness $tc \pm 0.15$

Biconvex



- Tolerance
- Diameter
 - $\phi 60$ or less $\phi D_{-0.05}^{+0.05}$
 - $\phi 80$ $\phi D_{-0.15}^{+0.15}$
 - $\phi 100$ $\phi D_{-0.2}^{+0.2}$
- Focal length
 - $(\phi 10 \leq \phi D)$ $\pm 1\%$
 - $(\phi D < \phi 10)$ $\pm 2\%$
- Thickness $tc \pm 0.15$

How to specify the anti-reflection coating

In case of specifying a anti-reflection coating 633nm – 1064nm to near infrared lens of S-SLB-100-500P.
⇒ S-SLB-100-500PIR1


Type of AR Coat	Part Number	Wavelength Range [nm]	Transmittance [%]
Visible range	S-SLB-100-500PM	400 – 700	> Average 99
Near-infrared	S-SLB-100-500PIR1	633 – 1064	> Average 98.5
Infrared	S-SLB-100-500PIR2	750 – 1550	> Average 98.5

⚠ Part of the above is an example of if you want to coat anti-reflective coating on the lens of the S-SLB-100-500P.

⚠ Anti-reflection coating can be available to the lens of all of S-SLB.

Typical Transmittance Data

T: Transmission



Plano Convex Lens $\phi 6 - \phi 25$

Uncoated	How to specify the anti-reflection coating			Diameter ϕD [mm]	Focal length f [mm]	Edge thickness t_e [mm]	Center thickness t_c [mm]	Back focal length f_b [mm]	Radius of curvature r [mm]
Part Number	Visible 400 - 700nm	Near-infrared 633 - 1064nm	Infrared 750 - 1550nm						
S-SLB-06-08P	M	IR1	IR2	$\phi 6$	8	1.0	2.3	6.5	4.15
S-SLB-06-10P	M	IR1	IR2	$\phi 6$	10	1.0	2.0	8.7	5.19
S-SLB-07-20P	M	IR1	IR2	$\phi 7$	20	1.7	2.3	18.5	10.38
S-SLB-07-40P	M	IR1	IR2	$\phi 7$	40	1.6	1.9	38.8	20.76
S-SLB-08-10P	M	IR1	IR2	$\phi 8$	10	1.5	3.4	7.8	5.19
S-SLB-08-15P	M	IR1	IR2	$\phi 8$	15	1.5	2.6	13.3	7.79
S-SLB-08-25P	M	IR1	IR2	$\phi 8$	25	1.5	2.1	23.6	12.98
S-SLB-08-40P	M	IR1	IR2	$\phi 8$	40	1.5	1.9	38.8	20.76
S-SLB-10-15P	M	IR1	IR2	$\phi 10$	15	2.0	3.8	12.5	7.79
S-SLB-10-20P	M	IR1	IR2	$\phi 10$	20	2.0	3.3	17.8	10.38
S-SLB-10-25P	M	IR1	IR2	$\phi 10$	25	2.0	3.0	23.0	12.98
S-SLB-10-30P	M	IR1	IR2	$\phi 10$	30	2.0	2.8	28.1	15.57
S-SLB-10-40P	M	IR1	IR2	$\phi 10$	40	2.0	2.6	38.3	20.76
S-SLB-10-50P	M	IR1	IR2	$\phi 10$	50	2.0	2.5	48.4	25.95
S-SLB-10-60P	M	IR1	IR2	$\phi 10$	60	2.0	2.4	58.4	31.14
S-SLB-10-70P	M	IR1	IR2	$\phi 10$	70	2.0	2.3	68.5	36.33
S-SLB-10-100P	M	IR1	IR2	$\phi 10$	100	2.0	2.2	98.5	51.90
S-SLB-15-20P	M	IR1	IR2	$\phi 15$	20	2.0	5.2	16.6	10.38
S-SLB-15-25P	M	IR1	IR2	$\phi 15$	25	2.0	4.4	22.1	12.98
S-SLB-15-30P	M	IR1	IR2	$\phi 15$	30	2.0	3.9	27.4	15.57
S-SLB-15-40P	M	IR1	IR2	$\phi 15$	40	2.0	3.4	37.8	20.76
S-SLB-15-50P	M	IR1	IR2	$\phi 15$	50	2.0	3.1	48.0	25.95
S-SLB-15-60P	M	IR1	IR2	$\phi 15$	60	2.0	2.9	58.1	31.14
S-SLB-15-70P	M	IR1	IR2	$\phi 15$	70	2.0	2.8	68.2	36.33
S-SLB-15-80P	M	IR1	IR2	$\phi 15$	80	2.0	2.7	78.2	41.52
S-SLB-15-90P	M	IR1	IR2	$\phi 15$	90	2.0	2.6	88.3	46.71
S-SLB-15-100P	M	IR1	IR2	$\phi 15$	100	2.0	2.5	98.3	51.90
S-SLB-15-120P	M	IR1	IR2	$\phi 15$	120	2.0	2.5	118.4	62.28
S-SLB-15-150P	M	IR1	IR2	$\phi 15$	150	2.0	2.4	148.4	77.85
S-SLB-20-25P	M	IR1	IR2	$\phi 20$	25	2.0	6.7	20.6	12.98
S-SLB-20-30P	M	IR1	IR2	$\phi 20$	30	2.0	5.6	26.3	15.57
S-SLB-20-40P	M	IR1	IR2	$\phi 20$	40	2.0	4.6	37.0	20.76
S-SLB-20-50P	M	IR1	IR2	$\phi 20$	50	2.0	4.0	47.4	25.95
S-SLB-20-60P	M	IR1	IR2	$\phi 20$	60	2.0	3.6	57.6	31.14
S-SLB-20-70P	M	IR1	IR2	$\phi 20$	70	2.0	3.4	67.8	36.33
S-SLB-20-80P	M	IR1	IR2	$\phi 20$	80	2.0	3.2	77.9	41.52
S-SLB-20-90P	M	IR1	IR2	$\phi 20$	90	2.0	3.1	88.0	46.71
S-SLB-20-100P	M	IR1	IR2	$\phi 20$	100	2.0	3.0	98.0	51.90
S-SLB-20-120P	M	IR1	IR2	$\phi 20$	120	2.0	2.8	118.2	62.28
S-SLB-20-150P	M	IR1	IR2	$\phi 20$	150	2.0	2.6	148.3	77.85
S-SLB-20-170P	M	IR1	IR2	$\phi 20$	170	2.0	2.6	168.2	88.23
S-SLB-20-200P	M	IR1	IR2	$\phi 20$	200	2.0	2.5	198.4	103.80
S-SLB-25-30P	M	IR1	IR2	$\phi 25$	30	2.0	8.3	24.5	15.57
S-SLB-25-35P	M	IR1	IR2	$\phi 25$	35	2.0	7.0	30.4	18.17
S-SLB-25-40P	M	IR1	IR2	$\phi 25$	40	2.0	6.2	36.0	20.76
S-SLB-25-50P	M	IR1	IR2	$\phi 25$	50	2.0	5.2	46.6	25.95
S-SLB-25-70P	M	IR1	IR2	$\phi 25$	70	2.0	4.2	67.2	36.33
S-SLB-25-80P	M	IR1	IR2	$\phi 25$	80	2.0	3.9	77.4	41.52
S-SLB-25-90P	M	IR1	IR2	$\phi 25$	90	2.0	3.7	87.6	46.71
S-SLB-25-100P	M	IR1	IR2	$\phi 25$	100	2.0	3.5	97.7	51.90
S-SLB-25-120P	M	IR1	IR2	$\phi 25$	120	2.0	3.3	117.8	62.28
S-SLB-25-150P	M	IR1	IR2	$\phi 25$	150	2.0	3.0	148.0	77.85
S-SLB-25-200P	M	IR1	IR2	$\phi 25$	200	2.0	2.8	198.2	103.80

Compatible Optic Mounts

LHF-10S, -15S, -20S, -25S / MLH-10, -15

Application
SystemsOptics &
Optical
CoatingsOpto-
Mechanics

Bases

Manual
StagesActuators &
AdjustersMotorized
StagesLight Sources &
Laser Safety

Index

Guide

Mirrors

Beamsplitters

Polarizers

Lenses

Multi-Element Optics

Filters

Prisms

Substrates/Windows

Optical Data

Maintenance

Selection Guide

Plano Convex
Lenses
Plano Concave
Lenses

Biconvex Lenses

Biconcave Lenses

Kit

Reasonable Lens

Cylindrical

Others

Reasonable Plano Convex Lens

S-SLB-P/S-SLB-B-P

Catalog Code W3220

Plano Convex Lens $\phi 30 - \phi 100$

Uncoated	How to specify the anti-reflection coating			Diameter ϕD [mm]	Focal length f [mm]	Edge thickness t_e [mm]	Center thickness t_c [mm]	Back focal length f_b [mm]	Radius of curvature r [mm]
	Part Number	Visibe 400 – 700nm	Near-infrared 633 – 1064nm	Infrared 750 – 1550nm					
Optics & Optical Coatings	S-SLB-30-35P	M	IR1	IR2	$\phi 30$	35	2.0	9.9	28.5
	S-SLB-30-40P	M	IR1	IR2	$\phi 30$	40	2.0	8.4	34.5
	S-SLB-30-50P	M	IR1	IR2	$\phi 30$	50	2.0	6.8	45.5
	S-SLB-30-60P	M	IR1	IR2	$\phi 30$	60	2.0	5.9	56.1
	S-SLB-30-70P	M	IR1	IR2	$\phi 30$	70	2.0	5.2	66.5
Opto-Mechanics	S-SLB-30-80P	M	IR1	IR2	$\phi 30$	80	2.0	4.8	76.8
	S-SLB-30-90P	M	IR1	IR2	$\phi 30$	90	2.0	4.5	87.1
	S-SLB-30-100P	M	IR1	IR2	$\phi 30$	100	2.0	4.2	97.2
	S-SLB-30-120P	M	IR1	IR2	$\phi 30$	120	2.0	3.8	117.5
	S-SLB-30-150P	M	IR1	IR2	$\phi 30$	150	2.0	3.5	147.7
Bases	S-SLB-30-170P	M	IR1	IR2	$\phi 30$	170	2.0	3.3	167.8
	S-SLB-30-200P	M	IR1	IR2	$\phi 30$	200	2.0	3.1	198.0
	S-SLB-30-250P	M	IR1	IR2	$\phi 30$	250	2.0	2.9	248.1
	S-SLB-30-300P	M	IR1	IR2	$\phi 30$	300	2.0	2.7	298.2
	S-SLB-30-350P	M	IR1	IR2	$\phi 30$	350	2.0	2.6	348.3
Manual Stages	S-SLB-40-50P	M	IR1	IR2	$\phi 40$	50	2.0	11.4	42.5
	S-SLB-40-60P	M	IR1	IR2	$\phi 40$	60	2.0	9.3	53.9
	S-SLB-40-70P	M	IR1	IR2	$\phi 40$	70	2.0	8.0	64.7
	S-SLB-40-80P	M	IR1	IR2	$\phi 40$	80	2.0	7.1	75.3
	S-SLB-40-90P	M	IR1	IR2	$\phi 40$	90	2.0	6.5	85.7
Actuators & Adjusters	S-SLB-40-100P	M	IR1	IR2	$\phi 40$	100	2.0	6.0	96.0
	S-SLB-40-120P	M	IR1	IR2	$\phi 40$	120	2.0	5.3	116.5
	S-SLB-40-150P	M	IR1	IR2	$\phi 40$	150	2.0	4.6	147
	S-SLB-40-170P	M	IR1	IR2	$\phi 40$	170	2.0	4.3	167.2
	S-SLB-40-200P	M	IR1	IR2	$\phi 40$	200	2.0	3.9	197.4
Motoeized Stages	S-SLB-40-250P	M	IR1	IR2	$\phi 40$	250	2.0	3.6	247.7
	S-SLB-40-1000P	M	IR1	IR2	$\phi 40$	1000	2.0	2.4	998.4
	S-SLB-50-70P	M	IR1	IR2	$\phi 50$	70	3.0	13.0	61.5
	S-SLB-50-90P	M	IR1	IR2	$\phi 50$	90	3.0	10.3	83.2
	S-SLB-50-100P	M	IR1	IR2	$\phi 50$	100	3.0	9.4	93.8
Light Sources & Laser Safety	S-SLB-50-120P	M	IR1	IR2	$\phi 50$	120	3.0	8.2	114.6
	S-SLB-50-150P	M	IR1	IR2	$\phi 50$	150	3.0	7.1	145.3
	S-SLB-50-170P	M	IR1	IR2	$\phi 50$	170	3.0	6.6	165.6
	S-SLB-50-200P	M	IR1	IR2	$\phi 50$	200	3.0	6.1	196.0
	S-SLB-60-70P	M	IR1	IR2	$\phi 60$	70	3.0	18.8	57.6
Index	S-SLB-60-100P	M	IR1	IR2	$\phi 60$	100	3.0	12.5	91.7
	S-SLB-60-120P	M	IR1	IR2	$\phi 60$	120	3.0	10.7	113.0
	S-SLB-60-150P	M	IR1	IR2	$\phi 60$	150	3.0	9.0	144.1
	S-SLB-60-150P	M	IR1	IR2	$\phi 60$	150	3.0	9.0	144.1
	S-SLB-80-150P	M	IR1	IR2	$\phi 80$	150	3.0	14.1	140.8
Guide	S-SLB-80-250P	M	IR1	IR2	$\phi 80$	250	3.0	9.3	243.9
	S-SLB-100-150P	M	IR1	IR2	$\phi 100$	150	3.0	21.2	136.1
	S-SLB-100-200P	M	IR1	IR2	$\phi 100$	200	3.0	15.8	189.6
	S-SLB-100-250P	M	IR1	IR2	$\phi 100$	250	3.0	13.0	241.4
	S-SLB-100-300P	M	IR1	IR2	$\phi 100$	300	3.0	11.2	292.6
Mirrors	S-SLB-100-500P	M	IR1	IR2	$\phi 100$	500	3.0	7.9	494.8
	S-SLB-100-1000P	M	IR1	IR2	$\phi 100$	1000	3.0	5.4	996.4
Beamsplitters									
Polarizers									
Lenses									
Multi-Element Optics									
Filters									
Prisms									
Substrates/Windows									
Optical Data									
Maintenance									
Selection Guide									
Plano Convex Lenses									
Plano Concave Lenses									
Biconvex Lenses									
Biconcave Lenses									
Kit									

Compatible Optic Mounts

LHF-30S, -40S, -50S, -60AS, -80, -100

Biconvex Lens									
Uncoated	How to specify the anti-reflection coating			Diameter ϕD [mm]	Focal length f [mm]	Edge thickness t_e [mm]	Center thickness t_c [mm]	Back focal length f_b [mm]	Radius of curvature r [mm]
Part Number	Visible 400 – 700nm	Near-infrared 633 – 1064nm	Infrared 750 – 1550nm						
S-SLB-05B-08P	M	IR1	IR2	$\phi 5$	8.4	1.4	2.1	7.6	8.30
S-SLB-05B-20P	M	IR1	IR2	$\phi 5$	20.2	1.1	1.4	19.8	20.76
S-SLB-06B-06P	M	IR1	IR2	$\phi 6$	6.4	1.0	2.5	5.6	6.23
S-SLB-08B-08P	M	IR1	IR2	$\phi 8$	8.6	1.5	3.6	7.4	8.30
S-SLB-10B-10P	M	IR1	IR2	$\phi 10$	10.8	2.0	4.6	9.2	10.38
S-SLB-10B-15P	M	IR1	IR2	$\phi 10$	15.6	2.0	3.6	14.4	15.57
S-SLB-10B-20P	M	IR1	IR2	$\phi 10$	20.5	2.0	3.2	19.5	20.76
S-SLB-10B-40P	M	IR1	IR2	$\phi 10$	40.4	2.0	2.6	39.6	41.52
S-SLB-15B-15P	M	IR1	IR2	$\phi 15$	16	2.0	5.9	14.0	15.57
S-SLB-15B-20P	M	IR1	IR2	$\phi 15$	20.8	2.0	4.8	19.2	20.76
S-SLB-15B-30P	M	IR1	IR2	$\phi 15$	30.6	2.0	3.8	29.4	31.14
S-SLB-15B-40P	M	IR1	IR2	$\phi 15$	40.6	2.0	3.4	39.4	41.52
S-SLB-20B-30P	M	IR1	IR2	$\phi 20$	31	2.0	5.3	29.1	31.14
S-SLB-20B-40P	M	IR1	IR2	$\phi 20$	40.7	2.0	4.4	39.3	41.52
S-SLB-20B-50P	M	IR1	IR2	$\phi 20$	50.7	2.0	3.9	49.3	51.90
S-SLB-25B-35P	M	IR1	IR2	$\phi 25$	36.1	2.0	6.4	33.9	36.33
S-SLB-25B-50P	M	IR1	IR2	$\phi 25$	50.8	2.0	5.1	49.2	51.90
S-SLB-25B-60P	M	IR1	IR2	$\phi 25$	60.8	2.0	4.5	59.2	62.28
S-SLB-25B-70P	M	IR1	IR2	$\phi 25$	70.7	2.0	4.2	69.3	72.66
S-SLB-30B-30P	M	IR1	IR2	$\phi 30$	31.7	2.0	9.7	28.3	31.14
S-SLB-30B-40P	M	IR1	IR2	$\phi 30$	41.3	2.0	7.6	38.7	41.52
S-SLB-40B-40P	M	IR1	IR2	$\phi 40$	42.1	2.0	12.3	37.9	41.52
S-SLB-40B-50P	M	IR1	IR2	$\phi 40$	51.7	2.0	10.0	48.3	51.90
S-SLB-40B-60P	M	IR1	IR2	$\phi 40$	61.4	2.0	8.6	58.6	62.28
S-SLB-40B-100P	M	IR1	IR2	$\phi 40$	101	2.0	5.9	99.0	103.80
S-SLB-40B-150P	M	IR1	IR2	$\phi 40$	150.8	2.0	4.6	149.2	155.70
S-SLB-50B-150P	M	IR1	IR2	$\phi 50$	151.2	3.0	7.0	148.8	155.70
S-SLB-50B-200P	M	IR1	IR2	$\phi 50$	201	3.0	6.0	199.0	207.60

Compatible Optic Mounts

LHF-10S, -15S, -20S, -25S, -30S, -40S, -50S / MLH-10, -15

Application
SystemsOptics &
Optical
CoatingsOpto-
Mechanics

Bases

Manual
StagesActuators &
AdjustersMotorized
StagesLight Sources &
Laser Safety

Index

Guide

Mirrors

Beamsplitters

Polarizers

Lenses

Multi-Element Optics

Filters

Prisms

Substrates/Windows

Optical Data

Maintenance

Selection Guide

Plano Convex
Lenses
Plano Concave
Lenses

Biconvex Lenses

Biconcave Lenses

Kit

Reasonable Lens

Cylindrical

Others

Reasonable Plano Concave Lens

S-SLB-N/S-SLB-B-N

RoHS

Application
SystemsOptics &
Optical
CoatingsOpto-
Mechanics

Bases

Manual
StagesActuators &
AdjustersMotorized
StagesLight Sources &
Laser Safety

Index

Guide

Mirrors

Beamsplitters

Polarizers

Lenses

Multi-Element Optics

Filters

Prisms

Substrates/Windows

Optical Data

Maintenance

Selection Guide

Plano Convex
LensesPlano Concave
Lenses

Biconvex Lenses

Biconcave Lenses

Kit

Reasonable Lenses

Cylindrical

Others


This lower cost product offering of Plano Convex Lenses has only minimal reduction in quality and is perfect for most applications.

It can be used in an optical systems such as observation or lighting applications when the higher surface quality Plano Concave Lens (SLB-N) is not required.




Schematic

Plano Concave



Biconcave



- It has the same specification of Plano Convex Lens (SLB-N) except the surface quality and is ideal for experiments and applications where high-precision is not required.
- There are two types of lens offer, a Plano convex lens with low spherical aberration and a biconvex lens that is used to shorten the focal length.
- In addition to uncoated products, there are three types of anti-reflection coating for visible, near-infrared, and infrared.

Specifications

Material	BK7
Design Wavelength	546.1nm
Refractive Index	$n_e=1.519$
Centration	<3'
Coating	Uncoated: the end of the part number 'N' Anti-reflection coating: the end of the part number 'NM', 'NIR1', 'NIR2'
Laser Damage Threshold	Anti-reflection coating: $4\text{J}/\text{cm}^2$ Laser pulse with 10ns, repetition frequency 20Hz
Clear Aperture	90% of actual aperture: Uncoated 85% of actual aperture: with coating, $\phi 10 \leq D$ 83% of actual aperture: with coating, $D < \phi 10$
Surface Quality (Scratch-Dig)	60-40


Attention

- ▶ Biconcave lens has a chromatic aberration, and the focal length will vary depending on the wavelength. Please check the "wavelength characteristic of the focal length data" on the Web for the focal lengths of each wavelength. [WEB Reference](#) [Catalog Code](#) W3050
- ▶ Transmissions losses due to reflection off the front and rear surfaces of the lens can be minimized by coating the surfaces. Consult our Sales Division for anti-reflection coatings suitable for your application.
- ▶ The outer edge of the concave side is chamfered and the result is possibility that the lens may have a smaller edge thickness for this design.

Outline Drawing


(in mm)

Plano Concave



- Tolerance
Diameter $\phi D_{\pm 0.1}$
Focal length $\pm 1\%$
Thickness $t_c \pm 0.15$

Biconcave



- Tolerance
Diameter $\phi D_{\pm 0.1}$
Focal length $\pm 1\%$
Thickness $t_c \pm 0.15$

How to specify the anti-reflection coating

In case of specifying a anti-reflection coating 633nm – 1064nm to near infrared lens of S-SLB-30-200N.
⇒ S-SLB-30-200NIR1


Type of AR Coat	Part Number	Wavelength Range [nm]	Transmittance [%]
Visible range	S-SLB-30-200NM	400 – 700	> Average 99
Near-infrared	S-SLB-30-200NIR1	633 – 1064	> Average 98.5
Infrared	S-SLB-30-200NIR2	750 – 1550	> Average 98.5

⚠ Part of the above is an example of if you want to coat anti-reflective coating on the lens of the S-SLB-30-200N.

⚠ Anti-reflection coating can be available to the lens of all of S-SLB.

Typical Transmittance Data

T: Transmission



Plano Concave Lens

Uncoated	How to specify the anti-reflection coating			Diameter ϕD [mm]	Focal length f [mm]	Edge thickness t_e [mm]	Center thickness t_c [mm]	Back focal length f_b [mm]	Radius of curvature r [mm]
Part Number	Visibe 400 – 700nm	Near-infrared 633 – 1064nm	Infrared 750 – 1550nm						
S-SLB-10-15N	M	IR1	IR2	$\phi 10$	-15	3.8	2.0	-16.3	7.79
S-SLB-10-20N	M	IR1	IR2	$\phi 10$	-20	3.3	2.0	-21.3	10.38
S-SLB-10-30N	M	IR1	IR2	$\phi 10$	-30	2.8	2.0	-31.3	15.57
S-SLB-10-100N	M	IR1	IR2	$\phi 10$	-100	2.2	2.0	-101.3	51.90
S-SLB-15-25N	M	IR1	IR2	$\phi 15$	-25	4.4	2.0	-26.3	12.98
S-SLB-15-30N	M	IR1	IR2	$\phi 15$	-30	3.9	2.0	-31.3	15.57
S-SLB-20-25N	M	IR1	IR2	$\phi 20$	-25	6.7	2.0	-26.3	12.98
S-SLB-20-30N	M	IR1	IR2	$\phi 20$	-30	5.6	2.0	-31.3	15.57
S-SLB-20-40N	M	IR1	IR2	$\phi 20$	-40	4.6	2.0	-41.3	20.76
S-SLB-20-50N	M	IR1	IR2	$\phi 20$	-50	4.0	2.0	-51.3	25.95
S-SLB-20-60N	M	IR1	IR2	$\phi 20$	-60	3.6	2.0	-61.3	31.14
S-SLB-25-40N	M	IR1	IR2	$\phi 25$	-40	6.2	2.0	-41.3	20.76
S-SLB-30-60N	M	IR1	IR2	$\phi 30$	-60	5.9	2.0	-61.3	31.14
S-SLB-30-200N	M	IR1	IR2	$\phi 30$	-200	3.1	2.0	-201.3	103.80

Biconcave Lens

Uncoated	How to specify the anti-reflection coating			Diameter ϕD [mm]	Focal length f [mm]	Edge thickness t_e [mm]	Center thickness t_c [mm]	Back focal length f_b [mm]	Radius of curvature r [mm]
Part Number	Visibe 400 – 700nm	Near-infrared 633 – 1064nm	Infrared 750 – 1550nm						
S-SLB-10B-10N	M	IR1	IR2	$\phi 10$	-9.7	4.6	2.0	-10.3	10.38
S-SLB-15B-15N	M	IR1	IR2	$\phi 15$	-14.7	5.9	2.0	-15.3	15.57
S-SLB-20B-50N	M	IR1	IR2	$\phi 20$	-49.7	3.9	2.0	-50.3	51.90
S-SLB-30B-100N	M	IR1	IR2	$\phi 30$	-99.7	4.2	2.0	-100.3	103.80

Compatible Optic Mounts

LHF-10S, -15S, -20S, -25S, -30S

Application
SystemsOptics &
Optical
CoatingsOpto-
Mechanics

Bases

Manual
StagesActuators &
AdjustersMotorized
StagesLight Sources &
Laser Safety

Index

Guide

Mirrors

Beamsplitters

Polarizers

Lenses

Multi-Element Optics

Filters

Prisms

Substrates/Windows

Optical Data

Maintenance

Selection Guide

Plano Convex
Lenses
Plano Concave
Lenses

Biconvex Lenses

Biconcave Lenses

Kit

Reasonable Lens

Cylindrical

Others

Cylindrical Plano Convex Lenses | CLB-P/CLSQ-P

RoHS

Application
SystemsOptics &
Optical
CoatingsOpto-
Mechanics

Bases

Manual
StagesActuators &
AdjustersMotorized
StagesLight Sources &
Laser Safety

Index

Guide

Mirrors

Beamsplitters

Polarizers

Lenses

Multi-Element Optics

Filters

Prisms

Substrates/Windows

Optical Data

Maintenance

Selection Guide

Plano Convex

Lenses

Plano Concave

Lenses

Biconvex Lenses

Biconcave Lenses

Kit

Reasonable Lens


Cylindrical

Others


Cylindrical plano-convex lens has a convex curvature in the vertical direction and has no curvature in the horizontal direction.

They are often used to condense a laser beam into a thin line.

- Plano Convex Cylindrical lenses are available in BK7 for from visible range to infrared wavelength range and high-strength synthetic fused silica which has high laser damage threshold used in applications with 350nm ultraviolet light.
- BK7 lenses are also available with three types of anti-reflection coatings, visible wavelength range, in the near-infrared range and in the infrared range.
- Cylindrical lenses are often used in an optical system to change the shape and aspect ratio of the illumination light beam.




Schematic



Outline Drawing

(in mm)



How to specify the anti-reflection coating

In case of specifying an anti-reflection coating 633nm – 1064nm to near infrared lens of CLB-30100-500P.

⇒ CLB-30100-500PIR1

Type of AR Coat	Part Number	Wavelength Range [nm]	Transmittance [%]
Visible range	CLB-30100-500PM	400 – 700	> Average 99
Near-infrared	CLB-30100-500PIR1	633 – 1064	> Average 98.5
Infrared	CLB-30100-500PIR2	750 – 1550	> Average 98.5

! Part of the above is an example of if you want to coat anti-reflective coating on the lens of the CLB-30100-500P.

! Anti-reflection coating can be available to the lens of all of CLB.

Specifications

Material	CLB: BK7 CLSQ: Synthetic fused silica
Design wavelength	546.1nm
Refractive index	BK7: $n_d=1.519$ Synthetic fused silica: $n_d=1.460$
Coating	Uncoated: the end of the part number 'P' Anti-reflection coating: the end of the part number 'PM', 'PIR1', 'PIR2'
Laser Damage Threshold	Anti-reflection coating: $4\text{J}/\text{cm}^2$ Laser pulse with 10ns, repetition frequency 20Hz
Clear aperture	90% of square or rectangle to actual dimension
Surface Quality (Scratch-Dig)	20-10

Guide


- ▶ Lenses are available in a large selection and in custom sizes and focal lengths.
- ▶ In addition to our standard coating we offer custom anti-reflective coating at specific wavelengths.
- ▶ We offer holders to mount our catalog cylindrical lenses, consult our Sales Division for assistance in your selection (CHA).

▶ WEB Reference Catalog Code W4022

Attention

- ▶ Plano-convex cylindrical lens have chromatic aberration, and the focal length will vary depending on the wavelength. Please check the "wavelength characteristic of the focal length data" on the Web for the focal lengths of each wavelength.
- ▶ When using a plano-convex cylindrical lens parallel light should incident to the convex side first. There is a possibility that the spherical aberration will increase and optical performance of the system will be degraded if use in reverse.
- ▶ Transmissions losses due to reflection off the front and rear surfaces of the lens can be minimized by coating the surfaces. Consult our Sales Division for anti-reflection coatings suitable for your application.

Typical Transmittance Data T: Transmission



Compatible Optic Mounts

CHA-25, -60, -130

BK7 10×10mm – 20×30mm

Uncoated	How to specify the anti-reflection coating			AxB [mm]	Focal length f [mm]	Edge thickness te [mm]	Center thickness tc [mm]	Back focal length fb [mm]	Radius of curvature r [mm]
Part Number	Visibe 400 – 700nm	Near-infrared 633 – 1064nm	Infrared 750 – 1550nm						
CLB-1010-15P	M	IR1	IR2	10x10	15	2.2	4.0	12.4	7.79
CLB-1010-20P	M	IR1	IR2	10x10	20	1.7	3.0	18.0	10.38
CLB-1010-25P	M	IR1	IR2	10x10	25	2.0	3.0	23.0	12.98
CLB-1010-30P	M	IR1	IR2	10x10	30	2.2	3.0	28.0	15.57
CLB-1010-40P	M	IR1	IR2	10x10	40	2.4	3.0	38.0	20.76
CLB-1020-15P	M	IR1	IR2	10x20	15	2.2	4.0	12.4	7.79
CLB-1020-20P	M	IR1	IR2	10x20	20	1.7	3.0	18.0	10.38
CLB-1020-25P	M	IR1	IR2	10x20	25	2.0	3.0	23.0	12.98
CLB-1020-30P	M	IR1	IR2	10x20	30	2.2	3.0	28.0	15.57
CLB-1020-40P	M	IR1	IR2	10x20	40	2.4	3.0	38.0	20.76
CLB-1070-15P	M	IR1	IR2	10x70	15	2.2	4.0	12.4	7.79
CLB-1070-20P	M	IR1	IR2	10x70	20	1.7	3.0	18.0	10.38
CLB-1070-25P	M	IR1	IR2	10x70	25	2.0	3.0	23.0	12.98
CLB-1070-30P	M	IR1	IR2	10x70	30	2.2	3.0	28.0	15.57
CLB-1070-40P	M	IR1	IR2	10x70	40	2.4	3.0	38.0	20.76
CLB-1515-20P	M	IR1	IR2	15x15	20	1.8	5.0	16.7	10.38
CLB-1515-25P	M	IR1	IR2	15x15	25	2.6	5.0	21.7	12.98
CLB-1515-30P	M	IR1	IR2	15x15	30	2.1	4.0	27.4	15.57
CLB-1515-40P	M	IR1	IR2	15x15	40	2.6	4.0	37.4	20.76
CLB-1525-20P	M	IR1	IR2	15x25	20	1.8	5.0	16.7	10.38
CLB-1525-25P	M	IR1	IR2	15x25	25	2.6	5.0	21.7	12.98
CLB-1525-30P	M	IR1	IR2	15x25	30	2.1	4.0	27.4	15.57
CLB-1525-40P	M	IR1	IR2	15x25	40	2.6	4.0	37.4	20.76
CLB-1570-20P	M	IR1	IR2	15x70	20	1.8	5.0	16.7	10.38
CLB-1570-25P	M	IR1	IR2	15x70	25	2.6	5.0	21.7	12.98
CLB-1570-30P	M	IR1	IR2	15x70	30	2.1	4.0	27.4	15.57
CLB-1570-40P	M	IR1	IR2	15x70	40	2.6	4.0	37.4	20.76
CLB-2020-25P	M	IR1	IR2	20x20	25	2.3	7.0	20.4	12.98
CLB-2020-30P	M	IR1	IR2	20x20	30	2.4	6.0	26.1	15.57
CLB-2020-40P	M	IR1	IR2	20x20	40	2.4	5.0	36.7	20.76
CLB-2020-50P	M	IR1	IR2	20x20	50	2.0	4.0	47.4	25.95
CLB-2020-60P	M	IR1	IR2	20x20	60	2.4	4.0	57.3	31.14
CLB-2020-70P	M	IR1	IR2	20x20	70	2.6	4.0	67.4	36.33
CLB-2020-80P	M	IR1	IR2	20x20	80	2.8	4.0	77.4	41.52
CLB-2020-100P	M	IR1	IR2	20x20	100	3.0	4.0	97.4	51.90
CLB-2020-130P	M	IR1	IR2	20x20	130	3.3	4.0	127.4	67.47
CLB-2020-150P	M	IR1	IR2	20x20	150	3.4	4.0	147.4	77.85
CLB-2020-200P	M	IR1	IR2	20x20	200	3.5	4.0	197.4	103.80
CLB-2020-250P	M	IR1	IR2	20x20	250	3.6	4.0	247.4	129.75
CLB-2020-300P	M	IR1	IR2	20x20	300	3.7	4.0	297.4	155.70
CLB-2020-400P	M	IR1	IR2	20x20	400	3.8	4.0	397.4	207.60
CLB-2020-500P	M	IR1	IR2	20x20	500	3.8	4.0	497.4	259.50
CLB-2020-700P	M	IR1	IR2	20x20	700	3.9	4.0	697.4	363.30
CLB-2020-1000P	M	IR1	IR2	20x20	1000	3.9	4.0	997.4	519.00
CLB-2030-25P	M	IR1	IR2	20x30	25	2.3	7.0	20.4	12.98
CLB-2030-30P	M	IR1	IR2	20x30	30	2.4	6.0	26.1	15.57
CLB-2030-40P	M	IR1	IR2	20x30	40	2.4	5.0	36.7	20.76
CLB-2030-50P	M	IR1	IR2	20x30	50	2.0	4.0	47.4	25.95
CLB-2030-60P	M	IR1	IR2	20x30	60	2.4	4.0	57.3	31.14
CLB-2030-70P	M	IR1	IR2	20x30	70	2.6	4.0	67.4	36.33
CLB-2030-80P	M	IR1	IR2	20x30	80	2.8	4.0	77.4	41.52
CLB-2030-100P	M	IR1	IR2	20x30	100	3.0	4.0	97.4	51.90
CLB-2030-130P	M	IR1	IR2	20x30	130	3.3	4.0	127.4	67.47
CLB-2030-150P	M	IR1	IR2	20x30	150	3.4	4.0	147.4	77.85
CLB-2030-200P	M	IR1	IR2	20x30	200	3.5	4.0	197.4	103.80
CLB-2030-250P	M	IR1	IR2	20x30	250	3.6	4.0	247.4	129.75
CLB-2030-300P	M	IR1	IR2	20x30	300	3.7	4.0	297.4	155.70
CLB-2030-400P	M	IR1	IR2	20x30	400	3.8	4.0	397.4	207.60
CLB-2030-500P	M	IR1	IR2	20x30	500	3.8	4.0	497.4	259.50
CLB-2030-700P	M	IR1	IR2	20x30	700	3.9	4.0	697.4	363.30
CLB-2030-1000P	M	IR1	IR2	20x30	1000	3.9	4.0	997.4	519.00

Application
SystemsOptics &
Optical
CoatingsOpto-
Mechanics

Bases

Manual
StagesActuators &
AdjustersMotorized
StagesLight Sources &
Laser Safety

Index

Guide

Mirrors

Beamsplitters

Polarizers

Lenses

Multi-Element Optics

Filters

Prisms

Substrates/Windows

Optical Data

Maintenance

Selection Guide

Plano Convex
Lenses
Plano Concave
Lenses

Biconvex Lenses

Biconcave Lenses

Kit

Reasonable Lens

Cylindrical

Others



Cylindrical Plano Convex Lenses

CLB-P/CLSQ-P

Catalog Code W3063

BK7 20×40mm – 30×30mm										
Uncoated		How to specify the anti-reflection coating			A×B [mm]	Focal length f [mm]	Edge thickness te [mm]	Center thickness tc [mm]	Back focal length fb [mm]	Radius of curvature r [mm]
Part Number	Visibe 400 – 700nm	Near-infrared 633 – 1064nm	Infrared 750 – 1550nm							
CLB-2040-25P	M	IR1	IR2	20×40	25	2.3	7.0	20.4	12.98	
CLB-2040-30P	M	IR1	IR2	20×40	30	2.4	6.0	26.1	15.57	
CLB-2040-40P	M	IR1	IR2	20×40	40	2.4	5.0	36.7	20.76	
CLB-2040-50P	M	IR1	IR2	20×40	50	2.0	4.0	47.4	25.95	
CLB-2040-60P	M	IR1	IR2	20×40	60	2.4	4.0	57.3	31.14	
CLB-2040-70P	M	IR1	IR2	20×40	70	2.6	4.0	67.4	36.33	
CLB-2040-80P	M	IR1	IR2	20×40	80	2.8	4.0	77.4	41.52	
CLB-2040-100P	M	IR1	IR2	20×40	100	3.0	4.0	97.4	51.90	
CLB-2040-130P	M	IR1	IR2	20×40	130	3.3	4.0	127.4	67.47	
CLB-2040-150P	M	IR1	IR2	20×40	150	3.4	4.0	147.4	77.85	
CLB-2040-200P	M	IR1	IR2	20×40	200	3.5	4.0	197.4	103.80	
CLB-2040-250P	M	IR1	IR2	20×40	250	3.6	4.0	247.4	129.75	
CLB-2040-300P	M	IR1	IR2	20×40	300	3.7	4.0	297.4	155.70	
CLB-2040-400P	M	IR1	IR2	20×40	400	3.8	4.0	397.4	207.60	
CLB-2040-500P	M	IR1	IR2	20×40	500	3.8	4.0	497.4	259.50	
CLB-2040-700P	M	IR1	IR2	20×40	700	3.9	4.0	697.4	363.30	
CLB-2040-1000P	M	IR1	IR2	20×40	1000	3.9	4.0	997.4	519.00	
CLB-2050-100P	M	IR1	IR2	20×50	100	3.0	4.0	97.4	51.90	
CLB-2050-130P	M	IR1	IR2	20×50	130	3.3	4.0	127.4	67.47	
CLB-2050-150P	M	IR1	IR2	20×50	150	3.4	4.0	147.4	77.85	
CLB-2050-200P	M	IR1	IR2	20×50	200	3.5	4.0	197.4	103.80	
CLB-2050-250P	M	IR1	IR2	20×50	250	3.6	4.0	247.4	129.75	
CLB-2050-300P	M	IR1	IR2	20×50	300	3.7	4.0	297.4	155.70	
CLB-2050-400P	M	IR1	IR2	20×50	400	3.8	4.0	397.4	207.60	
CLB-2050-500P	M	IR1	IR2	20×50	500	3.8	4.0	497.4	259.50	
CLB-2050-700P	M	IR1	IR2	20×50	700	3.9	4.0	697.4	363.30	
CLB-2050-1000P	M	IR1	IR2	20×50	1000	3.9	4.0	997.4	519.00	
CLB-2070-25P	M	IR1	IR2	20×70	25	2.3	7.0	20.4	12.98	
CLB-2070-30P	M	IR1	IR2	20×70	30	2.4	6.0	26.1	15.57	
CLB-2070-40P	M	IR1	IR2	20×70	40	2.4	5.0	36.7	20.76	
CLB-2070-50P	M	IR1	IR2	20×70	50	2.0	4.0	47.4	25.95	
CLB-2070-60P	M	IR1	IR2	20×70	60	2.4	4.0	57.3	31.14	
CLB-2070-70P	M	IR1	IR2	20×70	70	2.6	4.0	67.4	36.33	
CLB-2070-80P	M	IR1	IR2	20×70	80	2.8	4.0	77.4	41.52	
CLB-2070-100P	M	IR1	IR2	20×70	100	3.0	4.0	97.4	51.90	
CLB-20100-130P	M	IR1	IR2	20×100	130	3.3	4.0	127.4	67.47	
CLB-20100-150P	M	IR1	IR2	20×100	150	3.4	4.0	147.4	77.85	
CLB-20100-200P	M	IR1	IR2	20×100	200	3.5	4.0	197.4	103.80	
CLB-20100-300P	M	IR1	IR2	20×100	300	3.7	4.0	297.4	155.70	
CLB-3030-50P	M	IR1	IR2	30×30	50	2.2	7.0	45.4	25.95	
CLB-3030-60P	M	IR1	IR2	30×30	60	2.1	6.0	56.0	31.14	
CLB-3030-70P	M	IR1	IR2	30×30	70	1.8	5.0	66.7	36.33	
CLB-3030-80P	M	IR1	IR2	30×30	80	2.2	5.0	76.7	41.52	
CLB-3030-100P	M	IR1	IR2	30×30	100	2.8	5.0	96.7	51.90	
CLB-3030-130P	M	IR1	IR2	30×30	130	3.3	5.0	126.7	67.47	
CLB-3030-150P	M	IR1	IR2	30×30	150	3.5	5.0	146.7	77.85	
CLB-3030-200P	M	IR1	IR2	30×30	200	3.9	5.0	196.7	103.80	
CLB-3030-250P	M	IR1	IR2	30×30	250	4.0	5.0	246.7	129.75	
CLB-3030-300P	M	IR1	IR2	30×30	300	4.3	5.0	296.7	155.70	
CLB-3030-400P	M	IR1	IR2	30×30	400	4.5	5.0	396.7	207.60	
CLB-3030-500P	M	IR1	IR2	30×30	500	4.6	5.0	496.7	259.50	
CLB-3030-700P	M	IR1	IR2	30×30	700	4.7	5.0	696.7	363.30	
CLB-3030-1000P	M	IR1	IR2	30×30	1000	4.8	5.0	996.7	519.00	

BK7 30×40mm – 30×100mm

Uncoated	How to specify the anti-reflection coating			A×B [mm]	Focal length f [mm]	Edge thickness te [mm]	Center thickness tc [mm]	Back focal length fb [mm]	Radius of curvature r [mm]
Part Number	Visibe 400 – 700nm	Near-infrared 633 – 1064nm	Infrared 750 – 1550nm						
CLB-3040-50P	M	IR1	IR2	30×40	50	2.2	7.0	45.4	25.95
CLB-3040-60P	M	IR1	IR2	30×40	60	2.1	6.0	56.0	31.14
CLB-3040-70P	M	IR1	IR2	30×40	70	1.8	5.0	66.7	36.33
CLB-3040-80P	M	IR1	IR2	30×40	80	2.2	5.0	76.7	41.52
CLB-3040-100P	M	IR1	IR2	30×40	100	2.8	5.0	96.7	51.90
CLB-3040-130P	M	IR1	IR2	30×40	130	3.3	5.0	126.7	67.47
CLB-3040-150P	M	IR1	IR2	30×40	150	3.5	5.0	146.7	77.85
CLB-3040-200P	M	IR1	IR2	30×40	200	3.9	5.0	196.7	103.80
CLB-3040-250P	M	IR1	IR2	30×40	250	4.0	5.0	246.7	129.75
CLB-3040-300P	M	IR1	IR2	30×40	300	4.3	5.0	296.7	155.70
CLB-3040-400P	M	IR1	IR2	30×40	400	4.5	5.0	396.7	207.60
CLB-3040-500P	M	IR1	IR2	30×40	500	4.6	5.0	496.7	259.50
CLB-3040-700P	M	IR1	IR2	30×40	700	4.7	5.0	696.7	363.30
CLB-3040-1000P	M	IR1	IR2	30×40	1000	4.8	5.0	996.7	519.00
CLB-3050-50P	M	IR1	IR2	30×50	50	2.2	7.0	45.4	25.95
CLB-3050-60P	M	IR1	IR2	30×50	60	2.1	6.0	56.0	31.14
CLB-3050-70P	M	IR1	IR2	30×50	70	1.8	5.0	66.7	36.33
CLB-3050-80P	M	IR1	IR2	30×50	80	2.2	5.0	76.7	41.52
CLB-3050-100P	M	IR1	IR2	30×50	100	2.8	5.0	96.7	51.90
CLB-3050-130P	M	IR1	IR2	30×50	130	3.3	5.0	126.7	67.47
CLB-3050-150P	M	IR1	IR2	30×50	150	3.5	5.0	146.7	77.85
CLB-3050-200P	M	IR1	IR2	30×50	200	3.9	5.0	196.7	103.80
CLB-3050-250P	M	IR1	IR2	30×50	250	4.0	5.0	246.7	129.75
CLB-3050-300P	M	IR1	IR2	30×50	300	4.3	5.0	296.7	155.70
CLB-3050-400P	M	IR1	IR2	30×50	400	4.5	5.0	396.7	207.60
CLB-3050-500P	M	IR1	IR2	30×50	500	4.6	5.0	496.7	259.50
CLB-3050-700P	M	IR1	IR2	30×50	700	4.7	5.0	696.7	363.30
CLB-3050-1000P	M	IR1	IR2	30×50	1000	4.8	5.0	996.7	519.00
CLB-3070-50P	M	IR1	IR2	30×70	50	2.2	7.0	45.4	25.95
CLB-3070-60P	M	IR1	IR2	30×70	60	2.1	6.0	56.0	31.14
CLB-3070-70P	M	IR1	IR2	30×70	70	1.8	5.0	66.7	36.33
CLB-3070-80P	M	IR1	IR2	30×70	80	2.2	5.0	76.7	41.52
CLB-3070-100P	M	IR1	IR2	30×70	100	2.8	5.0	96.7	51.90
CLB-30100-130P	M	IR1	IR2	30×100	130	3.3	5.0	126.7	67.47
CLB-30100-150P	M	IR1	IR2	30×100	150	3.5	5.0	146.7	77.85
CLB-30100-200P	M	IR1	IR2	30×100	200	3.9	5.0	196.7	103.80

Application
SystemsOptics &
Optical
CoatingsOpto-
Mechanics

Bases

Manual
StagesActuators &
AdjustersMotorized
StagesLight Sources &
Laser Safety

Index

Guide

Mirrors

Beamsplitters

Polarizers

Lenses

Multi-Element Optics

Filters

Prisms

Substrates/Windows

Optical Data

Maintenance

Selection Guide

Plano Convex
Lenses
Plano Concave
Lenses

Biconvex Lenses

Biconcave Lenses

Kit

Reasonable Lens

Cylindrical

Others



Cylindrical Plano Convex Lenses

CLB-P/CLSQ-P

Catalog Code W3065

Synthetic fused silica 10×10mm – 20×30mm						
Part Number	A×B [mm]	Focal length f [mm]	Edge thickness te [mm]	Center thickness tc [mm]	Back focal length fb [mm]	Radius of curvature r [mm]
CLSQ-1010-15P	10×10	15	1.9	4.0	12.3	6.90
CLSQ-1010-20P	10×10	20	1.5	3.0	17.9	9.20
CLSQ-1010-25P	10×10	25	1.9	3.0	22.9	11.50
CLSQ-1010-30P	10×10	30	2.1	3.0	27.9	13.80
CLSQ-1010-40P	10×10	40	2.3	3.0	37.9	18.40
CLSQ-1020-15P	10×20	15	1.9	4.0	12.3	6.90
CLSQ-1020-20P	10×20	20	1.5	3.0	17.9	9.20
CLSQ-1020-25P	10×20	25	1.9	3.0	22.9	11.50
CLSQ-1020-30P	10×20	30	2.1	3.0	27.9	13.80
CLSQ-1020-40P	10×20	40	2.3	3.0	37.9	18.40
CLSQ-1070-15P	10×70	15	1.9	4.0	12.3	6.90
CLSQ-1070-20P	10×70	20	1.5	3.0	17.9	9.20
CLSQ-1070-25P	10×70	25	1.9	3.0	22.9	11.50
CLSQ-1070-30P	10×70	30	2.1	3.0	27.9	13.80
CLSQ-1070-40P	10×70	40	2.3	3.0	37.9	18.40
CLSQ-1515-20P	15×15	20	2.1	6.0	16.0	9.20
CLSQ-1515-25P	15×15	25	2.2	5.0	21.6	11.50
CLSQ-1515-30P	15×15	30	1.8	4.0	27.3	13.80
CLSQ-1515-40P	15×15	40	2.4	4.0	37.3	18.40
CLSQ-1525-20P	15×25	20	2.1	6.0	16.0	9.20
CLSQ-1525-25P	15×25	25	2.2	5.0	21.6	11.50
CLSQ-1525-30P	15×25	30	1.8	4.0	27.3	13.80
CLSQ-1525-40P	15×25	40	2.4	4.0	37.3	18.40
CLSQ-1570-20P	15×70	20	2.1	6.0	16.0	9.20
CLSQ-1570-25P	15×70	25	2.2	5.0	21.6	11.50
CLSQ-1570-30P	15×70	30	1.8	4.0	27.3	13.80
CLSQ-1570-40P	15×70	40	2.4	4.0	37.3	18.40
CLSQ-2020-25P	20×20	25	1.2	7.0	20.2	11.50
CLSQ-2020-30P	20×20	30	1.7	6.0	25.9	13.80
CLSQ-2020-40P	20×20	40	2.0	5.0	36.6	18.40
CLSQ-2020-50P	20×20	50	1.7	4.0	47.3	23.00
CLSQ-2020-60P	20×20	60	2.1	4.0	57.3	27.60
CLSQ-2020-70P	20×20	70	2.4	4.0	67.3	32.20
CLSQ-2020-80P	20×20	80	2.6	4.0	77.3	36.80
CLSQ-2020-100P	20×20	100	2.9	4.0	97.3	46.00
CLSQ-2020-130P	20×20	130	3.2	4.0	127.3	59.80
CLSQ-2020-150P	20×20	150	3.3	4.0	147.3	69.00
CLSQ-2020-200P	20×20	200	3.5	4.0	197.3	92.00
CLSQ-2020-250P	20×20	250	3.6	4.0	247.3	115.00
CLSQ-2020-300P	20×20	300	3.6	4.0	297.3	138.00
CLSQ-2020-400P	20×20	400	3.7	4.0	397.3	184.00
CLSQ-2020-500P	20×20	500	3.7	4.0	497.3	230.00
CLSQ-2020-700P	20×20	700	3.8	4.0	697.3	322.00
CLSQ-2020-1000P	20×20	1000	3.8	4.0	997.3	460.00
CLSQ-2030-25P	20×30	25	1.2	7.0	20.2	11.50
CLSQ-2030-30P	20×30	30	1.7	6.0	25.9	13.80
CLSQ-2030-40P	20×30	40	2.0	5.0	36.6	18.40
CLSQ-2030-50P	20×30	50	1.7	4.0	47.3	23.00
CLSQ-2030-60P	20×30	60	2.1	4.0	57.3	27.60
CLSQ-2030-70P	20×30	70	2.4	4.0	67.3	32.20
CLSQ-2030-80P	20×30	80	2.6	4.0	77.3	36.80
CLSQ-2030-100P	20×30	100	2.9	4.0	97.3	46.00
CLSQ-2030-130P	20×30	130	3.2	4.0	127.3	59.80
CLSQ-2030-150P	20×30	150	3.3	4.0	147.3	69.00
CLSQ-2030-200P	20×30	200	3.5	4.0	197.3	92.00
CLSQ-2030-250P	20×30	250	3.6	4.0	247.3	115.00
CLSQ-2030-300P	20×30	300	3.6	4.0	297.3	138.00
CLSQ-2030-400P	20×30	400	3.7	4.0	397.3	184.00
CLSQ-2030-500P	20×30	500	3.7	4.0	497.3	230.00
CLSQ-2030-700P	20×30	700	3.8	4.0	697.3	322.00
CLSQ-2030-1000P	20×30	1000	3.8	4.0	997.3	460.00

Synthetic fused silica 20×40mm – 30×30mm						
Part Number	A×B [mm]	Focal length f [mm]	Edge thickness te [mm]	Center thickness tc [mm]	Back focal length fb [mm]	Radius of curvature r [mm]
CLSQ-2040-25P	20×40	25	1.2	7.0	20.2	11.50
CLSQ-2040-30P	20×40	30	1.7	6.0	25.9	13.80
CLSQ-2040-40P	20×40	40	2.0	5.0	36.6	18.40
CLSQ-2040-50P	20×40	50	1.7	4.0	47.3	23.00
CLSQ-2040-60P	20×40	60	2.1	4.0	57.3	27.60
CLSQ-2040-70P	20×40	70	2.4	4.0	67.3	32.20
CLSQ-2040-80P	20×40	80	2.6	4.0	77.3	36.80
CLSQ-2040-100P	20×40	100	2.9	4.0	97.3	46.00
CLSQ-2040-130P	20×40	130	3.2	4.0	127.3	59.80
CLSQ-2040-150P	20×40	150	3.3	4.0	147.3	69.00
CLSQ-2040-200P	20×40	200	3.5	4.0	197.3	92.00
CLSQ-2040-250P	20×40	250	3.6	4.0	247.3	115.00
CLSQ-2040-300P	20×40	300	3.6	4.0	297.3	138.00
CLSQ-2040-400P	20×40	400	3.7	4.0	397.3	184.00
CLSQ-2040-500P	20×40	500	3.7	4.0	497.3	230.00
CLSQ-2040-700P	20×40	700	3.8	4.0	697.3	322.00
CLSQ-2040-1000P	20×40	1000	3.8	4.0	997.3	460.00
CLSQ-2050-100P	20×50	100	2.9	4.0	97.3	46.00
CLSQ-2050-130P	20×50	130	3.2	4.0	127.3	59.80
CLSQ-2050-150P	20×50	150	3.3	4.0	147.3	69.00
CLSQ-2050-200P	20×50	200	3.5	4.0	197.3	92.00
CLSQ-2050-250P	20×50	250	3.6	4.0	247.3	115.00
CLSQ-2050-300P	20×50	300	3.6	4.0	297.3	138.00
CLSQ-2050-400P	20×50	400	3.7	4.0	397.3	184.00
CLSQ-2050-500P	20×50	500	3.7	4.0	497.3	230.00
CLSQ-2050-700P	20×50	700	3.8	4.0	697.3	322.00
CLSQ-2050-1000P	20×50	1000	3.8	4.0	997.3	460.00
CLSQ-2070-25P	20×70	25	1.2	7.0	20.2	11.50
CLSQ-2070-30P	20×70	30	1.7	6.0	25.9	13.80
CLSQ-2070-40P	20×70	40	2.0	5.0	36.6	18.40
CLSQ-2070-50P	20×70	50	1.7	4.0	47.3	23.00
CLSQ-2070-60P	20×70	60	2.1	4.0	57.3	27.60
CLSQ-2070-70P	20×70	70	2.4	4.0	67.3	32.20
CLSQ-2070-80P	20×70	80	2.6	4.0	77.3	36.80
CLSQ-2070-100P	20×70	100	2.9	4.0	97.3	46.00
CLSQ-20100-130P	20×100	130	3.2	4.0	127.3	59.80
CLSQ-20100-150P	20×100	150	3.3	4.0	147.3	69.00
CLSQ-20100-200P	20×100	200	3.5	4.0	197.3	92.00
CLSQ-20100-250P	20×100	250	3.6	4.0	247.3	115.00
CLSQ-20100-300P	20×100	300	3.6	4.0	297.3	138.00
CLSQ-20100-400P	20×100	400	3.7	4.0	397.3	184.00
CLSQ-20100-500P	20×100	500	3.7	4.0	497.3	230.00
CLSQ-20100-700P	20×100	700	3.8	4.0	697.3	322.00
CLSQ-20100-1000P	20×100	1000	3.8	4.0	997.3	460.00
CLSQ-3030-50P	30×30	50	1.4	7.0	45.2	23.00
CLSQ-3030-60P	30×30	60	1.6	6.0	55.9	27.60
CLSQ-3030-70P	30×30	70	2.3	6.0	65.9	32.20
CLSQ-3030-80P	30×30	80	1.8	5.0	79.6	36.80
CLSQ-3030-100P	30×30	100	2.5	5.0	96.6	46.00
CLSQ-3030-130P	30×30	130	3.1	5.0	126.6	59.80
CLSQ-3030-150P	30×30	150	3.3	5.0	146.6	69.00
CLSQ-3030-200P	30×30	200	3.8	5.0	196.6	92.00
CLSQ-3030-250P	30×30	250	4.0	5.0	246.6	115.00
CLSQ-3030-300P	30×30	300	4.2	5.0	296.6	138.00
CLSQ-3030-400P	30×30	400	4.4	5.0	396.6	184.00
CLSQ-3030-500P	30×30	500	4.4	5.0	496.6	230.00
CLSQ-3030-700P	30×30	700	4.7	5.0	696.6	322.00
CLSQ-3030-1000P	30×30	1000	4.8	5.0	996.6	460.00

Application Systems

Optics & Optical Coatings

Opto-Mechanics

Bases

Manual Stages

Actuators & Adjusters

Motorized Stages

Light Sources & Laser Safety

Index

Guide

Mirrors

Beamsplitters

Polarizers

Lenses

Multi-Element Optics

Filters

Prisms

Substrates/Windows

Optical Data

Maintenance

Selection Guide

Plano Convex Lenses

Plano Concave Lenses

Biconvex Lenses

Biconcave Lenses

Kit

Reasonable Lens

Cylindrical

Others

Cylindrical Plano Convex Lenses

CLB-P/CLSQ-P

Catalog
Code

W3067

Synthetic fused silica 30×40mm – 30×100mm

Part Number	A×B [mm]	Focal length f [mm]	Edge thickness te [mm]	Center thickness tc [mm]	Back focal length fb [mm]	Radius of curvature r [mm]
CLSQ-3040-50P	30×40	50	1.4	7.0	45.2	23.00
CLSQ-3040-60P	30×40	60	1.6	6.0	55.9	27.60
CLSQ-3040-70P	30×40	70	2.3	6.0	65.9	32.20
CLSQ-3040-80P	30×40	80	1.8	5.0	79.6	36.80
CLSQ-3040-100P	30×40	100	2.5	5.0	96.6	46.00
CLSQ-3040-130P	30×40	130	3.1	5.0	126.6	59.80
CLSQ-3040-150P	30×40	150	3.3	5.0	146.6	69.00
CLSQ-3040-200P	30×40	200	3.8	5.0	196.6	92.00
CLSQ-3040-250P	30×40	250	4.0	5.0	246.6	115.00
CLSQ-3040-300P	30×40	300	4.2	5.0	296.6	138.00
CLSQ-3040-400P	30×40	400	4.4	5.0	396.6	184.00
CLSQ-3040-500P	30×40	500	4.4	5.0	496.6	230.00
CLSQ-3040-700P	30×40	700	4.7	5.0	696.6	322.00
CLSQ-3040-1000P	30×40	1000	4.8	5.0	996.6	460.00
CLSQ-3050-50P	30×50	50	1.4	7.0	45.2	23.00
CLSQ-3050-60P	30×50	60	1.6	6.0	55.9	27.60
CLSQ-3050-70P	30×50	70	2.3	6.0	65.9	32.20
CLSQ-3050-80P	30×50	80	1.8	5.0	79.6	36.80
CLSQ-3050-100P	30×50	100	2.5	5.0	96.6	46.00
CLSQ-3050-130P	30×50	130	3.1	5.0	126.6	59.80
CLSQ-3050-150P	30×50	150	3.3	5.0	146.6	69.00
CLSQ-3050-200P	30×50	200	3.8	5.0	196.6	92.00
CLSQ-3050-250P	30×50	250	4.0	5.0	246.6	115.00
CLSQ-3050-300P	30×50	300	4.2	5.0	296.6	138.00
CLSQ-3050-400P	30×50	400	4.4	5.0	396.6	184.00
CLSQ-3050-500P	30×50	500	4.4	5.0	496.6	230.00
CLSQ-3050-700P	30×50	700	4.7	5.0	696.6	322.00
CLSQ-3050-1000P	30×50	1000	4.8	5.0	996.6	460.00
CLSQ-30100-130P	30×100	130	3.1	5.0	126.6	59.80
CLSQ-30100-150P	30×100	150	3.3	5.0	146.6	69.00
CLSQ-30100-200P	30×100	200	3.8	5.0	196.6	92.00
CLSQ-30100-250P	30×100	250	4.0	5.0	246.6	115.00
CLSQ-30100-300P	30×100	300	4.2	5.0	296.6	138.00
CLSQ-30100-400P	30×100	400	4.4	5.0	396.6	184.00
CLSQ-30100-500P	30×100	500	4.4	5.0	496.6	230.00
CLSQ-30100-700P	30×100	700	4.7	5.0	696.6	322.00
CLSQ-30100-1000P	30×100	1000	4.8	5.0	996.6	460.00

Application
SystemsOptics &
Optical
CoatingsOpto-
Mechanics

Bases

Manual
StagesActuators &
AdjustersMotorized
StagesLight Sources &
Laser Safety

Index

Guide

Mirrors

Beamsplitters

Polarizers

Lenses

Multi-Element Optics

Filters

Prisms

Substrates/Windows

Optical Data

Maintenance

Selection Guide

Plano Convex
LensesPlano Concave
Lenses

Biconvex Lenses

Biconcave Lenses

Kit

Reasonable Lens


Cylindrical

Others


Cylindrical plano-concave lens has a concave curvature in the vertical direction and has no curvature in the horizontal direction.

When used in combination with a plano-convex cylindrical lens an elliptical shaped beam can be shaped into a circular beam for use in semiconductor and other laser applications.

- Plano Concave Cylindrical lenses are available in BK7 for from visible range to infrared wavelength range and high-strength synthetic fused silica which has high laser damage threshold used in applications with 350nm ultraviolet light.
- BK7 lenses are also available with three types of anti-reflection coatings, visible wavelength range, in the near-infrared range and in the infrared range.
- Cylindrical lenses are often used in an optical system to change the shape and aspect ratio of the illumination light beam.




Schematic



Outline Drawing

(in mm)



How to specify the anti-reflection coating

In case of specifying a anti-reflection coating 633nm – 1064nm to near infrared lens of CLB-3050-200N.
⇒ CLB-3050-200NIR1

Type of AR Coat	Part Number	Wavelength Range [nm]	Transmittance [%]
Visible range	CLB-3050-200NM	400 – 700	> Average 99
Near-infrared	CLB-3050-200NIR1	633 – 1064	> Average 98.5
Infrared	CLB-3050-200NIR2	750 – 1550	> Average 98.5

! Part of the above is an example of if you want to coat anti-reflective coating on the lens of the CLB-3050-200N.

! Anti-reflection coating can be available to the lens of all of CLB.

Specifications

Material	CLB: BK7 CLSQ: Synthetic fused silica
Design wavelength	546.1nm
Refractive index	BK: $n_d=1.519$ Synthetic fused silica: $n_d=1.460$
Coating	Uncoated: the end of the part number 'N' Anti-reflection coating: the end of the part number 'NM', 'NIR1', 'NIR2'
Laser Damage Threshold	Anti-reflection coating: $4\text{J}/\text{cm}^2$ Laser pulse with 10ns, repetition frequency 20Hz
Clear aperture	90% of square or rectangle to actual dimension
Surface Quality (Scratch-Dig)	20-10

Guide

- Lenses are available in a large selection and in custom sizes and focal lengths.
- In addition to our standard coating we offer custom anti-reflective coating at specific wavelengths.
- We offer holders to mount our catalog cylindrical lenses, consult our Sales Division for assistance in your selection (CHA).


► [WEB Reference](#) [Catalog Code](#) W4022

Attention

- The cylindrical plano-concave lens has chromatic aberration, the focal length will vary depending on the wavelength. Please check the "wavelength characteristic of the focal length data" on the Web for the focal lengths of each wavelength.
- When using a plano-concave cylindrical lens parallel light should incident to the concave side first. There is a possibility that the spherical aberration will increase and optical performance of the system will be degraded if use in reverse.
- Transmissions losses due to reflection off the front and rear surfaces of the lens can be minimized by coating the surfaces. Consult our Sales Division for anti-reflection coatings suitable for your application.

Typical Transmittance Data

T: Transmission



Compatible Optic Mounts

CHA-25, -60

Application Systems

Optics & Optical Coatings

Opto-Mechanics

Bases

Manual Stages

Actuators & Adjusters

MotORIZED Stages

Light Sources & Laser Safety

Index

Guide

Mirrors

Beamsplitters

Polarizers

Lenses

Multi-Element Optics

Filters

Prisms

Substrates/Windows

Optical Data

Maintenance

Selection Guide

Plano Convex Lenses
Plano Concave Lenses

Biconvex Lenses

Biconcave Lenses

Kit

Reasonable Lens

Cylindrical

Others

Cylindrical Plano Concave Lenses

CLB-N/CLSQ-N

Catalog Code W3068

BK7 10×10mm – 30×50mm									
Uncoated	How to specify the anti-reflection coating			A×B [mm]	Focal length f [mm]	Edge thickness te [mm]	Center thickness tc [mm]	Back focal length fb [mm]	Radius of curvature r [mm]
Part Number	Visibe 400 – 700nm	Near-infrared 633 – 1064nm	Infrared 750 – 1550nm						
CLB-1010-15N	M	IR1	IR2	10×10	−15	4.0	2.2	−16.4	7.79
CLB-1010-20N	M	IR1	IR2	10×10	−20	3.0	1.7	−21.1	10.38
CLB-1010-25N	M	IR1	IR2	10×10	−25	3.0	2.0	−26.3	12.98
CLB-1010-30N	M	IR1	IR2	10×10	−30	3.0	2.2	−31.4	15.57
CLB-1010-40N	M	IR1	IR2	10×10	−40	3.0	2.4	−41.6	20.76
CLB-1020-15N	M	IR1	IR2	10×20	−15	4.0	2.2	−16.4	7.79
CLB-1020-20N	M	IR1	IR2	10×20	−20	3.0	1.7	−21.1	10.38
CLB-1020-25N	M	IR1	IR2	10×20	−25	3.0	2.0	−26.3	12.98
CLB-1020-30N	M	IR1	IR2	10×20	−30	3.0	2.2	−31.4	15.57
CLB-1020-40N	M	IR1	IR2	10×20	−40	3.0	2.4	−41.6	20.76
CLB-1515-20N	M	IR1	IR2	15×15	−20	5.0	1.8	−21.2	10.38
CLB-1515-25N	M	IR1	IR2	15×15	−25	5.0	2.6	−26.7	12.98
CLB-1515-30N	M	IR1	IR2	15×15	−30	4.0	2.1	−31.4	15.57
CLB-1515-40N	M	IR1	IR2	15×15	−40	4.0	2.6	−41.7	20.76
CLB-1525-20N	M	IR1	IR2	15×25	−20	5.0	1.8	−21.2	10.38
CLB-1525-25N	M	IR1	IR2	15×25	−25	5.0	2.6	−26.7	12.98
CLB-1525-30N	M	IR1	IR2	15×25	−30	4.0	2.1	−31.4	15.57
CLB-1525-40N	M	IR1	IR2	15×25	−40	4.0	2.6	−41.7	20.76
CLB-2020-25N	M	IR1	IR2	20×20	−25	7.0	2.3	−26.5	12.98
CLB-2020-30N	M	IR1	IR2	20×20	−30	6.0	2.4	−31.6	15.57
CLB-2020-40N	M	IR1	IR2	20×20	−40	5.0	2.4	−41.6	20.76
CLB-2020-50N	M	IR1	IR2	20×20	−50	4.0	2.0	−51.3	25.95
CLB-2020-60N	M	IR1	IR2	20×20	−60	4.0	2.4	−61.5	31.14
CLB-2020-70N	M	IR1	IR2	20×20	−70	4.0	2.6	−71.7	36.33
CLB-2020-80N	M	IR1	IR2	20×20	−80	4.0	2.8	−81.8	41.52
CLB-2020-100N	M	IR1	IR2	20×20	−100	4.0	3.0	−102.0	51.90
CLB-2020-130N	M	IR1	IR2	20×20	−130	4.0	3.3	−132.1	67.47
CLB-2020-150N	M	IR1	IR2	20×20	−150	4.0	3.4	−152.2	77.85
CLB-2020-200N	M	IR1	IR2	20×20	−200	4.0	3.5	−202.3	103.80
CLB-2020-250N	M	IR1	IR2	20×20	−250	4.0	3.6	−252.4	129.75
CLB-2020-300N	M	IR1	IR2	20×20	−300	4.0	3.7	−302.4	155.70
CLB-2030-100N	M	IR1	IR2	20×30	−100	4.0	3.0	−102.0	51.90
CLB-2030-130N	M	IR1	IR2	20×30	−130	4.0	3.3	−132.1	67.47
CLB-2030-150N	M	IR1	IR2	20×30	−150	4.0	3.4	−152.2	77.85
CLB-2030-200N	M	IR1	IR2	20×30	−200	4.0	3.5	−202.3	103.80
CLB-2030-250N	M	IR1	IR2	20×30	−250	4.0	3.6	−252.4	129.75
CLB-2030-300N	M	IR1	IR2	20×30	−300	4.0	3.7	−302.4	155.70
CLB-2040-25N	M	IR1	IR2	20×40	−25	7.0	2.3	−26.5	12.98
CLB-2040-30N	M	IR1	IR2	20×40	−30	6.0	2.4	−31.6	15.57
CLB-2040-40N	M	IR1	IR2	20×40	−40	5.0	2.4	−41.6	20.76
CLB-2040-50N	M	IR1	IR2	20×40	−50	4.0	2.0	−51.3	25.95
CLB-2040-60N	M	IR1	IR2	20×40	−60	4.0	2.4	−61.5	31.14
CLB-2040-70N	M	IR1	IR2	20×40	−70	4.0	2.6	−71.7	36.33
CLB-2040-80N	M	IR1	IR2	20×40	−80	4.0	2.8	−81.8	41.52
CLB-2050-100N	M	IR1	IR2	20×50	−100	4.0	3.0	−102.0	51.90
CLB-2050-130N	M	IR1	IR2	20×50	−130	4.0	3.3	−132.1	67.47
CLB-2050-150N	M	IR1	IR2	20×50	−150	4.0	3.4	−152.2	77.85
CLB-2050-200N	M	IR1	IR2	20×50	−200	4.0	3.5	−202.3	103.80
CLB-2050-250N	M	IR1	IR2	20×50	−250	4.0	3.6	−252.4	129.75
CLB-2050-300N	M	IR1	IR2	20×50	−300	4.0	3.7	−302.4	155.70
CLB-3030-50N	M	IR1	IR2	30×30	−50	7.0	2.2	−51.5	25.95
CLB-3030-60N	M	IR1	IR2	30×30	−60	6.0	2.1	−61.4	31.14
CLB-3030-70N	M	IR1	IR2	30×30	−70	5.0	1.8	−71.2	36.33
CLB-3030-80N	M	IR1	IR2	30×30	−80	5.0	2.2	−81.4	41.52
CLB-3030-100N	M	IR1	IR2	30×30	−100	5.0	2.8	−101.8	51.90
CLB-3030-130N	M	IR1	IR2	30×30	−130	5.0	3.3	−132.2	67.47
CLB-3030-150N	M	IR1	IR2	30×30	−150	5.0	3.5	−152.3	77.85
CLB-3030-200N	M	IR1	IR2	30×30	−200	5.0	3.9	−202.6	103.80
CLB-3030-250N	M	IR1	IR2	30×30	−250	5.0	4.1	−252.7	129.75
CLB-3030-300N	M	IR1	IR2	30×30	−300	5.0	4.3	−302.8	155.70
CLB-3040-50N	M	IR1	IR2	30×40	−50	7.0	2.2	−51.5	25.95
CLB-3040-60N	M	IR1	IR2	30×40	−60	6.0	2.1	−61.4	31.14
CLB-3040-70N	M	IR1	IR2	30×40	−70	5.0	1.8	−71.2	36.33
CLB-3040-80N	M	IR1	IR2	30×40	−80	5.0	2.2	−81.4	41.52
CLB-3050-100N	M	IR1	IR2	30×50	−100	5.0	2.8	−101.8	51.90
CLB-3050-130N	M	IR1	IR2	30×50	−130	5.0	3.3	−132.2	67.47
CLB-3050-150N	M	IR1	IR2	30×50	−150	5.0	3.5	−152.3	77.85
CLB-3050-200N	M	IR1	IR2	30×50	−200	5.0	3.9	−202.6	103.80
CLB-3050-250N	M	IR1	IR2	30×50	−250	5.0	4.1	−252.7	129.75
CLB-3050-300N	M	IR1	IR2	30×50	−300	5.0	4.3	−302.8	155.70

Synthetic fused silica 10×10mm – 30×50mm

Part Number	A×B [mm]	Focal length f [mm]	Edge thickness te [mm]	Center thickness tc [mm]	Back focal length fb [mm]	Radius of curvature r [mm]
CLSQ-1010-15N	10×10	-15	4.0	1.9	-16.3	6.90
CLSQ-1010-20N	10×10	-20	3.0	1.5	-21.0	9.20
CLSQ-1010-25N	10×10	-25	3.0	1.9	-26.3	11.50
CLSQ-1010-30N	10×10	-30	3.0	2.1	-31.4	13.80
CLSQ-1010-40N	10×10	-40	3.0	2.3	-41.6	18.40
CLSQ-1020-15N	10×20	-15	4.0	1.9	-16.3	6.90
CLSQ-1020-20N	10×20	-20	3.0	1.5	-21.0	9.20
CLSQ-1020-25N	10×20	-25	3.0	1.9	-26.3	11.50
CLSQ-1020-30N	10×20	-30	3.0	2.1	-31.4	13.80
CLSQ-1020-40N	10×20	-40	3.0	2.3	-41.6	18.40
CLSQ-1515-20N	15×15	-20	6.0	2.1	-21.5	9.20
CLSQ-1515-25N	15×15	-25	5.0	2.2	-26.5	11.50
CLSQ-1515-30N	15×15	-30	4.0	1.8	-31.2	13.80
CLSQ-1515-40N	15×15	-40	4.0	2.4	-41.6	18.40
CLSQ-1525-20N	15×25	-20	6.0	2.1	-21.5	9.20
CLSQ-1525-25N	15×25	-25	5.0	2.2	-26.5	11.50
CLSQ-1525-30N	15×25	-30	4.0	1.8	-31.2	13.80
CLSQ-1525-40N	15×25	-40	4.0	2.4	-41.6	18.40
CLSQ-2020-25N	20×20	-25	7.0	1.2	-25.8	11.50
CLSQ-2020-30N	20×20	-30	6.0	1.7	-31.2	13.80
CLSQ-2020-40N	20×20	-40	5.0	2.0	-41.4	18.40
CLSQ-2020-50N	20×20	-50	4.0	1.7	-51.2	23.00
CLSQ-2020-60N	20×20	-60	4.0	2.1	-61.5	27.60
CLSQ-2020-70N	20×20	-70	4.0	2.4	-71.6	32.20
CLSQ-2020-80N	20×20	-80	4.0	2.6	-81.8	36.80
CLSQ-2020-100N	20×20	-100	4.0	2.9	-102.0	46.00
CLSQ-2020-130N	20×20	-130	4.0	3.2	-132.2	59.80
CLSQ-2020-150N	20×20	-150	4.0	3.3	-152.2	69.00
CLSQ-2020-200N	20×20	-200	4.0	3.5	-202.4	92.00
CLSQ-2020-250N	20×20	-250	4.0	3.6	-252.4	115.00
CLSQ-2020-300N	20×20	-300	4.0	3.6	-302.5	138.00
CLSQ-2040-25N	20×40	-25	7.0	1.2	-25.8	11.50
CLSQ-2040-30N	20×40	-30	6.0	1.7	-31.2	13.80
CLSQ-2040-40N	20×40	-40	5.0	2.0	-41.4	18.40
CLSQ-2040-50N	20×40	-50	4.0	1.7	-51.2	23.00
CLSQ-2040-60N	20×40	-60	4.0	2.1	-61.5	27.60
CLSQ-2040-70N	20×40	-70	4.0	2.4	-71.6	32.20
CLSQ-2040-80N	20×40	-80	4.0	2.6	-81.8	36.80
CLSQ-2050-100N	20×50	-100	4.0	2.9	-102.0	46.00
CLSQ-2050-130N	20×50	-130	4.0	3.2	-132.2	59.80
CLSQ-2050-150N	20×50	-150	4.0	3.3	-152.2	69.00
CLSQ-2050-200N	20×50	-200	4.0	3.5	-202.4	92.00
CLSQ-2050-250N	20×50	-250	4.0	3.6	-252.4	115.00
CLSQ-2050-300N	20×50	-300	4.0	3.6	-302.5	138.00
CLSQ-3030-50N	30×30	-50	7.0	1.4	-51.0	23.00
CLSQ-3030-60N	30×30	-60	6.0	1.6	-61.1	27.60
CLSQ-3030-70N	30×30	-70	6.0	2.3	-71.6	32.20
CLSQ-3030-80N	30×30	-80	5.0	1.8	-81.2	36.80
CLSQ-3030-100N	30×30	-100	5.0	2.5	-101.7	46.00
CLSQ-3030-130N	30×30	-130	5.0	3.1	-132.1	59.80
CLSQ-3030-150N	30×30	-150	5.0	3.3	-152.3	69.00
CLSQ-3030-200N	30×30	-200	5.0	3.8	-202.6	92.00
CLSQ-3030-250N	30×30	-250	5.0	4.0	-252.8	115.00
CLSQ-3030-300N	30×30	-300	5.0	4.2	-302.9	138.00
CLSQ-3040-50N	30×40	-50	7.0	1.4	-51.0	23.00
CLSQ-3040-60N	30×40	-60	6.0	1.6	-61.1	27.60
CLSQ-3040-70N	30×40	-70	6.0	2.3	-71.6	32.20
CLSQ-3040-80N	30×40	-80	5.0	1.8	-81.2	36.80
CLSQ-3050-100N	30×50	-100	5.0	2.5	-101.7	46.00
CLSQ-3050-130N	30×50	-130	5.0	3.1	-132.1	59.80
CLSQ-3050-150N	30×50	-150	5.0	3.3	-152.3	69.00
CLSQ-3050-200N	30×50	-200	5.0	3.8	-202.6	92.00
CLSQ-3050-250N	30×50	-250	5.0	4.0	-252.8	115.00
CLSQ-3050-300N	30×50	-300	5.0	4.2	-302.9	138.00

Application Systems

Optics & Optical Coatings

Opto-Mechanics

Bases

Manual Stages

Actuators & Adjusters

Motorized Stages

Light Sources & Laser Safety

Index

Guide

Mirrors

Beamsplitters

Polarizers

Lenses

Multi-Element Optics

Filters

Prisms

Substrates/Windows

Optical Data

Maintenance

Selection Guide

Plano Convex Lenses

Plano Concave Lenses

Biconvex Lenses

Biconcave Lenses

Kit

Reasonable Lens

Cylindrical

Others

Contact sheet

Catalog Code W3806

Contact sheet for Special Order for Cylindrical Lens

☐ Estimation ☐ Order

Date

☐ To: Sigma Koki Co., Ltd. **FAX +81-3-5638-6550**Application
SystemsOptics &
Optical
CoatingsOpto-
Mechanics

Bases

Manual
StagesActuators &
AdjustersMotorized
StagesLight Sources &
Laser Safety

Index

Guide

Mirrors

Beamsplitters

Polarizers

Lenses

Multi-Element Optics

Filters

Prisms

Substrates/Windows

Optical Data

Maintenance

Selection Guide

Plano Convex
Lenses
Plano Concave
Lenses

Biconvex Lenses

Biconcave Lenses

Kit

Reasonable Lens

Cylindrical

Others

Affiliation (Organization Name)					
Department					
TEL		FAX		E-mail	
Country/Address					
Name & Designation		(Tentative name is okay)			
Drawing Number		Estimate	☐ Yes: by Date ☐ No		
Desired Delivery Date		Budget	JP Yen		
Specification of lens	Quantity				
	Selected from standard product	Part Number	If you are using a Spherical lens of standard product, please fill in the product number.		
	Custom-made	Type	☐ Plano-convex ☐ Plano-concave		
		Material	☐ BK7 ☐ Synthetic fused silica ☐ Synthetic fused silica for Excimer Laser ($\lambda =$) ☐ Other ()		
		Focal length	$f =$ mm	●When there is no specification of the design wavelength, 546.1nm and standard products. ●May want to change the center thickness by the case of the production. ●If you do not specify the dimension tolerance, we will apply our standard tolerance instead.	
		Design wavelength	$\lambda =$ nm		
		Diameter			
		a	mm		
		b	mm		
		tc	mm		
Specifications of Coating	With or without coating	☐ Non ☐ Single-layer anti-reflection coating ☐ Broadband multi-layer anti-reflection coating ☐ Other ()			
	Wavelength Used	$\lambda =$ nm	Type of AR (If required)		
Other	* Write more detailed specifications here. (Rough illustration is acceptable.)				

Sigma Koki Co., Ltd.


General Catalog 02

Rod Lenses are cylindrical lenses with polished on its circumference surface. These are used in several applications including laser focusing beam into a line, changing beam shape into sheet-shape or irradiating at a distance with elongated line.

- Focal length shortened by reducing the rod lens diameter compared to cylindrical lenses.
- Precise processing and polishing yields distortion-free, flex free straight line gain when projection is made from a distance.
- Suitable for collecting large amount of light when installed it in front of a line sensor.




Schematic



Outline Drawing

(in mm)



Specifications

Material	BK7
Design wavelength	546.1nm
Polish	Rod circumference surface polished
Coating	Uncoated
Surface Quality (Scratch-Dig)	40-20


Guide

- ▶ Please contact our Sales Division for rod lens with AR coating requirements.
- ▶ Contact our Sales Division for customized products. (customized on outer diameter, length, etc.)
- ▶ Use MLH-10 (Small Lens Claw) or MLH-SF (Selfoc® Lens Claws) to hold cylindrical lens.
- ▶ [WEB Reference](#) [Catalog Code](#) W4021, [WEB Reference](#) [Catalog Code](#) W4051

Attention

- ▶ Align the beam on the circumference surface for proper use.
- ▶ Notable spherical aberration may occur due to the small curvature of rod lenses it is recommended that you use cylindrical lenses for precise optical systems. [Reference](#) B140
- ▶ When diverging laser beam through rod lenses, operators' eyes may be exposed to diverged beam. Make sure to check the power of laser and to apply safety goggles before using rod lenses.
- ▶ Rod lenses are not chamfered use caution when handling the product.

BK7(Uncoated) Typical Transmittance Data



Specifications


Part Number	Diameter ϕD [mm]	Length L [mm]	Focal length f [mm]	Back focal length f_b [mm]
RODB-03L06	$\phi 3$	6	2.2	0.7
RODB-03L08	$\phi 3$	8	2.2	0.7
RODB-03L10	$\phi 3$	10	2.2	0.7
RODB-04L06	$\phi 4$	6	2.9	0.9
RODB-04L08	$\phi 4$	8	2.9	0.9
RODB-04L10	$\phi 4$	10	2.9	0.9
RODB-05L06	$\phi 5$	6	3.7	1.2
RODB-05L08	$\phi 5$	8	3.7	1.2
RODB-05L10	$\phi 5$	10	3.7	1.2

Compatible Optic Mounts


MLH-10 / MLH-SF + MLH-10ADP-2 + FOP-1

Fly-Eye Lens is used when making illumination light of homogeneous brightness for projector and semiconductor manufacturing equipment. If used in fly-eye lenses of 2 pieces in pair, even strong diffusing light such as a lamp, it can be a light of rectangular intensity distribution.

- Two types are available for focal length of 42.07mm with partitions of 7×9 and 38.24mm with partition of 10×13 .
- With an anti-reflection coating, the incident light can be almost used as illumination light without loss of light.
- By using press molding technology to make the glass lens we have achieved both high performance and low cost.



Schematic



Specifications

Material	B270® or equivalent
Coating	Anti-reflection coating (dielectric multilayer coating)
Design Wavelength	400 – 700nm
Incident Angle	0° (Coating specification)
Focal Length Tolerance	±3%
Optical Axis Center Position Tolerance	±1.5mm

* B270® is a registered trademark of SCHOTT AG.

Guide

- ▶ We can provide a custom lens array suitable for your application. Please contact our Sales Division with your request and supply the number of divisions, the focal length, the size and the wavelength.
- ▶ We can also produce the optical systems using fly lens array.


Attention

- ▶ Imaging lens is not included in the specification. In addition, fly-eye lens array is sold one by one.
- ▶ When used in a laser with high coherence, noise may be generated in the intensity distribution due to the diffraction by the border line of the lens.


Outline Drawing

(in mm)

FEL-5860R03-42.07PM



FEL-46S03-38.24PM




Specifications

Part Number	Focal length [mm]	Radius of Curvature [mm]
FEL-5860R03-42.07PM	42.07	22.0
FEL-46S03-38.24PM	38.24	20.0


The lens of short focal length, which is thicker, has been made to a step structure and to a thin plate shape with the characteristics of the lens.

It can be used as a substitute for the lens for a loupe and LED light.

- Since it is processed directly on the acrylic plate of 2mm thickness, it is difficult to be deformed and the performance is stable.
- There are four focal lengths offered from 5mm to 20mm.
- Compared with the lens of the same focal length, it is lighter and lens will not protrude from the edge of holder.




Schematic



Outline Drawing

(in mm)



Specifications

Material	Acrylic CLAREX
Refractive Index	n=1.49
Focal Length Tolerance	±10% of focal length (in a clear aperture)

* CLAREX is a registered trademark of Nitto Jushi Kogyo Co., Ltd..

Guide

- ▶ This product is available with different focal lengths and sizes that are not listed on-line or in our catalog. Please contact our Sales Team with your requests.

Attention

- ▶ There is a direction to the Fresnel lens. Surface that is processed is equivalent to convex.
- ▶ When used in laser, since diffracted light is generated in the step structure, some of the light will also leaked around the focused spot.
- ▶ Characteristics as the lens is obtained in the range of $\phi 50\text{mm}$, but it is not guaranteed the accuracy of the focal length out of the scope of the clear aperture.
- ▶ When rubbing strongly the processed surface of the fresnel lens, performance may be degraded. Please do not touch directly the surface.
- ▶ When exposed to high temperature of 80°C or more, it may be deformed and performance can be severely degraded.
- ▶ Please do not use organic solvents such as acetone and chloroform which will dissolved and damage the step structure.
- ▶ At the time of delivery, it is delivered with a protection sheet affixed to the surface. Please remove this protective sheet before using.

Specifications

Part Number	Focal length [mm]	Prism pitch [mm]	Clear Aperture [mm]
FRL-50S-05P	5	0.05	$\phi 10$
FRL-50S-10P	10	0.05	$\phi 20$
FRL-50S-15P	15	0.05	$\phi 30$
FRL-50S-20P	20	0.08	$\phi 40$

Application Systems

Optics & Optical Coatings

Opto-Mechanics

Bases

Manual Stages

Actuators & Adjusters

MotORIZED Stages

Light Sources & Laser Safety

Index

Guide

Mirrors

Beamsplitters

Polarizers

Lenses

Multi-Element Optics

Filters

Prisms

Substrates/Windows

Optical Data

Maintenance

Selection Guide

Plano Convex Lenses
Plano Concave Lenses

Biconvex Lenses

Biconcave Lenses

Kit

Reasonable Lens

Cylindrical

Others

Micro Spheres | MS

RoHS

Application Systems

Optics & Optical Coatings

Opto-Mechanics

Bases

Manual Stages

Actuators & Adjusters

Motorized Stages

Light Sources & Laser Safety

Index

Guide

Mirrors

Beamsplitters

Polarizers

Lenses

Multi-Element Optics

Filters

Prisms

Substrates/Windows

Optical Data

Maintenance

Selection Guide

Plano Convex Lenses

Plano Concave Lenses

Biconvex Lenses

Biconcave Lenses

Kit

Reasonable Lens

Cylindrical


Others

Micro Spheres are mostly used for coupling optical fibers to laser diodes and other fibers or detectors.

- Since these ball lenses are much smaller they are suitable for applications requiring reduction in size and weight. The lens circumference are completely polished and should be handled carefully to avoid damage
- Both AR coated and uncoated are available. Single layer MgF_2 is available in 3 variations of bandwidths 400 – 700nm, 700 – 900nm and 1300 – 1550nm.
- Design wavelength of the focal lengths is 587.6nm (yellow helium line [d])



Schematic



Specifications

Material	LaSF9
Coating	Uncoated: MS-P Anti-reflection coating: MS-P1, -P2, -P3
Clear aperture	80% of actual aperture
Surface Quality (Scratch-Dig)	40-20

Guide

- ▶ Please contact our Sales Division for micro lenses with AR coatings.
- ▶ Contact our Sales Division for customized products. (customized on outer diameter, etc.)


Attention

- ▶ Small ball lenses with anti-reflective coating are marked at its optical axis to identify the direction of coating. After installation of a small spherical lens, clean the ball lens by wiping with alcohol and check marks on the optical axis.
- ▶ Small ball lenses have a short focal length, so it is possible to focus the beam at a very large angle. However, since spherical aberration is large, the focused spot size will not be small.


Outline Drawing

(in mm)

Uncoated




With coating



● Tolerance
Diameter $\phi D \pm 0.001$

LaSF9 (Uncoated) Typical Transmittance Data

T: Transmission



Uncoated				
Part Number	Wavelength Range [nm]	Diameter ϕ D [mm]	f (588nm) [mm]	fb (588nm) [mm]
MS-01-0.54P	400 – 2000	ϕ 1	0.54	0.04
MS-02-1.1P	400 – 2000	ϕ 2	1.09	0.09
MS-03-1.7P	400 – 2000	ϕ 3	1.63	0.13
MS-05-2.8P	400 – 2000	ϕ 5	2.72	0.22
MS-08-4.35P	400 – 2000	ϕ 8	4.35	0.35

632.8nm with AR coating				
Part Number	Wavelength Range [nm]	Diameter ϕ D [mm]	f (633nm) [mm]	fb (633nm) [mm]
MS-01-0.54P1	400 – 700	ϕ 1	0.55	0.05
MS-02-1.1P1	400 – 700	ϕ 2	1.09	0.09
MS-03-1.7P1	400 – 700	ϕ 3	1.64	0.14
MS-05-2.8P1	400 – 700	ϕ 5	2.73	0.23
MS-08-4.35P1	400 – 700	ϕ 8	4.37	0.37

830nm with AR coating				
Part Number	Wavelength Range [nm]	Diameter ϕ D [mm]	f (830nm) [mm]	fb (830nm) [mm]
MS-01-0.54P2	700 – 900	ϕ 1	0.55	0.05
MS-02-1.1P2	700 – 900	ϕ 2	1.10	0.10
MS-03-1.7P2	700 – 900	ϕ 3	1.65	0.15
MS-05-2.8P2	700 – 900	ϕ 5	2.75	0.25
MS-08-4.35P2	700 – 900	ϕ 8	4.41	0.41

1300nm with AR coating				
Part Number	Wavelength Range [nm]	Diameter ϕ D [mm]	f (1300nm) [mm]	fb (1300nm) [mm]
MS-01-0.54P3	1300 – 1550	ϕ 1	0.56	0.06
MS-02-1.1P3	1300 – 1550	ϕ 2	1.11	0.11
MS-03-1.7P3	1300 – 1550	ϕ 3	1.67	0.17
MS-05-2.8P3	1300 – 1550	ϕ 5	2.78	0.28
MS-08-4.35P3	1300 – 1550	ϕ 8	4.45	0.45

Table of Focal Length Shifts According to Wavelength

Wavelength Range [nm]	LaSF9 Refractive index	Diameter ϕ D [mm]									
		ϕ 1		ϕ 2		ϕ 3		ϕ 5		ϕ 8	
		Focal length f [mm]	Back focal length fb [mm]	Focal length f [mm]	Back focal length fb [mm]	Focal length f [mm]	Back focal length fb [mm]	Focal length f [mm]	Back focal length fb [mm]	Focal length f [mm]	Back focal length fb [mm]
404.7	1.8984	0.53	0.03	1.06	0.06	1.58	0.08	2.64	0.14	4.23	0.23
435.8	1.8847	0.53	0.03	1.07	0.07	1.60	0.10	2.66	0.16	4.26	0.26
480	1.8706	0.54	0.04	1.07	0.07	1.61	0.11	2.69	0.19	4.30	0.30
546.1	1.8565	0.54	0.04	1.08	0.08	1.63	0.13	2.71	0.21	4.34	0.34
587.6	1.8503	0.54	0.04	1.09	0.09	1.63	0.13	2.72	0.22	4.35	0.35
632.8	1.8449	0.55	0.05	1.09	0.09	1.64	0.14	2.73	0.23	4.37	0.37
706.5	1.8383	0.55	0.05	1.10	0.10	1.64	0.14	2.74	0.24	4.39	0.39
830	1.8310	0.55	0.05	1.10	0.10	1.65	0.15	2.75	0.25	4.41	0.41
852.1	1.8300	0.55	0.05	1.10	0.10	1.65	0.15	2.76	0.26	4.41	0.41
1060	1.8229	0.55	0.05	1.11	0.11	1.66	0.16	2.77	0.27	4.43	0.43
1300	1.8176	0.56	0.06	1.11	0.11	1.67	0.17	2.78	0.28	4.45	0.45
1529.6	1.8136	0.56	0.06	1.11	0.11	1.67	0.17	2.79	0.29	4.46	0.46

Application Systems

Optics & Optical Coatings

Opto-Mechanics

Bases

Manual Stages

Actuators & Adjusters

Motorized Stages

Light Sources & Laser Safety

Index

Guide

Mirrors

Beamsplitters

Polarizers

Lenses

Multi-Element Optics

Filters

Prisms

Substrates/Windows

Optical Data

Maintenance

Selection Guide

Plano Convex Lenses
Plano Concave Lenses

Biconvex Lenses

Biconcave Lenses

Kit

Reasonable Lens

Cylindrical

Others

Micro Lenses | SLM

RoHS

Micro lenses are spherical plano convex/biconvex lenses with diameters smaller than 4mm. These small lenses are designed for use in equipment and instruments that demand lighter and smaller footprint optics.

- Spherical plano convex lenses are useful when parallel beams are converged or lights from sources are converted to parallel beams, i.e., at infinite conjugate ratios.
- Spherical biconvex lenses are useful when lights from sources are converged or images are relayed to other optical systems, i.e., at unit conjugate ratios.
- Since these lenses are designed at the wavelength 587.6nm (yellow helium line [d]), the focal lengths of them vary at other wavelengths.



Specifications

Material	LaSF9, SK2, BK7
Design wavelength	587.6nm
Coating	Uncoated
Centration	<3'
Surface Quality (Scratch-Dig)	40-20

Guide


- In addition to our standard products listed on-line and in the catalog, custom products are available. Please contact our Sales Division for assistance with your request.

Attention


- The micro lenses have spherical aberration and the focal length will vary depending on the wavelength. Please check the "wavelength characteristic of the focal length data" on the Web for the focal lengths of each wavelength. [WEB Reference](#) [Catalog Code](#) W3072
- The plano convex lenses are designed for parallel light to be incident to the convex surface. Using the lens in reverse may increase the spherical aberration and the focused spot may enlarge and the image will appear out of focus.
- Transmissions losses due to reflection off the front and rear surfaces of the lens can be minimized by coating the surfaces. Consult our Sales Division for anti-reflection coatings suitable for your application.

Schematic

Micro Plano Convex




Micro Plano Concave




Outline Drawing

(in mm)



- Tolerance
Diameter $\phi D_{-0.02}$ Thickness ± 0.2 Focal length $\pm 5\%$

Typical Transmittance Data T: Transmission



Application Systems

Optics & Optical Coatings

Opto-Mechanics

Bases

Manual Stages

Actuators & Adjusters

Motorized Stages

Light Sources & Laser Safety

Index

Guide

Mirrors

Beamsplitters

Polarizers

Lenses

Multi-Element Optics

Filters

Prisms

Substrates/Windows

Optical Data

Maintenance

Selection Guide

Plano Convex Lenses

Plano Concave Lenses

Biconvex Lenses

Biconcave Lenses

Kit

Reasonable Lens

Cylindrical

Others

Plano Convex

Part Number	Diameter ϕD [mm]	Focal length f [mm]	Back focal length f_b [mm]	Edge thickness t_e [mm]	Center thickness t_c [mm]	Material	Radius of curvature r [mm]
SLM-1.5-01P	$\phi 1.5$	1.0	0.56	0.35	0.8	LaSF9	0.85
SLM-1.5-1.5P	$\phi 1.5$	1.5	0.44	1.65	1.9	LaSF9	1.25
SLM-02-1.5P	$\phi 2$	1.5	0.5	1.4	1.9	LaSF9	1.28
SLM-02-02P	$\phi 2$	2.0	1.2	1.2	1.5	LaSF9	1.70
SLM-02-2.5P	$\phi 2$	2.5	1.6	1.3	1.6	LaSF9	2.13
SLM-02-03P	$\phi 2$	3.0	2.2	1.0	1.3	LaSF9	2.55
SLM-03-2.5P	$\phi 3$	2.5	1.4	1.5	2.1	LaSF9	2.13
SLM-03-03P	$\phi 3$	3.0	1.9	1.5	2.0	LaSF9	2.55
SLM-03-04P	$\phi 3$	4.0	3.3	1.0	1.3	LaSF9	3.40
SLM-03-06P	$\phi 3$	6.0	5.1	1.1	1.4	SK2	3.64
SLM-04-04P	$\phi 4$	4.0	2.5	1.5	2.5	SK2	2.43
SLM-04-06P	$\phi 4$	6.0	5.0	0.7	1.3	SK2	3.64
SLM-04-08P	$\phi 4$	8.0	7.1	1.1	1.5	SK2	4.86
SLM-04-10P	$\phi 4$	10.0	9.1	1.2	1.5	SK2	6.07

Biconvex

Part Number	Diameter ϕD [mm]	Focal length f [mm]	Back focal length f_b [mm]	Edge thickness t_e [mm]	Center thickness t_c [mm]	Material	Radius of curvature r [mm]
SLM-03B-03P	$\phi 3$	3	2.4	1.1	1.8	SK2	3.26
SLM-03B-04P	$\phi 3$	4	3.4	1.2	1.8	BK7	3.80
SLM-03B-06P	$\phi 3$	6	5.5	1.1	1.5	BK7	5.93
SLM-04B-04P	$\phi 4$	4	3.2	1.2	2.2	SK2	4.40
SLM-04B-06P	$\phi 4$	6	5.4	1.2	1.9	BK7	5.86
SLM-04B-08P	$\phi 4$	8	7.4	1.2	1.7	BK7	7.97

Plano Concave

Part Number	Diameter ϕD [mm]	Focal length f [mm]	Back focal length f_b [mm]	Edge thickness t_e [mm]	Center thickness t_c [mm]	Material	Radius of curvature r [mm]
SLM-02-04N	$\phi 2$	-4	-4.40	0.95	0.8	LaSF9	-3.40
SLM-03-06N	$\phi 3$	-6	-6.39	1.03	0.8	LaSF9	-5.10
SLM-04-08N	$\phi 4$	-8	-8.37	1.10	0.8	LaSF9	-6.80

Biconcave

Part Number	Diameter ϕD [mm]	Focal length f [mm]	Back focal length f_b [mm]	Edge thickness t_e [mm]	Center thickness t_c [mm]	Material	Radius of curvature r [mm]
SLM-02B-02N	$\phi 2$	-2	-2.13	0.99	0.7	LaSF9	-3.50
SLM-04B-04N	$\phi 4$	-4	-4.16	1.39	0.8	LaSF9	-6.94

Compatible Optic Mounts

MLH-10, -15

Application Systems**Optics & Optical Coatings****Opto-Mechanics****Bases****Manual Stages****Actuators & Adjusters****MotORIZED Stages****Light Sources & Laser Safety****Index****Guide****Mirrors****Beamsplitters****Polarizers****Lenses****Multi-Element Optics****Filters****Prisms****Substrates/Windows****Optical Data****Maintenance****Selection Guide****Plano Convex Lenses****Plano Concave Lenses****Biconvex Lenses****Biconcave Lenses****Kit****Reasonable Lens****Cylindrical****Others**

Application Systems

Optics & Optical Coatings

Opto-Mechanics

Bases

Manual Stages

Actuators & Adjusters

Motorized Stages

Light Sources & Laser Safety

Index

Guide

Mirrors

Beamsplitters

Polarizers

Lenses

Multi-Element Optics

Filters

Prisms

Substrates/Windows

Optical Data

Maintenance

Selection Guide

Plano Convex Lenses

Plano Concave Lenses

Biconvex Lenses

Biconcave Lenses

Kit

Reasonable Lens

Cylindrical


Others

The aspheric shape allows the lens to achieve a shorter focus with smaller spherical aberration than provided by a similar convex surface of a plano convex lens. the lens is used for squeezing small illumination light or condensing efficiently the light emanating from a single point.

- Aspheric lenses can be used in a wide range from the visible to infrared of 1.5μm wavelength.
- There are two types of AGL-31.7P with a reduced spherical aberration by the plano convex lens of BK7 and AGL-12P with high NA using (FDS-90) high refractive index glass (FDS90).
- An aspheric shape can be produced by using a special polishing equipment. Polished Aspheric lenses do not have shrinkage, cracking and chipping which usually appear in molded aspheric lenses.




Schematic



Outline Drawing

(in mm)



- Tolerance
- Diameter $\phi D_{\pm 0.2}$
- Thickness $t_c \pm 0.2$
- Focal length $\pm 7\%$

Specifications

Material	BK7, FDS90
Design Wavelength	587nm
Coating	Uncoated
Shape	Aspheric Plano Convex Polished Both Surfaces
Centration	<5'
Surface Quality (Scratch-Dig)	60-40

Guide


- ▶ Please contact our Sales Division for Aspheric Condenser Lenses with anti-reflection coating.

Attention

- ▶ When the parallel light is incident from the back surface (flat), spherical aberration will not condense into a large point.
- ▶ Since an aspheric plano convex lens is a single lens, the focal length will change depending on the wavelength.
- ▶ Transmissions losses due to reflection off the front and rear surfaces of the lens can be minimized by coating the surfaces. Consult our Sales Division for anti-reflection coatings suitable for your application.

Typical Transmittance Data

T: Transmission



Specifications


Part Number	Diameter ϕD [mm]	Focal length f [mm]	Back focal length f_b [mm]	NA* ($D/2 \times 0.8/f$)	Edge thickness t_e [mm]	Center thickness t_c [mm]	Material
AGL-15-12P	$\phi 15$	12	6	0.50	8.1	11	FDS90
AGL-15-31.7P	$\phi 15$	31.7	28.7	0.19	2.7	4.5	BK7
AGL-20-12P	$\phi 20$	12	6	0.67	5.6	11	FDS90
AGL-20-31.7P	$\phi 20$	31.7	27.7	0.25	2.8	6	BK7

* NA is calculated using 80% of the outer diameter of the lens.


Aspheric and Spherical Lenses

When collecting a lot of light in a lens, it is required the lens which is short focal length and large diameter. However, when input the parallel light to the spherical lens of such conditions, there is the difference between the focal points of the rays passing through the vicinity of and periphery of the optical axis. This phenomenon is called the spherical aberration of the lens. In case of spherical lens, generally since the exceeding refraction occurs at the periphery area, it causes to be focused in closer point to the lens than the light beam of the vicinity of the optical axis. Therefore, if the lens shape is designed such as more gentle curvature of the lens away from the center of optical axis, all parallel light incident on the lens will be focused at one point.

Aspheric lens



Spherical lens




Aspheric condenser lens is a single lens for collection and condensing, which the radius of curvature of one side is changed according to the height from the optical axis to minimize spherical aberration. The other side is plano or convex.

- These lenses can condense light at a short focal length superior to what can be achieved with spherical lenses.
- Since these lenses are molded polished from B270-Superwhite, complex shapes that cannot be polished can be easily manufactured.
- These lenses are designed for the use at infinite conjugate ratios and focal lengths are designed at 587.6nm (yellow helium line [d]).




Schematic



Outline Drawing

(in mm)



- Tolerance
- Diameter $\phi D \pm 0.5$
- Thickness $t_{c,e} \pm 0.5$
- Focal length $\pm 7\%$

Specifications

Material	B270® ($n_d = 1.523$)
Shape	Front surface: Aspherical Rear surface: Plano or Convex
Coating	Uncoated
Maximum operating temperature	170°C
Surface Quality (Scratch-Dig)	80-50

Guide


- ▶ Please contact our Sales Division for Aspheric Condenser Lenses with anti-reflection coating.
- ▶ B270® is a registered trademark of SCHOTT AG Inc.

Attention

- ▶ When the parallel light is incident from the rear (side of plane or large spherical curvature), spherical aberration will not condense into a large point.
- ▶ Aspheric condenser lens is used as an illumination light source. It is not aberration-free for laser focusing.
- ▶ Transmissions losses due to reflection off the front and rear surfaces of the lens can be minimized by coating the surfaces. Consult our Sales Division for anti-reflection coatings suitable for your application.

Typical Transmittance Data

T: Transmission



Specifications

Part Number	Diameter ϕD [mm]	Focal length* ² f [mm]	Back focal length* ² f_b [mm]	NA* ¹ ($D/2 \times 0.8/f$)	Thickness of the edge t_e [mm]	Thickness of the center* ² t_c [mm]	Rear surface
AGL-12-8.5P	$\phi 12$	8.5	5.8	0.56	1.6	5.5	Convex
AGL-12-10.5P	$\phi 12$	10.5	8.2	0.46	1.1	3.5	Plano
AGL-18-12P	$\phi 18$	12	6.9	0.60	3.3	8.8	Convex
AGL-18-15.5P	$\phi 18$	15.5	10.8	0.46	3.0	7.0	Plano
AGL-19-17P	$\phi 19$	17	12.4	0.45	1.8	7.0	Plano
AGL-24-18P	$\phi 24$	18	11.4	0.53	2.0	10.0	Plano
AGL-25-20P	$\phi 25$	20	15.1	0.50	1.2	7.5	Plano
AGL-30-23.5P	$\phi 30$	23.5	14.3	0.51	3.8	14.0	Plano
AGL-30-26.5P	$\phi 30$	26.5	19.3	0.45	3.0	11.0	Plano
AGL-32.5-23.5P	$\phi 32.5$	23.5	15.1	0.55	2.5	14.0	Convex
AGL-38-34.5P	$\phi 38$	34.5	26.6	0.44	1.5	12.0	Plano
AGL-50-39P	$\phi 50$	39	25.5	0.51	2.8	20.5	Plano
AGL-50-50P	$\phi 50$	50	40.6	0.40	2.5	14.4	Convex

*1 NA is calculated using 80% of the outer diameter of the lens.

*2 Since this is a molding lens, therefore, it typically only can be used for illumination purpose.

Compatible Optic Mounts

LHF-20S, -25S, -30S, -50S / LHA-25, 60 / SLH-25, -50 / MLH-15

High Precision Polished Aspheric Lenses

AGL-E/AGL-G

RoHS

Application
SystemsOptics &
Optical
CoatingsOpto-
Mechanics

Bases

Manual
StagesActuators &
AdjustersMotorized
StagesLight Sources &
Laser Safety

Index

Guide

Mirrors

Beamsplitters

Polarizers

Lenses

Multi-Element Optics

Filters

Prisms

Substrates/Windows

Optical Data

Maintenance

Selection Guide

Plano Convex

Lenses

Plano Concave

Lenses

Biconvex Lenses

Biconcave Lenses

Kit

Reasonable Lens

Cylindrical

Others


These precision polished aspheric lenses can condense the collimated light into the range of diffraction limited.

These lenses are ideally suited for collimating the LD emitted light or focusing the collimated light into the optical fiber.

- High numerical apertures for effective light condensing.
- Surface irregularity of convex surface is less than $0.1\mu\text{m}$ for AGL-EA/AGL-GA series and less than $0.5\mu\text{m}$ for AGL-EB/AGL-GB series.




Schematic



Outline Drawing

(in mm)



- Tolerance
- Diameter $\phi D_{H,1}$
- Thickness $t_{c \pm 0.1}$
- Focal length $\pm 1\%$

Specifications

Material	S-LAH64
Refractive Index	1.792 (546.1nm), 1.777 (780nm)
Abbe number vd	47.37
Rear surface form	Plano
Centration	< 3'
Coating	Uncoated
Clear aperture	90% of diameter
Surface Quality (Scratch-Dig)	60-40


Guide

- High precision polished aspheric lens with anti-reflection coating on are available upon request.
- To mount the high precision polished aspheric lenses, fixed lens holders (LHF-S, LHA) are available.
- [WEB Reference](#) [Catalog Code](#) W4015, [WEB Reference](#) [Catalog Code](#) W4020
- Contact our Sales Division with your request for custom focal length, diameter and NA not listed on our website or in the catalog.

Attention

- There is a direction to put a light in the High precision polished aspheric lens. Please make sure to put the incident parallel light from the convex side.
- If it reversed, the spherical aberration is deteriorated and the focused spot becomes large.
- If the light other than the design wavelength is focused, the focal spot may not reach a diffraction limit due to a residual aberration.
- Since a high precision polished aspheric lens is not chromatically corrected, the focal length (back focal length) will change depending on the wavelength.
- Since there is no anti-reflection coating on the lens, by the reflection loss of the front surface and the back surface, the transmittance is 90% or less.

Typical Transmittance Data T: Transmission



Specifications								
Part Number	Designwav-length [nm]	Diameter ϕ D [mm]	Focal length f [mm]	Back focal length fb [mm]	NA	Edge thickness te [mm]	Center thickness tc [mm]	Surface irregularity of convex surface [μ m]
AGL-10-EA-08P	546.1	ϕ 10	8	5.91	0.54	1.82	3.9	< 0.1
AGL-10-EA-10P	546.1	ϕ 10	10	7.77	0.44	2.37	4.0	< 0.1
AGL-15-EA-12P	546.1	ϕ 15	12	8.93	0.54	2.38	5.5	< 0.1
AGL-20-EA-15P	546.1	ϕ 20	15	11.10	0.55	2.54	7.0	< 0.1
AGL-20-EA-18P	546.1	ϕ 20	18	13.93	0.51	3.65	7.3	< 0.1
AGL-25-EA-20P	546.1	ϕ 25	20	15.64	0.57	2.68	7.85	< 0.1
AGL-25-EA-24P	546.1	ϕ 25	24	19.63	0.49	3.60	7.85	< 0.1
AGL-30-EA-24P	546.1	ϕ 30	24	18.99	0.56	2.80	9.0	< 0.1
AGL-40-EA-30P	546.1	ϕ 40	30	22.47	0.60	4.59	13.5	< 0.1
AGL-50-EA-38P	546.1	ϕ 50	38	28.51	0.60	6.03	17.0	< 0.1
AGL-10-EB-08P	546.1	ϕ 10	8	5.91	0.54	1.82	3.9	< 0.5
AGL-10-EB-10P	546.1	ϕ 10	10	7.77	0.44	2.37	4.0	< 0.5
AGL-15-EB-12P	546.1	ϕ 15	12	8.93	0.54	2.38	5.5	< 0.5
AGL-20-EB-15P	546.1	ϕ 20	15	11.10	0.55	2.54	7.0	< 0.5
AGL-20-EB-18P	546.1	ϕ 20	18	13.93	0.51	3.65	7.3	< 0.5
AGL-25-EB-20P	546.1	ϕ 25	20	15.64	0.57	2.68	7.85	< 0.5
AGL-25-EB-24P	546.1	ϕ 25	24	19.63	0.49	3.60	7.85	< 0.5
AGL-30-EB-24P	546.1	ϕ 30	24	18.99	0.56	2.80	9.0	< 0.5
AGL-40-EB-30P	546.1	ϕ 40	30	22.47	0.60	4.59	13.5	< 0.5
AGL-50-EB-38P	546.1	ϕ 50	38	28.51	0.60	6.03	17.0	< 0.5
AGL-10-GA-08P	780	ϕ 10	8	5.89	0.54	1.76	3.9	< 0.1
AGL-10-GA-10P	780	ϕ 10	10	7.75	0.44	2.33	4.0	< 0.1
AGL-15-GA-12P	780	ϕ 15	12	8.91	0.54	2.31	5.5	< 0.1
AGL-20-GA-15P	780	ϕ 20	15	11.07	0.61	2.43	7.0	< 0.1
AGL-20-GA-18P	780	ϕ 20	18	13.89	0.51	3.57	7.3	< 0.1
AGL-25-GA-20P	780	ϕ 25	20	15.59	0.58	2.54	7.85	< 0.1
AGL-25-GA-24P	780	ϕ 25	24	19.58	0.49	3.51	7.85	< 0.1
AGL-30-GA-24P	780	ϕ 30	24	18.94	0.56	2.65	9.0	< 0.1
AGL-40-GA-30P	780	ϕ 40	30	22.40	0.61	4.38	13.5	< 0.1
AGL-50-GA-38P	780	ϕ 50	38	28.43	0.61	5.76	17.0	< 0.1
AGL-10-GB-08P	780	ϕ 10	8	5.89	0.54	1.76	3.9	< 0.5
AGL-10-GB-10P	780	ϕ 10	10	7.75	0.44	2.30	4.0	< 0.5
AGL-15-GB-12P	780	ϕ 15	12	8.91	0.54	2.31	5.5	< 0.5
AGL-20-GB-15P	780	ϕ 20	15	11.07	0.61	2.43	7.0	< 0.5
AGL-20-GB-18P	780	ϕ 20	18	13.89	0.51	3.57	7.3	< 0.5
AGL-25-GB-20P	780	ϕ 25	20	15.59	0.58	2.57	7.85	< 0.5
AGL-25-GB-24P	780	ϕ 25	24	19.58	0.49	3.51	7.85	< 0.5
AGL-30-GB-24P	780	ϕ 30	24	18.94	0.56	2.65	9.0	< 0.5
AGL-40-GB-30P	780	ϕ 40	30	22.40	0.61	4.38	13.5	< 0.5
AGL-50-GB-38P	780	ϕ 50	38	28.43	0.61	5.76	17.0	< 0.5

Application
SystemsOptics &
Optical
CoatingsOpto-
Mechanics

Bases

Manual
StagesActuators &
AdjustersMotorized
StagesLight Sources &
Laser Safety

Index

Guide

Mirrors

Beamsplitters

Polarizers

Lenses

Multi-Element Optics

Filters

Prisms

Substrates/Windows

Optical Data

Maintenance

Selection Guide

Plano Convex
Lenses
Plano Concave
Lenses

Biconvex Lenses

Biconcave Lenses

Kit

Reasonable Lens

Cylindrical

Others

Calcium Fluoride Plano Convex Lens

SLCFU

RoHS

Catalog
Code

W3189

Application
SystemsOptics &
Optical
CoatingsOpto-
Mechanics

Bases

Manual
StagesActuators &
AdjustersMotorized
StagesLight Sources &
Laser Safety

Index

Guide

Mirrors

Beamsplitters

Polarizers

Lenses

Multi-Element Optics

Filters

Prisms

Substrates/Windows

Optical Data

Maintenance

Selection Guide

Plano Convex
Lenses
Plano Concave
Lenses

Biconvex Lenses

Biconcave Lenses

Kit

Reasonable Lens

Cylindrical


Others

Calcium fluoride (CaF_2) is a crystal which has excellent transmission characteristics in a wide wavelength range from ultraviolet (200nm) to near-infrared (8 μm).

- Impurities and crystal defects were reduced, and the transmission characteristics in the ultraviolet region were increased. CaF_2 is used for the range from the ultraviolet to the infrared.
- When compared with other crystals, CaF_2 has high durability to moisture, and it can be treated the same as the general optical elements.
- Since CaF_2 is isotropic crystal, birefringence (polarization characteristics) does not occur.




Schematic



Outline Drawing


(in mm)



Specifications

Part Number	Focal length f [mm]	Back focal length fb [mm]	Edge thickness t_e [mm]	Center thickness t_c [mm]
SLCFU-25-50P	50	48	2.0	6.4
SLCFU-25-100P	100	98	2.0	4.1
SLCFU-25-150P	150	148	2.0	3.4
SLCFU-25-200P	200	198	2.0	3.0

Typical Transmittance Data T: Transmission



Specifications

Material	CaF_2 for Optical Crystal
Design Wavelength	5 μm
Coating	Uncoated
Surface Reflectance	3% (per side)
Shape	Spherical Plano Convex, Polished Both Surfaces
Centration	<3'
Clear Aperture	90% of diameter
Surface Quality (Scratch-Dig)	60-40

Guide

- It is available with an AR coating to reduce the transmission loss at the requested wavelength.
- It is also available for products with different size and focal lengths that are not listed in on the website or in the catalog.

Attention

- It may be broken and be cleaved by a sudden temperature change and shock. CaF_2 has low hardness and scratch upon contact with metal and glass. Please use very carefully.
- There is not an anti-reflection coating on the surfaces and the loss due to surface reflection (3% per surface) results in transmittance of about 94%.

Wavelength dependency data of the focal length (CaF_2 plano convex)

Wavelength	0.2 μm	0.6328 μm	1.064 μm	2.94 μm	5.0 μm	7.0 μm
Focal length f [mm]	40.4	46.2	47.7	47.8	50.0	54.2
	80.8	92.4	93.3	95.6	100.0	108.1
	121.2	138.6	140.0	143.4	150.0	162.5
	161.5	184.8	186.7	191.2	200.0	216.7

Physics


Wavelength [nm]	Refractive Index
193.5	1.502
200.0	1.496
248.4	1.467
308.0	1.453
355.0	1.446
404.7	1.442
488.0	1.437
632.8	1.433
694.3	1.432
780.0	1.430
1064	1.429
2000	1.424
3000	1.418
4000	1.410
5000	1.399
6000	1.386
7000	1.369
8000	1.350
9000	1.327
Density	3.18g/cm ³
Thermal Conductivity	9.71W·m ⁻¹ K ⁻¹
Thermal Expansion Coefficient	24×10 ⁻⁶ /°C (20 - 60°C)

Sapphire crystal is a transparent crystal without absorption from the visible to infrared wavelength of 5μm. In addition, sapphire has extremely hard and resists scratching.

- Sapphire crystal is a very stable material used in optical equipment in the field.
- Since there is no absorption (1.4μm, 2.2μm, 2.7μm) by water (OH radical), it can be used on a lens for the analyzer for near-infrared.




Schematic



Outline Drawing


(in mm)



Specifications

Part Number	Focal length f [mm]	Back focal length fb [mm]	Edge thickness te [mm]	Center thickness tc [mm]
SLSH-25-50P	50	47.7	2.0	4.1
SLSH-25-100P	100	98.3	2.0	3.0
SLSH-25-200P	200	198.6	2.0	2.5

Typical Transmittance Data T: Transmission



Specifications

Material	Optical sapphire crystal (uniaxial crystal)
Design Wavelength	546.1nm
Coating	Uncoated
Shape	Spherical Plano Convex Polished Both Surfaces
Centration	<10'
Clear Aperture	90% of diameter
Surface Quality (Scratch-Dig)	60-40

Guide

- Sapphire jewelry is the thing that metal ions such as iron and titanium are mixed with natural sapphire crystal. The artificial sapphire crystal is colorless and transparent. It is available for the AR coating to reduce the transmission loss at the requested wavelength.
- It can be used safely because it is harmless to the human body.

Attention

- Transmissions losses due to reflection off the front and rear surfaces can be minimized by coating the surfaces. Consult our Sales Division for anti-reflection coatings suitable for your application.

Physics

Wavelength [nm]	Refractive Index
248.4	1.834
325.0	1.804
365.0	1.794
404.7	1.786
587.6	1.769
694.3	1.764
1014	1.756
1800	1.742
2200	1.733
3400	1.699
4500	1.650
Density	3.98g/cm ³
Thermal Conductivity	42W·m ⁻¹ K ⁻¹ (25°C)
Thermal Expansion Coefficient	6.9×10 ⁻⁶ /°C (Perpendicular to the C axis 200°C) 7.6×10 ⁻⁶ /°C (Parallel to the C axis 200°C)

Application Systems

Optics & Optical Coatings

Opto-Mechanics

Bases

Manual Stages

Actuators & Adjusters

MotORIZED Stages

Light Sources & Laser Safety

Index

Guide

Mirrors

Beamsplitters

Polarizers

Lenses

Multi-Element Optics

Filters

Prisms

Substrates/Windows

Optical Data

Maintenance

Selection Guide

Plano Convex Lenses

Plano Concave Lenses

Biconvex Lenses

Biconcave Lenses

Kit

Reasonable Lens

Cylindrical

Others

Single Lenses for CO₂ Lasers

SLZS

RoHS

Catalog Code

W3074

Application Systems

Optics & Optical Coatings

Opto-Mechanics

Bases

Manual Stages

Actuators & Adjusters

Motorized Stages

Light Sources & Laser Safety

Index

Guide

Mirrors

Beamsplitters

Polarizers

Lenses

Multi-Element Optics

Filters

Prisms

Substrates/Windows

Optical Data

Maintenance

Selection Guide

Plano Convex Lenses

Plano Concave Lenses

Biconvex Lenses

Biconcave Lenses

Kit


Reasonable Lens

Cylindrical

Others


These spherical single lenses are made of zinc selenide. In contrast to other optical materials for infrared wavelengths such as Ge (germanium) or Si (silicon), ZnSe lenses transmit some visible light, facilitating optical axis adjustment (alignment) of infrared laser systems using lower cost He-Ne lasers. Lenses intended for use with CO₂ lasers have AR coatings.

- High powered lasers often emit laser light in the infrared region. Such systems require careful handling, since infrared laser light is invisible. Because of this laser light, preliminary alignment of optical parts in many cases are essential. While zinc selenide transmit some light in the visible spectrum, it allows easier alignment of other optical components.




Schematic

Plano Convex




Plano Concave




Outline Drawing

(in mm)

Plano Convex



Plano Concave



Refractive index	
Wavelength Range [μm]	n
0.58	2.631
0.65	2.584
1.0	2.489
2.2	2.444
4.2	2.432
6.2	2.425
8.2	2.416
10.6	2.403
16.2	2.353
Density	5.27g/cm ³
Thermal expansion coefficient	7.1×10 ⁻⁶ /K
Thermal conductivity	18W·m ⁻¹ K ⁻¹

Important: Treatment of ZnSe optics

ZnSe (Zinc selenide) is Poisonous and harmful substance classified as legal, depending on the specifications, the certificate of delivery may be required for acquisition of Poisonous and harmful substances. **In addition, ZnSe Optics disposal after use is prohibited in general.**

Lenses that are no longer needed, please return it to us. However, we only take back products that we supplied. This policy noted is in Japan and other countries may differ in the treatment of ZnSe (Zinc selenide), please contact your local sales office.

Specifications

Material	ZnSe crystal
Design wavelength	10.6μm
Coating	AR coating (both surfaces)
Transmittance	99% or more
Centration	<3'
Surface Quality (Scratch-Dig)	40-20

Guide


- For other focal length and diameter size not listed on the website or in our current catalog, please contact our Sales Division with your request.

Attention

- Hydrogen selenide is harmful when it comes in contact with strong acids! Do not immerse the lens in hydrochloric or sulphuric acid.
- When light is condensed on the surface of ZnSe, the high power laser beam may produce toxic gases due to the thermal decomposition. In addition, a large amount of gas and powder occurs when the ZnSe lens is damaged by the laser thermal runaway. In case of the ZnSe lens is damaged by any chance, DO NOT handle the lens with your bare hands. Collect the debris and be careful not to inhale the powder and gas generated.
- Please check the "wavelength characteristic of the focal length data" on our web-site. [WEB Reference](#) [Catalog Code](#) W3074
- There is a possibility that the spherical aberration will increase and optical performance of the system will be degraded if use in reverse. The focused spot may enlarge and the image will appear un-focused.

Typical Transmittance Data

T: Transmission



Plano Convex

Part Number	Focal length f [mm]	Edge thickness te [mm]	Center thickness fb [mm]	Radius of curvature r [mm]
SLZS-30-100PCO2	100	2.2	98.8	140.3
SLZS-30-150PCO2	150	2.5	148.8	210.5
SLZS-30-200PCO2	200	2.6	198.8	280.6

Plano Concave


Part Number	Focal length f [mm]	Edge thickness te [mm]	Center thickness fb [mm]	Radius of curvature r [mm]
SLZS-30-50NCO2	-50	4.6	-51.2	-70.2

Zinc selenide (ZnSe) meniscus Lens (ZnSe) is used as a condensing lens with CO₂ laser (10.6μm). The meniscus designed shape is optimized to minimize spherical aberration.

- With anti-reflection coating the loss due to surface reflection can be reduced, and the laser light with high efficiency can be condensed.
- ZnSe crystal has little hygroscopic, it can be handled in the same way as a normal optical element.
- Since ZnSe crystal is a isotropic crystal, it does not have birefringence (polarization characteristics).




Schematic



Outline Drawing

(in mm)



- Tolerance
- Diameter $\phi D_{\pm 0.1}$
- Thickness $t_{\pm 0.1}$
- Focal length $\pm 1.5\%$

Specifications

Material	ZnSe
Design Wavelength	10.6μm
Refractive Index	2.403
Centration	<3'
Coating	AR coating (Wavelength 10.6μm) (Diameter of φ25.4mm is wavelength of 650nm and 10.6μm)
Clear Aperture	90% of diameter
Surface Quality (Scratch-Dig)	40-20

Guide

- ▶ We can also provide window plates (OPZS / WZSA) made with ZnSe for CO₂. [Reference](#) ▶ B321

Attention

- ▶ When the high power laser beam is condensed on the surface of ZnSe, due to the thermal decomposition, toxic gas may occur. In addition, a large amount of gas and powder occur when the ZnSe lens is damaged by the laser thermal run-away. If the ZnSe lens is damaged, DO NOT touch the lens by bare hands. Please collect the debris and be careful not to inhale the powder and gas steam generated.
- ▶ Since meniscus lens is a single lens, the focal length will be changed depending on the wavelength.
- ▶ There is a direction to put a light in the Plano convex lens. Please make sure to put the parallel light from the convex side. If it is reserved, the spherical aberration increases, the focused spot becomes large and the image looks blurred.

Specifications

Part Number	Diameter φD [mm]	Focal length f [mm]	Edge thickness te [mm]	Center thickness tc [mm]	Back focal length fb [mm]	WD [mm]
SLZS2-19-38.1PCO2	φ19.05	38.1	2.0	2.85	36.1	35.6
SLZS2-19-50.8PCO2	φ19.05	50.8	2.0	2.64	49.0	48.6
SLZS2-19-63.5PCO2	φ19.05	63.5	2.0	2.51	61.8	61.5
SLZS2-20-38.1PCO2	φ20.00	38.1	2.0	2.94	36.1	35.5
SLZS2-20-50.8PCO2	φ20.00	50.8	2.0	2.70	48.9	48.5
SLZS2-20-63.5PCO2	φ20.00	63.5	2.0	2.58	61.7	61.4
SLZS2-25.4-38.1PCO2	φ25.40	38.1	3.0	4.52	35.0	34.1
SLZS2-25.4-63.5PCO2	φ25.40	63.5	3.0	3.91	60.9	60.3

Important: Treatment of ZnSe optics

ZnSe (Zinc selenide) is Poisonous and harmful substance classified as legal, depending on the specifications, the certificate of delivery may be required for acquisition of Poisonous and harmful substances. **In addition, ZnSe Optics disposal after use is prohibited in general.**

Lenses that are no longer needed, please return it to us. However, we only take back products that we supplied. This policy noted is in Japan and other countries may differ in the treatment of ZnSe (Zinc selenide), please contact your local sales office.

Application Systems

Optics & Optical Coatings

Opto-Mechanics

Bases

Manual Stages

Actuators & Adjusters

MotORIZED Stages

Light Sources & Laser Safety

Index

Guide

Mirrors

Beamsplitters

Polarizers

Lenses

Multi-Element Optics

Filters

Prisms

Substrates/Windows

Optical Data

Maintenance

Selection Guide

Plano Convex Lenses
Plano Concave Lenses

Biconvex Lenses

Biconcave Lenses

Kit

Reasonable Lens

Cylindrical

Others

Silicon Plano Convex Lens | SLSI

RoHS

Catalog
Code

W3192

Application
SystemsOptics &
Optical
CoatingsOpto-
Mechanics

Bases

Manual
StagesActuators &
AdjustersMotorized
StagesLight Sources &
Laser Safety

Index

Guide

Mirrors

Beamsplitters

Polarizers

Lenses

Multi-Element Optics

Filters

Prisms

Substrates/Windows

Optical Data

Maintenance

Selection Guide

Plano Convex

Lenses

Plano Concave

Lenses

Biconvex Lenses

Biconcave Lenses

Kit

Reasonable Lens


Cylindrical

Others


The single crystal of silicon used in semiconductor has low absorption in the infrared wavelength of 1.2 - 6 μ m and it can be used as an optical element for infrared light. It is a spherical plano convex lens that was made with the silicon single crystal.

It is used as a lens for receiving infrared light and in infrared sensors.

- Even though it looks like the light does not transmit because of its metallic luster, it is transmitting through a wide infrared range of 1.2 - 6 μ m.
- The wavelength of 1.2 μ m or less does not transmit, so it also provides the effect of an infrared transmission filter.
- Since the silicon lens has a refractive index of 3 or more, the lens curvature is slower than when made from standard glass.




Schematic



Outline Drawing


(in mm)



Specifications

Part Number	Focal length f [mm]	Back focal length f_b [mm]	Edge thickness t_e [mm]	Center thickness t_c [mm]
SLSI-25-25P	25	23	2.0	3.3
SLSI-25-50P	50	48	2.0	2.6
SLSI-25-100P	100	98	2.0	2.3

Typical Transmittance Data T: Transmission



Specifications

Material	Silicon (Si)
Design Wavelength	5 μ m
Coating	Uncoated
Surface Reflectance	30% (per side)
Shape	Spherical Plano Convex Polished Both Surfaces
Centration	<3'
Clear Aperture	90% of diameter
Surface Quality (Scratch-Dig)	60-40

Guide

- It is available with an AR coating to reduce the transmission loss by reflection at the requested wavelength.

Attention

- Silicon lens has metallic luster so that visible light is reflected and absorbed. Because of this, no transmittance occurs.
- Silicon lens without an anti-reflection coating has a loss due to surface reflection and results in transmittance of about 50%.

Physics

Wavelength [nm]	Refractive Index
1.2	3.519
1.3	3.503
1.4	3.494
1.5	3.483
1.6	3.473
1.8	3.462
2.0	3.454
2.2	3.449
2.4	3.445
2.6	3.441
2.8	3.437
3.0	3.435
3.4	3.433
3.6	3.431
3.8	3.431
4.0	3.430
4.5	3.428
5.0	3.426
5.5	3.425
6.0	3.424
Density	2.33g/cm ³
Thermal Conductivity	129W·m ⁻¹ ·K ⁻¹ (40°C)
Thermal Expansion Coefficient	4.2×10 ⁻⁶ /°C (25°C)


The single crystal of germanium used in semiconductor is less absorption in the infrared wavelength of 2 - 20 μ m and it can be used as an optical element of the infrared light. It is a single lens which was made with the germanium crystal.

It is used as a lens of a camera to observe the infrared, such as thermography.

- Even though it looks like the light does not transmit because of its metallic luster, it is transmitting through a wide infrared range of 2 - 20 μ m.
- The wavelength of 1.5 μ m or less does not transmit, so it also provides the effect of an infrared transmission filter.
- Since the silicon lens has a refractive index of 4 or more, the lens curvature is slower then when made from standard glass.




Schematic



Outline Drawing


(in mm)



Specifications

Part Number	Focal length f [mm]	Back focal length f_b [mm]	Edge thickness t_e [mm]
SLGE-25-25P	25	24.25	1.95
SLGE-25-50P	50	49.25	2.48
SLGE-25-100P	100	99.25	2.74

Typical Transmittance Data T: Transmission



Specifications

Material	Germanium (Ge)
Design Wavelength	10.6 μ m
Coating	Uncoated
Surface Reflectance	36% (per side)
Shape	Spherical Plano Convex Polished Both Surfaces
Centration	<3'
Clear Aperture	90% of diameter
Surface Quality (Scratch-Dig)	60-40

Guide

► It is available with an AR coating to reduce the transmission loss by reflection at the requested wavelength.

Attention

- Germanium lens can have metallic luster, so that visible light is reflected and absorbed. Because of this, no transmittance occurs.
- Germanium lens without an anti-reflection coating has a loss due to surface reflection and results in transmittance of about 40%.
- For the observation of infrared wavelengths, it is necessary to consider the effect of the radiation spectrum by temperature. In case of using in an environment of 30°C or more, radiant light of infrared (near 9.6 μ m) is emitted from all substances, and it will not be able to properly observe this infrared spectrum.

Physics

Wavelength [nm]	Refractive Index	Remarks column
1064	4.4100	YAG laser
1320	4.3050	communication LD
1550	4.2300	communication LD
2000	4.1200	
3000	4.0443	
4000	4.0250	
5000	4.0162	
6000	4.0115	
7000	4.0086	
8000	4.0067	
9000	4.0054	
9400	4.0049	CO ₂ laser
10600	4.0035	CO ₂ laser
12000	4.0029	
13000	4.0022	
14000	4.0018	
15000	4.0013	
16000	4.0009	
17000	4.0004	
18000	4.0000	
19000	3.9996	
20000	3.9992	
Density	5.33g/cm ³	
Thermal Conductivity	58.6W·m ⁻¹ K ⁻¹ (20°C)	
Thermal Expansion Coefficient	5.5×10 ⁻⁶ /°C (25°C)	

Application
Systems

Optics &
Optical
Coatings

Opto-
Mechanics

Bases

Manual
Stages

Actuators &
Adjusters

Motoeized
Stages

Light Sources &
Laser Safety

Index

Guide

Mirrors

Beamsplitters

Polarizers

Lenses

Multi-Element Optics

Filters

Prisms

Substrates/Windows

Optical Data

Maintenance

Selection Guide

Plano Convex
Lenses
Plano Concave
Lenses

Biconvex Lenses

Biconcave Lenses

Kit

Reasonable Lens

Cylindrical

Others

Contact sheet

Catalog Code W3807

Contact sheet for Special Order for Lenses

☐ Estimation ☐ Order

Date

☐ To: Sigma Koki Co., Ltd. **FAX +81-3-5638-6550**

Affiliation (Organization Name)							
Department							
TEL		FAX		E-mail			
Country/Address							
Name & Designation		(Tentative name is okay)					
Drawing Number			Estimate		☐ Yes: by Date ☐ No		
Desired Delivery Date			Budget		JP Yen		
Specifications of Lens	Quantity						
	Shape	☐ Ball Lens		☐ Aspherical Lens		☐ Lens for CO ₂ Lasers	
		☐ Hemispherical Lens		☐ Cylindrical Lens		☐ Rod Lens	
		☐ Other ()					
Specifications of Coating	Metal coating	☐ Al only ☐ Al+MgF ₂ ☐ Cr+Au ☐ Other ()					
	Dielectric coating	Wavelength Range	$\lambda =$ nm	Incident angle	$\theta =$ °	Reflection rate	%
	Anti-reflection coating	Wavelength Range	$\lambda =$ nm	Incident angle	$\theta =$ °	☐ Single-layer AR coating ☐ Multi-layer AR coating	
	Polarization conditions	☐ Unpolarized ☐ P polarization ☐ S polarization					
Other	* Write more detailed specifications here. (Rough illustration is acceptable.)						

Sigma Koki Co., Ltd.

General Catalog 02

Application Systems

Optics & Optical Coatings

Opto-Mechanics

Bases

Manual Stages

Actuators & Adjusters

Motorized Stages

Light Sources & Laser Safety

Index

Guide

Mirrors

Beamsplitters

Polarizers

Lenses

Multi-Element Optics

Filters

Prisms

Substrates/Windows

Optical Data

Maintenance

Selection Guide

Plano Convex Lenses
Plano Concave Lenses

Biconvex Lenses

Biconcave Lenses

Kit

Reasonable Lens

Cylindrical

Others